

Xmenha Xmenha-GWC-AK57

Xmenha Mini Invisible Bluetooth Earbuds User Manual

Model: Xmenha-GWC-AK57

1. INTRODUCTION

Thank you for choosing the Xmenha Mini Invisible Bluetooth Earbuds. These earbuds are designed for discreet and comfortable listening, featuring a compact size, high-fidelity sound, and intuitive controls. This manual will guide you through the proper use and care of your new earbuds.

Key Features:

- **Mini and Lightweight Design:** Weighing only 2.8g, designed for small ears and comfortable all-day wear.
- **High-Fidelity Sound:** Graphene diaphragm for clear, powerful audio.
- **Clear Calls:** Effective external noise reduction for smooth conversations.
- **One-Step Auto-Pairing:** Automatic connection to the last paired device upon removal from the charging case.
- **Smart Touch Control:** Manage music, volume, calls, and voice assistant directly from the earbuds.
- **Secure and Portable:** Ergonomic in-ear design and compact charging case for easy transport.

2. PACKAGE CONTENTS

Please check the package for the following items:

- 1 Pair of Xmenha Mini Invisible Bluetooth Earbuds
- 1 Charging Case
- 1 USB Type-C Charging Cable
- 1 User Manual

3. SETUP AND FIRST USE

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated; they will automatically begin charging.

2. Connect the Type-C charging cable to the charging port on the case and the other end to a USB power source (e.g., wall adapter, computer).
3. The indicator lights on the charging case will show the charging status. A full charge typically takes approximately 1 hour for the earbuds. The case battery capacity is 300mAh, providing up to 3 full charges for the earbuds.



Image: Charging case and earbud battery indicators. The case has a 300mAh battery, providing up to 3 full charges for the earbuds, which offer approximately 3.5 hours of music playback per charge.

3.2 Pairing with Your Device

The earbuds feature one-step automatic pairing.

1. Ensure your device's Bluetooth is turned on.
2. Open the charging case and remove both earbuds. They will automatically power on and enter pairing mode.
3. On your device, search for Bluetooth devices and select "Xmenha Earbuds" (or similar name) from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.
5. For subsequent uses, the earbuds will automatically connect to the last paired device when removed from the case.

Be mistaken for earplugs

No one noticed you're wearing headphones—they thought they were earplugs



Image: A woman wearing the discreet Xmenha Mini Invisible Bluetooth Earbuds while using a laptop, demonstrating their low-profile design suitable for work environments.

4. OPERATING INSTRUCTIONS

The Xmenha Mini Invisible Bluetooth Earbuds feature smart touch controls for easy management of audio and calls.

4.1 Touch Controls

Action	Function
Single Tap (Left/Right Earbud)	Play/Pause Music, Answer/End Call
Double Tap (Right Earbud)	Next Track
Double Tap (Left Earbud)	Previous Track

Action	Function
Triple Tap (Right Earbud)	Volume Up
Triple Tap (Left Earbud)	Volume Down
Long Press (2 seconds)	Reject Call, Activate Voice Assistant

Note: Touch sensitivity may vary. Ensure your finger covers the touch area completely.

4.2 Power On/Off

- **Power On:** Earbuds automatically power on when removed from the charging case.
- **Power Off:** Earbuds automatically power off and begin charging when placed back into the charging case.

5. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The earbuds are waterproof. However, avoid prolonged submersion in water and ensure they are dry before placing them back in the charging case to prevent damage.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.
- **Charging Port:** Keep the Type-C charging port free of dust and debris.

6. TROUBLESHOOTING

If you encounter any issues with your Xmenha Mini Invisible Bluetooth Earbuds, refer to the following common solutions:

- **Earbuds not pairing:**
 - Ensure both earbuds are fully charged.
 - Place earbuds back into the case, close it, then open and remove them again to re-initiate pairing mode.
 - Turn off and on your device's Bluetooth.
 - Forget the earbuds from your device's Bluetooth list and try pairing again.
- **No sound from one earbud:**
 - Ensure both earbuds are charged and connected.
 - Try resetting the earbuds by placing them in the case and then removing them.
 - Check your device's audio settings to ensure balance is centered.
- **Earbuds not charging:**
 - Ensure the charging cable is securely connected to both the case and the power source.
 - Verify the power source is active.
 - Clean the charging contacts on both the earbuds and inside the case.
- **Touch controls unresponsive:**
 - Ensure your fingers are clean and dry.

- Try restarting the earbuds by placing them in the case and removing them.

If the issue persists, please contact customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	Xmenha
Model Name	Xmenha-GWC-AK57
Color	Black
Form Factor	In-Ear
Noise Control	Sound Isolation
Material	Plastic
Water Resistance Level	Waterproof
Control Method	Touch
Audio Driver Type	Balanced Armature
Earbud Weight	2.8g (per earbud)
Charging Case Battery	300mAh
Earbud Playback Time	Approx. 3.5 hours per charge
Charges from Case	Up to 3 additional charges

8. WARRANTY AND SUPPORT

Xmenha products are designed for reliability and performance. If you encounter any issues or have questions regarding your Xmenha Mini Invisible Bluetooth Earbuds, please refer to the troubleshooting section first. For further assistance, product support, or warranty claims, please contact Xmenha customer service through the retailer where you purchased the product or visit the official Xmenha website. Please retain your proof of purchase for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question