

[Manuals.plus](#) /

› [GreenPan](#) /

› GreenPan Frost 15-in-1 Sorbet & Slushie Machine User Manual

GreenPan Frost (CC010400-001)

GreenPan Frost 15-in-1 Sorbet & Slushie Machine User Manual

Model: Frost (CC010400-001)

Brand: GreenPan

INTRODUCTION

Congratulations on your purchase of the GreenPan Frost 15-in-1 Sorbet & Slushie Machine. This innovative appliance is designed to transform fresh ingredients into a wide variety of frozen desserts and drinks quickly and effortlessly, thanks to its integrated compressor. With multiple modes and texture settings, you can customize your creations to perfection. This manual provides essential information for safe operation, setup, use, maintenance, and troubleshooting to ensure you get the most out of your new machine.



MACHINE À GLACE TOUT-EN-UN

DES GRANITÉS À LA CRÈME GLACÉE MOLLE - UNE MACHINE POUR TOUTES LES DOUCEURS GLACÉES

Image: The GreenPan Frost machine, highlighting its ability to prepare frozen treats in 30 minutes. It is a versatile all-in-one ice cream machine.

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is unplugged from the power outlet before assembly, disassembly, or cleaning.
- Do not immerse the motor base in water or other liquids. Clean with a damp cloth only.
- Keep hands and utensils out of the mixing bowl during operation to prevent injury and damage to the machine.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

- Use only attachments and accessories recommended by the manufacturer.
- Do not use outdoors. This appliance is for household use only.
- Place the appliance on a stable, flat, heat-resistant surface.
- Ensure proper ventilation around the machine during operation.

PACKAGE CONTENTS

Verify that all items are present and in good condition upon unpacking:

- 1 x GreenPan Frost Machine Base
- 1 x Removable Mixing Bowl (1.8 Liters capacity)
- 1 x Installation Rod
- 1 x Silicone Cleaning Brush
- 1 x Bristle Cleaning Brush
- 1 x Accessory Bag
- 2 x Swirling Tips
- 2 x Seals
- 1 x Recipe Book
- 1 x Quick Start Guide
- 1 x Tips Guide



Image: An exploded view diagram of the GreenPan Frost machine, detailing its built-in cooling compressor, double-insulated transparent mixing bowl, 1.8-liter capacity, dishwasher-safe parts, easy cleaning program, and included accessories.

SETUP

1. Unpacking

- Carefully remove all packaging materials and protective films from the machine and its components.
- Retain packaging for future storage or transport.

2. Initial Cleaning

- Before first use, wash all removable parts (mixing bowl, installation rod, swirling tips, seals) in warm, soapy water. Rinse thoroughly and dry completely.
- Wipe the main unit with a damp cloth. Do not immerse the main unit in water.

3. Assembly

- Place the machine on a clean, dry, and stable surface.

- Insert the removable mixing bowl into the main unit.
- Attach the installation rod and desired swirling tip according to the quick start guide.

OPERATING INSTRUCTIONS

1. Basic Operation

The GreenPan Frost machine features an integrated compressor for rapid freezing without pre-cooling. Follow these simple steps:

1. **Prepare Ingredients:** Mix your desired ingredients for your frozen treat. Ensure they are well-combined and at a suitable temperature (usually chilled).
2. **Pour:** Pour the prepared mixture into the removable mixing bowl. Do not exceed the maximum fill line (1.8 L capacity).
3. **Select Mode:** Plug in the machine. Use the 'MODE' button to cycle through the available programs: Slushie, Soft Ice Cream, Spiked Slushie, Sorbet, Milkshake, and Extrude/Clean.
4. **Select Texture:** Use the 'TEXTURE' button to choose from 7 different texture levels, ranging from light and airy to dense and creamy.
5. **Start:** Press the 'START/STOP' button to begin the freezing process. The machine will automatically churn and freeze your mixture.
6. **Enjoy:** Your frozen treat will be ready in approximately 15-30 minutes, depending on the recipe and desired consistency.

3 ÉTAPES SIMPLES



AJOUTER



Mélangez les ingrédients et versez-les dans le bol mélangeur



SÉLECTIONNER



Choisissez le réglage et la texture souhaités



PROFITER



Prêt en 30 minutes

Image: A visual guide showing three simple steps: 1. Add ingredients by pouring into the mixing bowl. 2. Select the desired setting and texture. 3. Enjoy the finished product, ready in about 30 minutes.

2. Modes and Textures

The GreenPan Frost offers 6 versatile modes and 7 texture levels to cater to various frozen dessert preferences:

- **Slushie:** For refreshing crushed ice drinks.
- **Soft Ice Cream:** For creamy, soft-serve style ice cream.
- **Spiked Slushie:** For alcoholic slushie preparations.
- **Sorbet:** For fruit-based frozen desserts.
- **Milkshake:** For thick and smooth milkshakes.
- **Extrude/Clean:** This mode is used for dispensing the finished product and for the self-cleaning function.

The 7 texture levels allow fine-tuning from a very soft, airy consistency to a firm, dense texture.



SAVEUR ET TEXTURE PARFAITES

6 RÉGLAGES ET 7 TEXTURES : DE LA CRÈME GLACÉE MOLLE AU GRANITÉ

Image: The GreenPan Frost machine's control panel showing the available modes: Spiked Slushie, Soft Ice Cream, Sorbet, Milkshake, Granita, and Clean. This illustrates the perfect flavor and texture options.

3. Integrated Compressor

The silent and fast integrated compressor ensures that your ingredients are quickly transformed into frozen delights without the need for pre-freezing the bowl. This allows for spontaneous preparation of frozen treats whenever you desire.



COMPRESSEUR INTÉGRÉ SILENCIEUX

SYSTÈME DE REFROIDISSEMENT SILENCIEUX INTÉGRÉ MAINTIEN LES INGRÉDIENTS AU FROID

Image: A close-up of the GreenPan Frost machine, highlighting its silent integrated compressor, which maintains ingredients at a cold temperature.

4. Large Capacity

With a generous 1.8-liter mixing bowl, the GreenPan Frost can prepare enough frozen treats for the whole family or for entertaining guests.



POUR TOUTE LA FAMILLE

GRAND BOL MÉLANGEUR D'UNE CAPACITÉ DE 1,8 L

Image: A hand pouring liquid into the large 1.8 L mixing bowl of the GreenPan Frost machine, demonstrating its family-sized capacity.

MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygienic operation of your GreenPan Frost machine.

1. Self-Cleaning Mode

The machine features an easy self-cleaning program:

1. After dispensing your treat, select the 'Extrude/Clean' mode to remove any remaining mixture.
2. Add warm water with a small amount of dish soap into the mixing bowl.
3. Select the 'Clean' program and let the rotating paddles clean the interior.
4. Once complete, discard the water and rinse the bowl.

FACILE À NETTOYER

AJOUTER



Ajoutez de l'eau et du liquide vaisselle dans le bol mélangeur

SÉLECTIONNER



Sélectionnez le programme de nettoyage

PROFITER



Prêt en 15 minutes

Image: A visual guide demonstrating the easy cleaning process: 1. Add water and dish soap to the mixing bowl. 2. Select the 'Clean' program. 3. The machine cleans itself, ready in 15 minutes.

2. Manual Cleaning

- Unplug the machine before cleaning.
- All removable parts (mixing bowl, rod, swirling tips, seals) are dishwasher-safe for convenient cleaning.
- Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners or scourers.
- Ensure all parts are completely dry before reassembling or storing.

3. Storage

- Store the machine in a clean, dry place, away from direct sunlight and extreme temperatures.
- Ensure all components are properly assembled or stored together to prevent loss.

TROUBLESHOOTING

If you encounter any issues with your GreenPan Frost machine, refer to the table below for common problems and

solutions.

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; Power outlet issue; Machine not assembled correctly.	Ensure the power cord is securely plugged into a working outlet. Check if all components are correctly installed.
Dessert is not freezing or is too soft.	Ingredients not cold enough; Too much liquid; Incorrect mode/texture selected.	Ensure ingredients are chilled before adding. Adjust recipe for less liquid. Select a firmer texture setting or a longer processing time.
Machine is making unusual noise.	Components not properly seated; Overfilling the bowl.	Check that the mixing bowl and rod are correctly installed. Do not exceed the maximum fill line.
Difficulty dispensing finished product.	Product too firm; Dispensing mechanism blocked.	Allow the product to soften slightly. Ensure the dispensing mechanism is clear of obstructions. Use the 'Extrude' function.

SPECIFICATIONS

Feature	Detail
Brand	GreenPan
Model Name	Frost
Model Number	CC010400-001
Color	Grey
Capacity	1.8 Liters
Special Features	Digital display, Auto shut-off, Integrated compressor, Keep cool function, Integrated timer
Material	Metal, Silicone, Plastic
Product Dimensions (L x W x H)	43 x 28 x 48 cm
Item Weight	10.9 Kilograms
Operating Mode	Automatic
Recommended Uses	Italian ice, sorbets, granitas, slushies, frozen cocktails, milkshakes, smoothies, frozen yogurt



ÉLÉGANT ET COMPACT

SUPERBE SUR LE PLAN DE TRAVAIL ET FACILE À RANGER

Image: The GreenPan Frost machine with its dimensions (44.5 cm height, 22.2 cm width) highlighted, showcasing its elegant and compact design suitable for countertops.

WARRANTY AND SUPPORT

Warranty Information

GreenPan products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your product or visit the official GreenPan website. Keep your proof of purchase for any warranty claims.

Customer Support

If you have any questions, require assistance, or need to report a problem that is not covered in the troubleshooting section, please contact GreenPan customer support. Contact information can typically be found on the GreenPan website or in the documentation provided with your appliance.

