

[Manuals.plus](#) /

> [VIDCASTIVE](#) /

> VIDCASTIVE 4K Mini Body Camera L20 User Manual

VIDCASTIVE L20

VIDCASTIVE 4K Mini Body Camera L20 User Manual

Model: L20

1. INTRODUCTION

The VIDCASTIVE 4K Mini Body Camera L20 is a compact, wearable camera designed for capturing high-quality point-of-view (POV) video and photos. Its small size, magnetic and clip mounts, and 4K resolution make it suitable for various activities, including outdoor sports, daily vlogging, and personal recording. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your camera.



Image: The VIDCASTIVE 4K Mini Body Camera L20.

2. WHAT'S IN THE BOX

Verify that all items are present in your package:

- Camera

- USB-C Cable
- 12-Piece Accessory Kit (various mounts and clips)
- User Manual
- Memory Card (64GB V30-rated, pre-installed)



Image: All included accessories for the VIDCASTIVE 4K Mini Body Camera L20.

3. PRODUCT OVERVIEW

The VIDCASTIVE L20 features a compact design with a 1.47-inch display for real-time viewing and playback. It records in 4K/30fps and includes a 750mAh rechargeable battery for up to 150 minutes of continuous recording.

Camera Components

- **Lens:** Main camera lens for capturing video and photos.
- **1.47-inch Display:** For menu navigation, live view, and playback.
- **Power Button:** To turn the camera on/off and confirm selections.
- **Mode Button:** To switch between video, photo, and playback modes, and navigate menus.
- **USB-C Port:** For charging and data transfer.
- **Micro SD Card Slot:** For memory card insertion.
- **Microphone:** For audio recording.

4. SETUP

4.1 Charging the Camera

Before first use, fully charge the camera. Connect the provided USB-C cable to the camera's USB-C port and the other end to a USB power adapter (not included) or a computer's USB port. The camera supports recording while charging.

Instant WiFi Transfer

View your footage on your phone in seconds



Image: The camera connected to a power source via USB-C cable for charging.

4.2 Inserting the Memory Card

The camera comes with a pre-installed 64GB V30-rated high-speed Micro SD card. If you need to insert or replace the card, ensure the camera is powered off. Open the Micro SD card slot cover and gently insert the card with the gold contacts facing the front of the camera until it clicks into place. Close the cover securely.

5.2 Taking Photos

From the main menu, select 'Photo Shot'. Press the Power button to capture a photo. Photos are saved to the Micro SD card.

5.3 Playback

From the main menu, select 'Playback'. Use the Mode button to navigate through your recorded videos and photos. Press the Power button to view a selected file.

5.4 WiFi Connectivity and App Usage

The camera features built-in WiFi for connecting to your smartphone via a dedicated companion app. This allows for live preview, wireless video transfer, and direct sharing. Refer to the app's instructions for detailed pairing and usage.



Image: The camera displaying WiFi connection information, with a smartphone showing the companion app interface.

5.5 Mounting Options

The camera is designed for versatile mounting with its magnetic body and included accessory kit. Common mounting methods include:

- **Magnetic Mount:** Attach directly to metallic surfaces or use with the magnetic necklace mount for hands-free recording on clothing.
- **Clip Mount:** Securely attach to shirt pockets, backpack straps, or other fabric edges.
- **Helmet Mount:** Use the helmet adapter for POV recording during cycling or other activities.
- **Bike Mount:** Attach to bicycle handlebars for stable recording.

Mount It Anywhere

All mounts included
Ready to use right out of the box.



Image: The camera clipped onto a shirt for wearable recording.

1.59
0Z
(45g)



Small & Lightweight

Feels like nothing — you forget you're wearing it.

Image: The camera mounted on a bicycle helmet.

4K Hands-Free POVs

Capture smooth 4K POV without breaking your flow.



Image: The camera mounted on bicycle handlebars.

6. MAINTENANCE

6.1 Cleaning

Use a soft, dry cloth to clean the camera body. For the lens, use a specialized lens cleaning cloth and solution. Avoid using harsh chemicals or abrasive materials.

6.2 Storage

Store the camera in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery

is partially charged (around 50%) if storing for extended periods to prolong battery life.

6.3 Memory Card Management

Regularly back up your footage and format the Micro SD card in the camera's settings to maintain optimal performance and prevent data corruption. A V30-rated card is recommended for 4K recording.

7. TROUBLESHOOTING

If you encounter issues with your VIDCASTIVE L20 camera, refer to the following common solutions:

- **Camera not powering on:** Ensure the battery is charged. Connect the camera to a power source and try again.
- **"Please plug in SD card" message:** Verify that the Micro SD card is correctly inserted. Try re-inserting the card or using a different compatible V30-rated card. Ensure the card is not damaged.
- **Poor video/photo quality:** Ensure the lens is clean. Check the recording resolution settings. Ensure sufficient lighting.
- **Poor audio quality:** Ensure the microphone is not obstructed.
- **Camera freezing or unresponsive:** Press and hold the Power button for 10-15 seconds to force a restart. If the issue persists, perform a factory reset via the camera's settings menu (note: this will erase custom settings).
- **WiFi connection issues:** Ensure the camera's WiFi is enabled and your smartphone is within range. Restart both the camera and your phone. Reinstall the companion app if necessary.

If problems persist after attempting these steps, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	VIDCASTIVE
Model Number	L20
Video Capture Resolution	4K
Video Capture Format	MP4
Screen Size	1.47 Inches
Battery Average Life	2.5 Hours (150 minutes)
Flash Memory Installed Size	64 GB (V30-rated)
Connectivity Technology	USB, WiFi
Photo Sensor Technology	CMOS
Maximum Aperture	2.8 f
Water Resistance Level	Not Water Resistant
Image Stabilization	Anti-Shake (Digital)

Item Weight	0.37 Kilograms (approx. 1.59 oz / 45g)
-------------	--

9. WARRANTY & SUPPORT

9.1 Warranty Information

The VIDCASTIVE 4K Mini Body Camera L20 comes with a **1-Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your product, please contact VIDCASTIVE customer support through the retailer's platform or the official VIDCASTIVE website. Provide your model number (L20) and a detailed description of the issue for faster service.