

[Manuals.plus](#) /

› [MAHANCRI](#) /

› MAHANCRI Desk Shelf DSBK5501 Instruction Manual

MAHANCRI DSBK5501

MAHANCRI Desk Shelf DSBK5501 Instruction Manual

MODEL: DSBK5501

1. Introduction

The MAHANCRI Desk Shelf DSBK5501 is a versatile 3-tier corner desk organizer designed to maximize your workspace and provide efficient storage. This manual provides essential information for the proper assembly, operation, and maintenance of your desk shelf.



Image: The MAHANCRISS Desk Shelf DSBK5501 in a modern office setting, showcasing its three tiers holding headphones, speakers, and a decorative car model, with a monitor and LED clock on the desk.

2. Included Components

Please ensure all the following components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- 3 x Engineered Wood Shelf Panels
- 2 x Metal Vertical Support Frames
- 2 x Adjustable C-Clamps
- Assembly Hardware (screws, Allen wrench)








Image: Detailed image of the MAHANCRISS Desk Shelf DSBK5501, showcasing its three shelves holding a camera, a small plant, books, a clock, and a picture frame, with the C-clamps visible at the base.

3. Setup and Assembly Instructions

Follow these steps to assemble your MAHANCRISS Desk Shelf DSBK5501:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all components listed in Section 2 are present.
2. **Attach Shelf Panels to Support Frames:** Align the pre-drilled holes on the engineered wood shelf panels with the holes on the metal vertical support frames. Use the provided screws and Allen wrench to securely fasten each shelf to the frames. Ensure the shelves are oriented correctly to form the corner design.
3. **Attach C-Clamps:** Secure the adjustable C-clamps to the bottom of the vertical support frames. Ensure they are tightened firmly.
4. **Position and Secure to Desk:** Place the assembled desk shelf in your desired corner position on your desk. Adjust the C-clamps to fit your desktop thickness. The maximum desktop thickness for clamping is 1.6 inches (4 cm). Tighten the clamps securely to prevent wobbling.

Note: While the included Allen wrench is functional, using a screwdriver with a proper grip may ease assembly, especially for individuals with limited hand strength.



Image: Close-up image of the adjustable C-clamps used to secure the MAHANCRIIS Desk Shelf DSBK5501 to a desk. The diagram highlights the maximum desktop thickness for clamping, which is 1.6 inches.

4. Operating Instructions (Usage)

The MAHANCRIIS Desk Shelf DSBK5501 is designed for organizing various items on your desk. Utilize its three tiers to store office supplies, small electronics, decorative items, or books.

- **Weight Capacity:** Each shelf is designed to hold a maximum weight of 15 lbs (6.8 kg). Do not exceed this limit to ensure stability and prevent damage.
- **Placement:** Distribute weight evenly across the shelves. Avoid placing excessively heavy items on the top shelf to maintain balance.
- **Space Optimization:** The corner design allows for efficient use of often-underutilized desk space, providing vertical storage without encroaching on your primary work area.




Image: Diagram illustrating the dimensions of the MAHANCRISS Desk Shelf DSBK5501, including height (67cm/26.4"), shelf width (41cm/16.1"), shelf depth (30cm/11.8"), and individual shelf height (18cm/7.1"). It also indicates a maximum weight capacity of 15 lbs per shelf.

5. Maintenance

To keep your MAHANCRISS Desk Shelf DSBK5501 in optimal condition:

- **Cleaning:** The sturdy panels have a smooth surface that can be easily wiped clean. Use a soft, damp cloth with mild soap and water. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Inspection:** Periodically check all screws and clamps to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Moisture:** While the surface is resistant to minor spills, avoid prolonged exposure to excessive moisture.

Sturdy Panels

Smooth surface wipes clean easily.



Image: Close-up image demonstrating the easy cleaning of the MAHANCRIS Desk Shelf DSBK5501's sturdy panels. A hand is wiping the smooth, water-resistant surface with a cloth, showing water droplets.

6. Troubleshooting

- **Shelf Wobbles After Assembly:**

Ensure all screws connecting the shelves to the support frames are fully tightened. Verify that the C-clamps are securely fastened to the desk and that the desk surface is stable and even.

- **Difficulty Tightening C-Clamps:**

Confirm your desktop thickness does not exceed 1.6 inches (4 cm). If it does, the clamps may not fit properly. Ensure the clamp pads are making full contact with the desk surface.

- **Misaligned Clamps:**

In some cases, the clamps may not sit at a perfect 90-degree angle relative to the desk. This typically does not affect functionality or stability as long as they are securely tightened. Adjust the shelf position slightly if needed to achieve optimal alignment.

7. Specifications

Model Number	DSBK5501
Brand	MAHANCRIS
Material	Engineered Wood, Metal
Mounting Type	Tabletop Mount (C-Clamps)
Number of Shelves	3
Shelf Type	Engineered Wood
Product Dimensions (L x W x H)	30D x 30W x 71.1H centimetres (11.8"L x 11.8"W x 28.0"H)
Item Weight	2.72 kg
Color	Black
Finish Type	Particleboard
Special Feature	Easy to Install
Room Type	Office

8. Warranty and Support

Specific warranty information for the MAHANCRIS Desk Shelf DSBK5501 is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please refer to the product listing on the retailer's website or contact MAHANCRIS customer service directly through their official channels.

© 2026 MAHANCRIS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question