

IRONCK QR-1001

IRONCK Dog Crate Furniture Instruction Manual

Model: QR-1001

- Introduction
- Safety Information
- Parts List
- Assembly
- Instructions
- Operation
- Maintenance
- Troubleshooting
- Specifications
- Warranty & Support

1. INTRODUCTION

Thank you for purchasing the IRONCK Dog Crate Furniture. This manual provides important information for the safe assembly, operation, and maintenance of your new dog crate. Please read it thoroughly before use and retain it for future reference.

2. SAFETY INFORMATION

- Ensure all parts are securely fastened before allowing your pet to use the crate.
- Do not allow children to climb on or play inside the crate.
- Regularly inspect the crate for any loose parts, damage, or wear. Replace or repair as necessary.
- This product is designed for indoor use only.
- Ensure the crate is placed on a flat, stable surface to prevent tipping.
- Do not use harsh chemicals for cleaning; refer to the maintenance section.
- This crate is suitable for small to medium-sized dogs. Ensure your dog's size is appropriate for the crate dimensions to prevent injury or discomfort.

3. PARTS LIST

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Wooden Panels (Top, Bottom, Sides, Back)
- Metal Bar Panels (for door and side vents)
- Drawer Components (Front, Back, Sides, Bottom)
- Flip-Top Lid
- Door with Latch Mechanism

- Hardware Pack (Screws, Dowels, Hinges, Drawer Slides, Handle)
- Assembly Tools (e.g., Hex Key, Screwdriver - usually included)

Dog Kennel Furniture for Small Dogs Up to 30 LBS

Ideal for breeds such as Shih Tzus, Maltese, Pomeranians



Image: Exploded view showing various components and overall dimensions of the dog crate furniture.

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have two people for certain steps to ensure stability and ease of construction.

1. **Prepare the Area:** Clear a spacious, flat area for assembly. Lay out all parts and hardware, matching them to the parts list.
2. **Assemble the Base:** Attach the side panels to the bottom panel using the provided screws and dowels. Ensure the metal bar panels are correctly oriented for the crate opening.
3. **Install Back Panel:** Secure the back panel to the assembled base and side panels.

4. **Construct the Drawer:** Assemble the drawer box using the drawer front, back, and side pieces. Attach the drawer bottom. Install the drawer slides onto the drawer and the corresponding side panels of the main unit.
5. **Attach the Top Panel:** Place the top panel onto the assembled structure, ensuring it aligns with the pre-drilled holes. Secure it with screws.
6. **Install the Flip-Top Mechanism:** Attach the hinges for the flip-top storage compartment to the top panel and the flip-top lid.
7. **Mount the Crate Door:** Attach the door hinges to the main unit and the crate door. Install the latch mechanism on the door and the corresponding side panel. Test the latch for smooth operation.
8. **Final Checks:** Tighten all screws and ensure the crate is stable.

Drawer and Flip-Top Storage

Making full use of storage space while achieving partitioned storage



Image: The assembled IRONCK Dog Crate Furniture, showcasing the pull-out drawer and the open flip-top storage compartment.

Heavy Duty Cage Kennel

Chew-resistant & sturdy metal frame dog cage



Image: Close-up of the heavy-duty metal frame integrated into the wooden dog crate, highlighting its chew-resistant construction.

5. OPERATION

5.1 Using the Dog Crate

The main compartment serves as a comfortable and secure space for your dog. To open the door, slide the top and bottom latches and gently pull the door outwards. To close, push the door shut and engage both latches securely. Ensure your pet has adequate bedding and water inside.



Image: A dog resting inside the crate with the door open, demonstrating the spacious interior.

5.2 Utilizing the Drawer Storage

The pull-out drawer is located beneath the flip-top compartment. Gently pull the handle to open the drawer. This space is ideal for storing smaller pet accessories, treats, or personal items. Push the drawer back in until it is fully closed.

5.3 Accessing the Flip-Top Storage

The flip-top compartment is located on the top surface of the unit. Lift the designated section of the top panel to reveal a hidden storage area. This compartment is suitable for storing larger items like toys or grooming tools, keeping them out of sight and protected.

Your browser does not support the video tag.

Video: Demonstration of the IRONCK Wooden Dog Crate's drawer and flip-top storage features.

6. MAINTENANCE

- **Cleaning:** Wipe down wooden surfaces with a soft, damp cloth. For stubborn stains, use a mild wood cleaner. Avoid abrasive cleaners or excessive moisture.
- **Metal Bars:** Clean metal bars with a damp cloth and mild soap if necessary. Dry thoroughly to prevent rust.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten if loose.
- **Pet Bedding:** Regularly clean or replace pet bedding inside the crate to maintain hygiene.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Door latches are stiff or difficult to operate.	Tight tolerances during manufacturing or minor misalignment during assembly.	Apply a small amount of lubricant (e.g., silicone spray) to the latch mechanism. Ensure the door is properly aligned when closing. If necessary, slightly adjust the latch screws.
Crate feels wobbly or unstable.	Screws are not fully tightened or uneven placement.	Check and tighten all assembly screws. Ensure the crate is placed on a level surface.
Drawer does not slide smoothly.	Drawer slides are misaligned or obstructed.	Verify that the drawer slides are correctly installed and free from debris. Ensure the drawer is not overloaded.

8. SPECIFICATIONS

Model Number: QR-1001

Brand: IRONCK

Product Dimensions (L x W x H): 21.7" x 25.6" x 25.2"

Item Weight: 87 Pounds

Material: Engineered Wood, Metal

Color: Walnut

Special Features: Drawer, Durable, Flip-Top Storage

Target Species: Dog (Small to Medium breeds)

UPC: 743636923878



Image: The IRONCK Dog Crate Furniture, showcasing its walnut finish and overall design.

9. WARRANTY AND SUPPORT

This IRONCK Dog Crate Furniture comes with a **2-Year Warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical assistance, missing parts, or warranty inquiries, please contact IRONCK customer support through the retailer's platform or the official IRONCK website. Our team is available to assist you with any questions or concerns.

Contact Information: Refer to your purchase platform or the official IRONCK website for the most up-to-date customer service contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GDXXBMH7N>

More documents and user manuals: <https://manuals.plus/>