

Huuger B0GDY2VPKQ

Huuger 78.7-Inch Adjustable Sofa Table with Power Outlets

Model: B0GDY2VPKQ - Instruction Manual

SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use of this product. Failure to follow these instructions may result in injury or damage to the product.

- Always follow assembly instructions carefully.
- Use the provided anti-tip hardware to secure the table to a wall for enhanced stability, especially in households with children or pets.
- Adjust the pads for baseboards to ensure the table sits flush against the wall and prevents tipping.
- Do not exceed the maximum weight limits for the table surface. Refer to the Specifications section for details.
- Keep the table away from direct heat sources, open flames, and excessive moisture.
- Avoid placing hot items directly on the table surface without protective coasters.
- Ensure all electrical connections are secure and follow local electrical safety guidelines when using the integrated power outlets. Do not overload the outlets.

PRODUCT OVERVIEW

The Huuger 78.7-inch adjustable sofa table is designed to provide convenient surface space and charging capabilities behind your couch or along a wall. Its narrow design and adjustable height allow for versatile placement in various living spaces.

Key Features

- **Integrated Power Outlets:** Features 2 AC outlets, 1 USB-C port, and 1 USB port for convenient device charging.
- **Adjustable Height:** Height can be adjusted from 23.9 inches to 34.4 inches to match various sofa heights.
- **Slim Design:** Narrow profile fits well in tight spaces behind furniture.
- **Connectable Design:** Includes metal connectors to securely join multiple tables for extended length.

- **Durable Construction:** Built with P2 particleboard and a sturdy metal frame.
- **Adjustable Anti-Collision Pads:** Prevents tilting against baseboards and protects walls.



Image: Overview of the Huuger adjustable sofa table in a living room setting.

SETUP AND ASSEMBLY

This section provides general guidelines for assembling your Huuger sofa table. Refer to the included assembly instructions for detailed, step-by-step procedures and diagrams.

1. **Unpack Components:** Carefully unpack all parts and hardware. Verify that all components listed in the assembly guide are present and undamaged.
2. **Assemble Frame:** Attach the metal frame components according to the instructions. Ensure all screws are tightened securely but do not overtighten.
3. **Attach Tabletop:** Secure the P2 particleboard tabletop to the assembled metal frame.
4. **Install Adjustable Feet:** Screw the adjustable feet into the bottom of the table legs. These feet help stabilize the table on uneven floors.



Image: Detail of the sturdy metal frame construction.

Anti-Tipping Kit Installation

To prevent accidental tipping, it is crucial to install the anti-tipping kit.

1. Locate the anti-tipping strap and hardware.
2. Attach one end of the strap to the table frame using the provided screws.
3. Position the table against the wall in its desired location.
4. Mark the wall where the other end of the strap will be secured.
5. Drill a pilot hole (if necessary) and secure the strap to the wall using the appropriate anchor and screw.



Image: Anti-tipping kit installation guide.

Adjustable Feet

The table is equipped with adjustable feet to ensure stability on uneven floor surfaces. Rotate the feet clockwise or counter-clockwise to raise or lower individual corners until the table is level and stable.




Image: Adjustable feet for leveling the table.

OPERATING INSTRUCTIONS

Height Adjustment

The table's height can be adjusted to match various sofa heights, ranging from 23.9 inches to 34.4 inches. There

are 8 marked height levels, with approximately 1.5 inches between each setting.

1. Loosen the locking mechanisms on the adjustable legs.
2. Carefully raise or lower the tabletop to your desired height. Ensure both sides are adjusted evenly.
3. Once the desired height is reached, securely tighten the locking mechanisms on both legs to prevent movement.



Image: Height adjustment mechanism and range.

Using the Power Outlets

The table includes a built-in power strip with 2 standard AC outlets, 1 USB-C port (5V/2A), and 1 USB port (5V/2A) for convenient charging of electronic devices.

1. Plug the table's power cord into a standard wall outlet.
2. Connect your devices to the available AC, USB-C, or USB ports.
3. Ensure devices are compatible with the provided voltage and current specifications.



Image: Built-in power outlets with charging devices.

The power outlets can be positioned flexibly along the table's length to suit your needs.

Flexible Power Outlets



Image: Flexible power outlet positions.

Connecting Multiple Tables

For longer sofas or extended surface needs, two Huuger sofa tables can be securely joined using the provided metal connectors.

1. Align two tables side-by-side.
2. Use the included sheet metal connectors to bridge the gap between the two tabletops.
3. Secure the connectors with screws as indicated in the assembly instructions to create a seamless, extended surface.



Image: Method for connecting two tables.

Adjustable Anti-Collision Pads

The table features adjustable anti-collision pads to prevent tilting against baseboards and protect your walls from scratches or marks.

1. Position the table against the wall.
2. Adjust the pads by rotating them until they make firm contact with the wall or baseboard, ensuring the table is stable and upright.



Image: Adjustable anti-collision pads in action.

MAINTENANCE

Proper maintenance will ensure the longevity and appearance of your sofa table.

- **Cleaning:** Wipe the table surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or water damage to the engineered wood surface. The surface is waterproof, but prolonged exposure to liquids should be avoided.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain stability.
- **Electrical Components:** Keep the power outlets clean and free of dust. Do not attempt to disassemble or repair the electrical components yourself.

TROUBLESHOOTING

This section addresses common issues you might encounter with your sofa table.

- **Table is Unstable/Wobbly:**
 - Ensure all assembly screws are fully tightened.
 - Adjust the leveling feet on the bottom of the legs to compensate for uneven floors.
 - Verify that the anti-tipping kit is correctly installed and secured to the wall.
- **Power Outlets Not Working:**
 - Check if the table's main power cord is securely plugged into a functional wall outlet.
 - Ensure the devices you are trying to charge are properly connected and functional.
 - Avoid overloading the outlets. If an outlet trips, unplug devices and try again.
- **Height Adjustment is Difficult:**
 - Ensure the locking mechanisms on both legs are fully loosened before attempting to adjust the height.
 - Adjust both sides evenly to prevent jamming.
- **Table Does Not Sit Flush Against Wall:**
 - Adjust the anti-collision pads by rotating them to accommodate baseboards or wall irregularities.

SPECIFICATIONS

Feature	Detail
Brand	Huuger
Model Number	B0GDY2VPKQ
Product Dimensions (D x W x H)	5.9"D x 78.7"W x 23.9"-34.4"H
Adjustable Height Range	23.9" - 34.4"
Frame Material	Metal
Top Material Type	Engineered Wood (P2 Particleboard)
Color	Grey
Power Outlets	2 AC Outlets (125V/12A)
USB Ports	1 USB-C Port (5V/2A), 1 USB Port (5V/2A)
Special Features	Waterproof surface, Adjustable Anti-Collision Pads, Anti-Tip Design
Assembly Required	Yes
Included Components	Assembly Tools, Assembly Instructions

WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact Huuger customer service directly. Refer to the packaging or the official Huuger website for contact details.

Please retain your purchase receipt for warranty claims.