

MOFII MOFII Wireless Keyboard and Mouse Combo

MOFII Wireless Keyboard and Mouse Combo User Manual

Model: MOFII Wireless Keyboard and Mouse Combo

INTRODUCTION

This manual provides detailed instructions for the MOFII 2.4 GHz Full-Size Retro Round Wireless Keyboard and Mouse Combo. This product offers a reliable wireless connection, ergonomic design, and convenient multimedia hotkeys for enhanced productivity and comfort across various operating systems and devices.

PACKAGE CONTENTS

Before you begin, please ensure all items are present in your package:

- Wireless Keyboard
- Wireless Mouse
- USB Receiver (typically stored in the mouse battery compartment)
- User Manual

SETUP INSTRUCTIONS

Follow these steps to set up your MOFII Wireless Keyboard and Mouse Combo:

1. **Install Batteries:** Open the battery compartments on both the keyboard and mouse. Insert the required batteries (not included), ensuring correct polarity.
2. **Locate USB Receiver:** The compact USB receiver is typically stored in the battery compartment of the mouse for safekeeping during transport.
3. **Connect Receiver:** Plug the USB receiver into an available USB port on your computer.
4. **Power On:** Locate the power switch on the bottom of both the keyboard and the mouse and slide them to the 'ON' position.
5. **Automatic Connection:** The keyboard and mouse should automatically connect to your computer. No additional drivers are usually required for this plug-and-play device.



The USB receiver enables a 2.4GHz wireless connection for both the keyboard and mouse.

OPERATING INSTRUCTIONS

General Use

Once connected, you can begin using your keyboard and mouse. The full-size keyboard layout with round retro-styled keys provides a comfortable typing experience. The mouse is ergonomically designed for a hand-friendly contoured shape, offering smooth and precise tracking.

Multimedia Hotkeys

The keyboard features 13 multimedia hotkeys for quick access to various functions. These keys are typically activated by pressing the 'Fn' key in combination with the corresponding function key (F1-F12) or dedicated multimedia keys.



ERGONOMIC TYPING

Keep optimal tilt to offer a more neutral wrist position for greater typing

The keyboard includes convenient media keys for quick access to common functions.

Common Multimedia Hotkey Functions

Key Combination	Function
Fn + F1	Media Player
Fn + F2	Volume Down
Fn + F3	Volume Up
Fn + F4	Mute
Fn + F5	Previous Track
Fn + F6	Next Track
Fn + F7	Play/Pause
Fn + F8	Stop
Fn + F9	Internet Browser
Fn + F10	Email

Key Combination	Function
Fn + F11	My Computer
Fn + F12	Calculator

Ergonomic Design

The keyboard is designed with foldable stands on the underside, allowing you to adjust the typing angle for a more neutral wrist position and improved comfort during extended use. The mouse's contoured shape fits comfortably in the hand.



REMOVABLE KEYCAP

Easily remove and install design for dust cleaning

Foldable stands allow for an optimal tilt, promoting ergonomic typing.


POWER SAVING FEATURES


To extend battery life, both the wireless keyboard and mouse are equipped with power-saving features:

- **Power Switch:** Each device has a dedicated power switch for manual on/off control, preventing unnecessary battery drain when not in use.
- **Automatic Sleep Mode:** After approximately 8 minutes of inactivity, both the keyboard and mouse will automatically enter sleep mode to conserve energy. To wake them up, simply press any key on the keyboard or move/click the mouse.



 2.4G Wireless

 Ergonomics Design

 Auto-Power Saving


RELIABLE WIRELESS COMBO

The combo automatically enters sleep mode after 8 minutes of inactivity to save power.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your MOFII combo:

- **Cleaning:** Use a soft, dry cloth to wipe down the surfaces of the keyboard and mouse. For more stubborn dirt, a slightly damp cloth can be used, but ensure no liquid enters the internal components.
- **Keycap Removal:** The round keycaps are designed for easy removal, facilitating thorough cleaning underneath. Gently pull upwards on a keycap to detach it, and press firmly to reattach.
- **Battery Replacement:** When you notice a decrease in performance or responsiveness, replace the batteries in both the keyboard and mouse with new ones of the specified type.



ENJOY YOUR WORKING

Wireless Connection, plug and play.
Keep your desk clean and tidy.

Keycaps can be easily removed for cleaning and maintenance.

TROUBLESHOOTING

If you encounter issues with your MOFII Wireless Keyboard and Mouse Combo, refer to the following common solutions:

- **No Connection / Devices Not Responding:**
 - Ensure the USB receiver is securely plugged into a functional USB port on your computer.
 - Verify that both the keyboard and mouse power switches are in the 'ON' position.
 - Replace the batteries in both devices with fresh ones.
 - Try plugging the USB receiver into a different USB port.
- **Lagging or Intermittent Connection:**
 - Move the keyboard and mouse closer to the USB receiver. The optimal range is up to 33 feet (10 meters).
 - Avoid placing the USB receiver near large metal objects, other wireless devices (like Wi-Fi routers), or strong electromagnetic interference sources.
- **Mouse Cursor Not Moving:**
 - Check the mouse's power and battery status.
 - Ensure the optical sensor on the bottom of the mouse is clean and unobstructed.
 - Use the mouse on a suitable surface; highly reflective or transparent surfaces may affect tracking.
- **Specific Keys Not Responding:**
 - Check the keyboard's power and battery status.
 - Gently remove the affected keycap and check for any debris or obstruction underneath. Clean if necessary.

SPECIFICATIONS

Feature	Description
Brand	MOFII
Connectivity Technology	2.4 GHz Wireless (USB Receiver)
Keyboard Type	Full-Size, Retro Round Keycaps, Multimedia
Mouse Type	Ergonomic, Wireless
Special Features	Ergonomic Design, Portable, Round Keycaps, Wireless, Multimedia Hotkeys, Auto Power Saving
Compatible Devices	Laptop, Personal Computer, Projector, Television (Mac, Windows)
Power Source	Battery Powered (Batteries not included)
Wireless Range	Up to 33 ft (10 meters)

WIRELESS FREEDOM

Comfortable rubber grip and responsive clicks



The mouse features a compact and portable size, designed for comfortable use.

WARRANTY AND SUPPORT

Warranty Information

This MOFII Wireless Keyboard and Mouse Combo is covered by a **1-year manufacturer's warranty** from the original date of purchase. This warranty covers defects in materials and workmanship under normal use. The warranty does not cover damage caused by accident, misuse, abuse, unauthorized modification, or external causes such as liquid damage or power surges.

Customer Support

For technical assistance, troubleshooting, or to inquire about warranty claims, please contact MOFII customer support. You can typically find contact information on the official MOFII website or through the retailer where you purchased the product.

Please have your product model number and proof of purchase ready when contacting support.