

Veehoo CWC2530CP18

Veehoo Extra Large Outdoor Dog House with Elevated Bed

Instruction Manual - Model CWC2530CP18

1. INTRODUCTION

Thank you for choosing the Veehoo Extra Large Outdoor Dog House with Elevated Bed. This product is designed to provide a comfortable and secure shelter for your pets, offering protection from various weather conditions. It features an elevated bed to keep your pet off the ground, and a durable, weatherproof design suitable for outdoor use.

This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal use and longevity of your dog house.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembling and using the product. Failure to follow these instructions may result in injury or damage to the product.

- Always supervise pets, especially during initial use, to ensure they adapt safely to the shelter.
- Ensure all components are securely assembled before allowing pets to use the dog house.
- Regularly inspect the dog house for any signs of wear, damage, or loose parts. Replace or repair as necessary.
- Place the dog house on a flat, stable surface to prevent tipping.
- Use the provided ground stakes to secure the shelter, especially in windy conditions.
- Keep children away from the assembly area and do not allow them to play with the product.

3. PACKAGE CONTENTS

Verify that all parts are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Iron Tubes (for frame)
- Polyester Fabric Cover (tent material)
- Elevated Dog Bed (frame and mesh fabric)
- Webbing Straps
- Rubber Bed Feet
- Spring Buckles
- Ground Stakes
- Instruction Manual


4. ASSEMBLY INSTRUCTIONS

Assembly of the Veehoo Dog House is designed to be tool-free and can typically be completed in under 10 minutes. Follow these steps carefully:


1. **Assemble the Base Frame:** Connect the horizontal iron tubes to form the rectangular base of the dog house. Ensure the snap-on locks engage securely.
2. **Attach Upright Supports:** Insert the vertical iron tubes into the base frame. These will form the side walls of the structure.
3. **Install Roof Frame:** Connect the roof-forming iron tubes to the top of the upright supports. The frame should now resemble the basic shape of the dog house.
4. **Drape Fabric Cover:** Carefully place the polyester fabric cover over the assembled frame. Ensure it is centered and aligned correctly.
5. **Secure Fabric:** Fasten the fabric cover to the frame using the integrated webbing straps and spring buckles. Ensure all buckles are tightened to keep the cover taut and secure.
6. **Assemble Elevated Dog Bed:** Assemble the elevated bed frame by connecting its tubes and attaching the mesh fabric. Place the rubber bed feet on the bottom of the bed legs.
7. **Position Bed:** Place the assembled elevated dog bed inside the dog house.
8. **Ground Stakes:** For added stability, especially in outdoor environments, use the provided ground stakes to anchor the dog house to the ground. Insert them through the designated loops at the base of the dog house.

Easy Assembly without tool


1




2



3



4



Dog Bed




Figure 4.1: Easy Assembly Steps for the Dog House Frame.

Stay Cool with Sun



UV Protection



3-Sided Mesh
Enhanced Airflow




Figure 4.2: Details of the Easy Snap-on Lock, Windproof Buckle, and Ground Stakes for secure assembly.

Your browser does not support the video tag.

Video 4.1: Official Veehoo assembly and product overview. This video demonstrates the ease of setting up the dog house and highlights its features.

5. OPERATING INSTRUCTIONS

The Veehoo Dog House is designed for all-weather comfort and ease of use.

5.1 All-Weather Comfort Adjustment

The dog house features three mesh windows with roll-up flaps to adapt to different weather conditions:

- **For Warm Weather (Summer Cooling):** Roll up the flaps on the mesh windows to allow for optimal airflow and ventilation, keeping your pet cool. The mesh also provides UV protection.
- **For Cold Weather (Winter Cozy):** Roll down the flaps to cover the mesh windows. This helps to retain heat, block drafts, and provide a warmer, more enclosed space for your pet.

Comes with a Raised Dog Bed Comfort Enhanced

Elevate your pup above dirt, damp, cold or heat



Figure 5.1: Dog house with mesh windows open for enhanced airflow and UV protection.



Figure 5.2: Comparison of summer cooling (mesh windows open) and winter cozy (flaps down) configurations.

5.2 Wind and Rain Protection

The dog house is crafted from water-resistant polyester fabric. In rainy or windy conditions, ensure all flaps are rolled down and securely fastened to seal out rain and wind. The ground stakes and windproof buckles provide additional security against strong gusts.



Figure 5.3: The weatherproof Oxford fabric protecting a dog from rain.

6. MAINTENANCE AND CARE

Proper maintenance will extend the life of your Veehoo Dog House.

- **Cleaning the Fabric Cover:** The polyester fabric can be easily cleaned with a damp cloth. For more

thorough cleaning, rinse with water and allow it to air dry completely before reassembling or storing.

- **Cleaning the Elevated Bed:** The mesh fabric of the elevated bed can be wiped clean with a damp cloth or rinsed with water. Remove pet hair regularly to maintain hygiene.
- **Frame Inspection:** Periodically check the iron tubes and connections for any signs of rust, damage, or looseness. Tighten any loose connections.
- **Storage:** When not in use for extended periods, disassemble the dog house and store it in a dry, cool place away from direct sunlight to prevent material degradation.

Easy to Clean



Figure 6.1: Cleaning instructions for the dog house cover and elevated bed.

7. TROUBLESHOOTING

If you encounter any issues with your Veehoo Dog House, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Dog house feels unstable or wobbly.	Not all frame connections are fully engaged; ground stakes not used or improperly installed.	Ensure all snap-on locks are securely fastened. Install ground stakes firmly into the ground. Place on a level surface.
Water leakage during rain.	Flaps not fully rolled down and secured; fabric cover not properly aligned.	Ensure all mesh window flaps are completely rolled down and fastened. Verify the fabric cover is correctly draped and secured to the frame.
Pet is reluctant to use the dog house.	New environment; unfamiliar smell.	Introduce your pet gradually. Place familiar bedding or toys inside. Reward your pet for entering the shelter.
Difficulty assembling frame tubes.	Misalignment or obstruction.	Ensure tubes are aligned correctly before pushing. Apply gentle pressure. Do not force connections.

8. SPECIFICATIONS

Feature	Detail
Model Number	CWC2530CP18
Product Dimensions (Overall)	49"D x 31.5"W x 30"H (124.5 cm D x 80 cm W x 76.2 cm H)
Dog Bed Dimensions	49"L x 33"W x 9"H (124.5 cm L x 83.8 cm W x 22.9 cm H)
Materials	Alloy Steel (frame), Plastic (connectors), Polyester (fabric cover, bed mesh)
Item Weight	8.3 Kilograms (18.3 Pounds)
Color	Gray
Assembly Required	Yes (Tool-free)



Figure 8.1: Overall dimensions of the Veehoo Extra Large Dog House.

9. WARRANTY INFORMATION

Veehoo products are manufactured to high-quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please refer to the product packaging or contact customer support for specific warranty terms and conditions.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact Veehoo customer support through the retailer's platform or visit the official Veehoo website for contact information.

Online Resources: For additional tips and product information, please visit the [Veehoo Store on Amazon](#).



© 2026 Veehoo. All rights reserved.