

AAOBOSI AAOBOSI

AAOBOSI 36-Inch Electric Range Oven User Manual

Model: AAOBOSI

[Installation](#) [Operation](#) [Introduction](#) [Safety Information](#) [Setup & Specifications](#) [Support](#) [Maintenance](#) [Troubleshooting](#)

1. INTRODUCTION

Thank you for choosing the AAOBOSI 36-inch Electric Range Oven. This manual provides essential information for the safe and efficient use of your new appliance. Please read all instructions carefully before installation and operation, and retain this manual for future reference.

2. SAFETY INFORMATION

Always follow basic safety precautions when using this appliance to reduce the risk of fire, electric shock, burns, or injury.

- **Electrical Safety:** This appliance requires a 240V electrical supply. Installation must be performed by a qualified electrician in accordance with all local codes and ordinances. A power cord is not included and must be purchased separately and installed correctly.
- **Hot Surfaces:** The cooktop and oven surfaces become hot during use. Use caution and wear appropriate protective gear, such as oven mitts. Allow surfaces to cool before cleaning or touching.
- **Child Safety:** Do not allow children to operate or play near the appliance. The oven door features triple insulated glass and an anti-scald handle, but supervision is always required.
- **Overheat Protection:** The ceramic cooktop is equipped with overheat indicator lights for enhanced safety.
- **Proper Ventilation:** Ensure adequate ventilation in the kitchen area during operation.
- **Stability:** Ensure the range is properly leveled and secured to prevent tipping.

3. SETUP & INSTALLATION

3.1 Unpacking

Carefully remove all packaging materials from the range and its accessories. Inspect the appliance for any shipping damage. The package includes:

- 2x Cast iron grill racks
- 1x Grill net rack
- 1x Grill pan
- 1x Grease drip tray
- 2x User Manuals

3.2 Placement and Dimensions

The AAOBOSI electric range oven can be installed freestanding or built-in. Ensure the installation area meets the required dimensions and electrical specifications.



Figure 3.2.1: Dimensions of the AAOBOSI 36-inch electric range oven. The range measures approximately 35.88 inches (91.1cm) wide, 27 inches (68.5cm) deep, and 36.19 inches (91.9cm) high.

3.3 Electrical Connection

This appliance operates on 240V. A power cord is not supplied and must be installed by a qualified professional. Refer to local electrical codes for proper wiring and grounding procedures.

4. OPERATION

4.1 Cooktop Operation

The ceramic cooktop features five heating elements with varying power outputs for diverse cooking needs. Control each element using the corresponding knob on the front panel.



Figure 4.1.1: Ceramic cooktop layout with five heating elements. Power outputs include one 3000W (240mm), one 2100W (190mm), one 1800W (190mm), and two 1200W (160mm) zones.

The cooktop elements provide efficient and uniform heat distribution, suitable for stir-frying, deep-frying, roasting, boiling, and stewing. Overheat indicator lights will illuminate when a surface is hot.

Uniquely Designed Electric Ceramic Cooktop



Non-slip Knob, Senior-Friendly



Tempered Double Glass,
Scratch-Resistant & Durable



Wipes clean instantly
No Streaks, No Residue

Figure 4.1.2: Front view of the electric range oven, highlighting the non-slip control knobs for the cooktop and oven functions.

4.2 Oven Operation

The oven has a large 6 cubic feet (170 liter) capacity and offers multiple cooking functions controlled via the smart touch display and knobs.

Large-Capacity Kitchen Electric Stove and Oven

Ideal for Baking and Cooking Large Quantities of Food at the Same Time



Figure 4.2.1: The oven interior, illustrating its spacious 6 cubic feet (170 liter) capacity.

4.2.1 Oven Functions

The oven includes the following functions:

- **Baking:** For general baking of cakes, cookies, and casseroles.
- **Air Frying:** Utilizes convection for crispier results.
- **Convection Grilling:** Combines grilling with convection for even browning.
- **Keep Warming:** Maintains food at a serving temperature.
- **Delayed Start:** Allows you to set a future time for cooking to begin.
- **Timed Cooking:** Sets a specific duration for cooking.
- **Timer On/Off:** Controls the oven's operation based on a set timer.

AAOBOSI Convection Gas Range Ovens

Multiple cooking functions, create rich and delicious feast



Figure 4.2.2: Examples of dishes prepared using the oven's various cooking functions, such as baking, grilling, and keeping warm.

4.2.2 Convection System

The oven features internal convection fans, temperature probes, and explosion-proof lights to ensure even baking and cooking with 360° surround heat distribution.

Air Frying 3D Convection Circulation Range

Bakes and Baking Food More Evenly and Deliciously



Figure 4.2.3: Illustration of the 3D convection circulation system within the oven, designed for even cooking and air frying.

AAOBOSI High-Quality **Range Ovens**, Durable & Long Service Life



Figure 4.2.4: A detailed view of the oven's HD display panel, the internal convection fan, and the seven available shelf positions for flexible cooking.

The oven door is constructed with triple insulated glass and an anti-scald stainless steel handle, allowing you to monitor food without significant heat loss.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your AAOBOSI electric range oven.

AAOBOSI Easy to Dismantle and Clean Electric Oven



Figure 5.1.1: Features designed for easy maintenance, including the removable oven door, ceramic-coated interior, and a storage drawer.

- **Exterior Cleaning:** The stainless steel exterior is heat and corrosion resistant. Wipe with a soft cloth and mild detergent. Avoid abrasive cleaners.
- **Ceramic Cooktop:** The durable ceramic glass cooktop can be wiped clean with a damp cloth after it has cooled. For stubborn stains, use a ceramic cooktop cleaner.
- **Oven Interior:** The oven interior is coated with high-temperature resistant enamel. For cleaning, allow the oven to cool, then wipe with a damp cloth and mild soap. For baked-on residue, a non-abrasive oven cleaner suitable for enamel surfaces can be used.
- **Removable Oven Door:** The oven door can be removed for thorough cleaning or maintenance. Refer to the detailed instructions in the full manual for removal and reinstallation.
- **Storage Drawer:** The drawer at the bottom of the oven provides storage for cutlery or baking trays and can be easily cleaned.
- **Cooling System:** The high-speed cooling system located at the back of the oven protects the product and extends its service life. Ensure it is not obstructed.

6. TROUBLESHOOTING

If you encounter issues with your appliance, refer to the following common solutions. For problems not listed here, contact customer support.

Problem	Possible Cause	Solution
Appliance does not turn on	No power supply; circuit breaker tripped.	Check electrical connection and circuit breaker. Ensure the appliance is properly plugged in (if applicable) or wired.
Cooktop element not heating	Incorrect knob setting; element failure.	Ensure the knob is turned to the desired heat setting. If problem persists, contact support.
Oven not heating	Incorrect function selected; oven locked.	Verify the correct oven function and temperature are set. If the oven is locked, hold the 'Start' button for 3 seconds to unlock.
Uneven cooking in oven	Improper rack position; overloaded oven.	Adjust rack position for optimal air circulation. Avoid overcrowding the oven. Utilize convection functions for more even heat.
Oven light not working	Bulb needs replacement.	Refer to the full manual for instructions on replacing the explosion-proof oven light bulb.

7. SPECIFICATIONS

Key technical specifications for the AAOBOSI Electric Range Oven:

- **Brand:** AAOBOSI
- **Model Name:** AAOBOSI
- **Form Factor:** Freestanding
- **Material:** Stainless Steel
- **Finish Type:** Stainless Steel
- **Controls Type:** Knob/Touch
- **Voltage:** 240 volts
- **Oven Capacity:** 6 cubic feet (170 Liters)
- **Number of Cooktop Heating Elements:** 5
- **Cooktop Power Levels:** 9 (Total 9300W)
- **Number of Oven Racks:** 3 (with 7 selectable positions)
- **Drawer Type:** Storage
- **Item Dimensions (D x W x H):** 25"D x 35"W x 35"H (Approximate, refer to Figure 3.2.1 for detailed measurements)
- **Item Weight:** 90 pounds
- **Certifications:** CSA certified

8. WARRANTY AND SUPPORT

AAOBOSI provides lifetime technical support for this freestanding stainless steel electric range oven. If you have any questions or encounter issues during use, please contact us through the store where you purchased the product. We are committed to providing the best solution online within 24 hours.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question