

[Manuals.plus](#) /

› [Sooguard](#) /

› Sooguard Keyboard Case for Samsung Galaxy Tab S11 Ultra 14.6 Inch User Manual

Sooguard Galaxy Tab S11 Ultra Keyboard Case

Sooguard Keyboard Case for Samsung Galaxy Tab S11 Ultra 14.6 Inch User Manual

Model: Galaxy Tab S11 Ultra Keyboard Case

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Sooguard Keyboard Case for the Samsung Galaxy Tab S11 Ultra 14.6 Inch. This keyboard case is designed to enhance your tablet's functionality, offering a comfortable typing experience, precise trackpad control, and versatile viewing angles.

1. SETUP

1.1 Compatibility

The Sooguard Keyboard Case is designed for specific Samsung Galaxy Tab Ultra models. Please verify your tablet's model number to ensure compatibility.

Perfect Fit for 2025-2022 Models

Designed for Samsung Galaxy Tab S11 Ultra

Compatible with



2025 (New): Galaxy Tab S11 Ultra

(SM-X930 / X936B)

2024: Galaxy Tab S10 Ultra

(SM-X920 / X926B)

2023: Galaxy Tab S9 Ultra

(SM-X910 / X916B)

2022: Galaxy Tab S8 Ultra

(SM-X900 / X906)



Setting - About Tablet - Model Name

Image 1.1: Compatibility information for the Sooguard Keyboard Case. This case is compatible with Samsung Galaxy Tab S11 Ultra (2025, SM-X930 / X936B), Galaxy Tab S10 Ultra (2024, SM-X920 / X926B), Galaxy Tab S9 Ultra (2023, SM-X910 / X916B), and Galaxy Tab S8 Ultra (2022, SM-X900 / X906). To check your tablet's model, navigate to "Settings > About Tablet > Model Name".

1.2 Attaching Your Tablet

1. Ensure your tablet is clean and free of debris.
2. Align the back of your Samsung Galaxy Tab S11 Ultra with the magnetic panel on the keyboard case.
3. The strong magnets will securely attach the tablet to the case, creating a floating cantilever design.

1.3 Initial Charging

Before first use, fully charge the keyboard case. Connect the provided USB-C cable to the charging port on the keyboard and to a power source. The charging indicator light will show the charging status.



Image 1.2: The keyboard charging port is located on the side. A full charge takes approximately 2.5 hours, providing up to 200 hours of working time and 90 days of standby time.

1.4 Bluetooth Pairing

1. Turn on the keyboard by pressing the power button (usually located on the side or top edge of the keyboard). The Bluetooth indicator light will flash.
2. On your Samsung Galaxy Tab S11 Ultra, go to **Settings > Connections > Bluetooth**.
3. Ensure Bluetooth is enabled. Your tablet will search for available devices.
4. Select the keyboard (e.g., "Sooguard Keyboard") from the list of available devices.
5. Follow any on-screen prompts to complete the pairing process. The Bluetooth indicator light on the keyboard will turn solid when successfully connected.

2. OPERATING INSTRUCTIONS

2.1 Floating Cantilever Stand

The magnetic floating cantilever design allows for easy adjustment of your tablet's viewing angle. Gently adjust the tablet's position to find your preferred ergonomic setup for typing or viewing content. The stand supports up to a 130-degree viewing angle.

Floating Cantilever Design

Find your perfect viewing angle for work or entertainment



Image 2.1: The floating cantilever design allows for a 130-degree adjustable viewing angle, promoting a raised screen view for improved posture compared to a normal, lower screen view.

2.2 Multi-Touch Trackpad

The integrated multi-touch trackpad provides precise cursor control and supports various gestures for efficient navigation.

- **Trackpad On/Off:** Press **FN + Spacebar** simultaneously to toggle the trackpad on or off.
- **Basic Gestures:**
 - **Single Finger Tap:** Left-click.
 - **Two Finger Tap:** Right-click.
 - **Two Finger Pinch:** Zoom in/out.
 - **Two Finger Scroll:** Scroll up/down.

- **Three Finger Swipe:** Switch between applications.

Large Multi-Touch Trackpad

Smooth & Precise: Like a laptop, but better

Press "FN+ Spacebar" Turn touchpad on/off



Multi-touch
Trackpad



Zoom in
Out



Scroll up
Down



Switch
Apps

Image 2.2: The large multi-touch trackpad supports various gestures including multi-touch, zoom in/out, scroll up/down, and switching applications. The trackpad can be turned on/off by pressing FN + Spacebar.

2.3 Backlit Keyboard

The keyboard features adjustable backlighting with multiple colors and brightness levels for comfortable typing in various lighting conditions.

- **Adjust Brightness:** Press the **Backlight Brightness Key** (often represented by a sun icon) to cycle through 3 levels of brightness or turn off the backlight.
- **Change Color:** Press the **Backlight Color Key** (often represented by a color palette icon or RGB) to cycle through 7 different backlight colors.



Image 2.3: The keyboard offers 7 distinct backlight colors and 3 adjustable brightness levels, providing customizable illumination for typing.

2.4 Dex Mode Support

The keyboard case fully supports Samsung Dex Mode, allowing you to transform your tablet into a desktop-like environment for enhanced productivity. Activate Dex Mode from your tablet's quick settings panel.

2.5 AI Key Functionality

The dedicated AI Key provides quick access to intelligent features or voice assistant functionality on your Samsung Galaxy Tab S11 Ultra. Press this key to activate the assigned AI function.

2.6 Keyboard Key Features

The keyboard is designed for comfortable and efficient typing with the following features:

- **1.0mm Key Travel:** Provides a responsive and tactile typing experience.
- **Skin-friendly Coating:** Ensures a comfortable touch during extended use.
- **Scissor Switch Mechanism:** Offers stable and precise key presses.

- **Silent Keys:** Reduces typing noise for a quieter work environment.

3. MAINTENANCE

3.1 Cleaning Instructions

- Disconnect the keyboard from your tablet and power source before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive cleaner to wipe the surfaces of the keyboard and case.
- Avoid getting moisture into any openings or ports.
- Do not use harsh chemicals, solvents, or abrasive materials, as these can damage the finish.

3.2 Battery Care

- To prolong battery life, avoid fully discharging the keyboard frequently.
- Charge the keyboard when the battery indicator is low.
- Store the keyboard in a cool, dry place if not used for an extended period.

4. TROUBLESHOOTING

- **Keyboard not connecting via Bluetooth:**
 - Ensure the keyboard is powered on and fully charged.
 - Check that Bluetooth is enabled on your tablet.
 - Forget the device in your tablet's Bluetooth settings and attempt to re-pair.
 - Restart both your tablet and the keyboard.
- **Trackpad not responding:**
 - Ensure the trackpad is enabled by pressing **FN + Spacebar**.
 - Clean the trackpad surface to remove any dirt or obstructions.
 - If the issue persists, try re-pairing the keyboard.
- **Backlight not working or changing:**
 - Ensure the keyboard has sufficient battery charge.
 - Press the **Backlight Brightness Key** or **Backlight Color Key** to cycle through options.
- **Keys not responding:**
 - Ensure the keyboard is properly connected via Bluetooth.
 - Check for any physical obstructions under the keys.
 - Restart the keyboard and tablet.

5. SPECIFICATIONS

Feature	Detail
Brand	Sooguard
Model Number	Galaxy Tab S11 Ultra Keyboard Case

Feature	Detail
Compatible Devices	Samsung Galaxy Tab S11 Ultra 14.6 inch (and compatible S8/S9/S10 Ultra models)
Connectivity Technology	Bluetooth
Keyboard Description	Backlit Keyboard With 7-color Illumination And Multi-touch Trackpad
Recommended Uses	Typing
Product Features	Backlit, Floating Cantilever Magnetic Stand, Dex Mode Support, AI Key
Number of Keys	78
Keyboard Backlighting	RGB, 7-color, 3-level adjustable brightness
Language	English
Power Source	Battery Powered (1 battery)
Charging Time	Approx. 2.5 hours
Working Time	Approx. 200 hours
Standby Time	Approx. 90 days
Switch Type	Membrane (Scissor Switch Mechanism)
Keyboard Layout	QWERTY
Water Resistance Level	Not Water Resistant
Colour	Charcoal Black
Material	Plastic
Item Weight	998 g
Item Dimensions (L x W x H)	33L x 24.9W x 1.5H Centimeters
Box Contents	Keyboard Cover

6. WARRANTY INFORMATION

Sooguard products are manufactured with high-quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please refer to the product packaging or the official Sooguard website for specific warranty terms and conditions, including duration and coverage details.

7. CUSTOMER SUPPORT

For technical assistance, troubleshooting, or any questions regarding your Sooguard Keyboard Case, please

contact our customer support team. You can find contact information on the official Sooguard website or through your purchase platform.

Please have your product model number (Galaxy Tab S11 Ultra Keyboard Case) and purchase details ready when contacting support.