MONSGA MV3

MONSGA MV3 Cordless Vacuum Cleaner User Manual

Model: MV3

1. Introduction

Thank you for choosing the MONSGA MV3 Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new vacuum. Please read it thoroughly before first use and keep it for future reference.



The MONSGA MV3 Cordless Vacuum Cleaner is designed for versatile cleaning across various surfaces, offering powerful suction and convenient features.

2. What's in the Box

Your MONSGA MV3 package includes the following components:

- MV3 Cordless Vacuum Main Unit (1)
- Extended Conductive Rod (1)

- FeatherSwing Brushroll (1)
- Crevice Nozzle (1)
- 2-In-1 Combination Brush (1)
- V-Shaped Brush (1, pre-installed)
- Dust Cup & Filter System (1, pre-installed)
- Detachable Battery (1)
- Washable HEPA Filter (2, 1 pre-installed, 1 spare)
- 2-In-1 Charging & Storage Wall Mount (1)
- Adapter (1)
- Wall Mount Fix Tool Bag (1)
- Cleaning Tool (1)
- Instruction Manual (1)

3. Setup

Follow these steps for initial assembly and preparation:

1. **Attach the Extension Tube:** Connect the extended conductive rod to the main unit until it clicks securely into place.
2. **Attach the Floor Head:** Connect the FeatherSwing brushroll (floor head) to the other end of the extended conductive rod. Ensure it clicks firmly.
3. **Install the Battery:** Slide the detachable battery into the main unit until it locks.
4. **Initial Charge:** Before first use, fully charge the vacuum for approximately 4 hours. Refer to the 'Charging and Storage' section for charging methods.



The detachable battery provides flexibility for charging and extended runtime.

4. Operating Instructions

Power On/Off and Mode Selection

The MV3 features an intuitive LED touchscreen for control.

- **Power On/Off:** Use the button on the handle to turn the vacuum on or off.

- **Mode Switch:** Tap the 'Mode Switch' button on the LED display to toggle between Carpet Mode (45KPa suction for deep cleaning) and Barefloor Mode (30KPa suction for daily sweeps). The display shows remaining battery life for the selected mode.



The LED touchscreen provides real-time information and easy mode switching.


Auto-Boost Technology

When powering off in Barefloor Mode, the MV3's smart Auto-Boost activates for 3 seconds, providing turbocharged suction to clear trapped debris into the dustbin. This ensures a thorough clean without needing to

re-vacuum.

Green Search Light

The floor head is equipped with a 4x dust-reveal green beam that illuminates invisible dust, pet dander, and fine particles on your floors, ensuring you clean what's actually there.




The green search light helps reveal hidden dust for a more complete clean.

Maneuverability and Versatility

The MV3 is designed for effortless cleaning in various scenarios:

- **Self-Standing:** The vacuum can stand upright at a 90° angle, allowing you to pause cleaning hands-free.
- **Lie-Flat Design:** A 180° lie-flat design enables easy cleaning under beds, sofas, and other low-clearance furniture.
- **Rotatable Head:** The brushroll offers 150° rotation for navigating around obstacles and corners.
- **Lightweight Handheld Mode:** At just 2.8 lbs, the main unit can be detached for handheld cleaning of ceilings, stairs, car interiors, and upholstery.



The lightweight design and various attachments make the MV3 highly versatile for different cleaning tasks.

Accessories for Specific Tasks


- **Crevice Tool:** Ideal for narrow spaces like car seats, window tracks, and between cushions.
- **2-in-1 Combination Brush:** Features long bristles for dusting and a wider nozzle for upholstery and delicate surfaces.
- **Extended Conductive Rod:** Use with handheld mode for reaching high places like ceilings and tall shelves.

5. Maintenance

Regular maintenance ensures optimal performance and longevity of your MV3 vacuum cleaner.

Dust Cup Emptying

The 0.7L XL dust cup features a one-tap eject system for hygienic emptying. Simply press the release button to dump debris directly into the trash without touching it.




The one-tap system allows for easy and hygienic disposal of collected debris.

Filter System Cleaning

The MV3 utilizes a 5-stage filtration system that captures 99.97% of dust and microscopic particles. All parts of the dustbin, including the HEPA filter and cyclone core, are washable.

1. Remove the dust cup and separate the filter components.
2. Rinse all washable parts under running tap water.
3. Allow all components to air dry completely before reassembling and reinserting into the vacuum. Ensure they are thoroughly dry to prevent damage and maintain suction power.



The multi-layer filtration system is designed for easy cleaning and maintenance.

FeatherSwing Anti-Tangled Brushroll

The unique FeatherSwing brushroll is designed to prevent hair tangles. If debris accumulates, use the provided cleaning tool to remove it. The brushroll can be easily removed for deeper cleaning if necessary.



The FeatherSwing brushroll effectively manages hair and debris without tangling.


6. Charging and Storage

The MV3 offers flexible charging and storage solutions.

Charging Methods

You have three options for charging your MV3:

- **Wall-Mounted:** Hang the entire unit on the wall mount for charging.
- **Desktop Charging:** Place the main unit on a desktop for a quick boost.
- **Standalone Battery Charging:** Remove the detachable battery and charge it separately.



The wall-mount dock provides convenient storage and charging.

Battery Life

The 6-cell rechargeable Lithium-Ion battery provides up to 50 minutes of runtime in Barefloor Mode. Charging time is approximately 4 hours.

7. Specifications

Feature	Detail
Brand	MONSGA
Model Name	MV3
Suction Power	Up to 45KPa (Carpet Mode)
Motor	400W Brushless Motor, 75000 RPM Turbine
Runtime	Up to 50 minutes (Barefloor Mode)
Battery	6-cell Lithium-Ion, Detachable
Charging Time	4 Hours
Dust Cup Capacity	0.7 Liters
Filtration System	5-stage, Washable HEPA Filter
Special Features	Auto-Boost, Green Search Light, LED Touch Display, FeatherSwing Anti-Tangled Brushroll, 90° Self-Standing, 180° Lie-Flat, 150° Swing Angle, Extendable Height (34-47")
Weight	2.8 lbs (handheld unit), 6.61 lbs (total)

Dimensions (L x W x H)	12.95"L x 4.41"W x 8.27"H
Surface Recommendation	Hard Floor, Low-Pile Carpet, Hardwood Floor, Laminate, Luxury Vinyl, Tile

8. Troubleshooting

If you encounter any issues with your MONSGA MV3, please refer to the following common solutions:

- **No Power:** Ensure the battery is fully charged and correctly inserted. Check the power adapter connection if charging.
- **Reduced Suction:** Check if the dust cup is full and needs emptying. Inspect the filters for clogs and clean them as per maintenance instructions. Ensure the brushroll is free of tangled hair or debris.
- **Brushroll Not Spinning:** Check for obstructions in the brushroll. Ensure the floor head is properly attached.
- **Short Runtime:** The battery may not be fully charged, or it might be operating in a higher power mode (Carpet Mode uses more power).

For persistent issues, please contact customer support.

9. Warranty and Support

Your MONSGA MV3 Cordless Vacuum Cleaner is backed by a **2-year full warranty**. MONSGA is committed to providing 100% satisfactory solutions.
For any questions, troubleshooting assistance, or warranty claims, please contact our **24/7 customer support squad**. Real humans are available to reply fast and assist you with any rare glitches, lost parts, or how-to questions.
You can find contact information on the product packaging or the official MONSGA website.

10. Product Video Overview

Watch this official product video for a visual guide on the MONSGA MV3 Cordless Vacuum Cleaner's features and operation.

Your browser does not support the video tag.

Official video showcasing the MONSGA MV3 Cordless Vacuum Cleaner's design, features, and cleaning capabilities.