

OMOTON TP02-Pro

OMOTON TP02-Pro Magnetic Phone Holder Instruction Manual

Model: TP02-Pro

INTRODUCTION

Thank you for choosing the OMOTON TP02-Pro Magnetic Phone Holder. This versatile accessory is designed to enhance your mobile content creation, vlogging, and hands-free viewing experiences. Crafted from durable aluminum alloy, it features a powerful magnetic base, multi-functional expansion options, and free-angle adjustment for optimal positioning. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure you get the most out of your device.

PRODUCT OVERVIEW

The OMOTON TP02-Pro is a compact and robust magnetic phone holder that transforms into a stand, selfie stick, or mount for various surfaces. Its key features include:

- **Powerful Magnetic Base:** Equipped with N52 industrial magnets for secure attachment to metal surfaces.
- **Multi-functional Expansion:** Supports Arca-Swiss standard and 1/4" screw mounts for integration with professional gear.
- **Free-Angle Adjustment:** Offers 3-axis control and 360° rotation for flexible positioning.
- **Durable & Portable Design:** Made from high-strength aluminum alloy, lightweight, and foldable for easy transport.
- **Universal Compatibility:** Compatible with iPhone 12-17 series and other smartphones (4.7-6.5 inches) with the included metal ring.

What's in the Box:

- OMOTON TP02-Pro Magnetic Phone Holder
- Additional Metal Ring (for non-MagSafe compatible phones/cases)

SETUP

Follow these steps to set up your OMOTON TP02-Pro:

1. **Unfold the Holder:** Gently unfold the device to reveal its various components. The arms and base are designed to articulate smoothly.

2. Magnetic Attachment (MagSafe Compatible Phones):

If you have an iPhone 12-17 series or a MagSafe-compatible case, simply align your phone with the magnetic ring on the holder. The strong N52 magnets will securely attach your device.



+



work with included metal ring for all phones

Image: Demonstrates MagSafe compatibility and the use of the included metal ring for non-MagSafe devices.

3. Non-MagSafe Compatibility (Using Metal Ring):

For other smartphones (4.7-6.5 inches) or cases without MagSafe, use the included metal ring. Peel off the adhesive backing and carefully center the metal ring on the back of your phone or phone case. Ensure it is firmly pressed for optimal adhesion. Once attached, your phone can be magnetically mounted to the holder.

4. Attaching to Tripods/Gear (1/4" Screw & Arca-Swiss):

The base of the holder features a 1/4" screw hole and is Arca-Swiss compatible. This allows you to mount the holder onto standard tripods, monopods, or other photography equipment. Simply align the screw or Arca-Swiss plate with the holder's base and secure it.

Ready for Every Shot, Outdoors or On the Go.

Arca-style plate and 1/4" screw compatibility let you mount your phone to most photography gear with ease.



Image: Illustrates the 1/4" screw hole and Arca-Swiss plate compatibility for mounting on external gear.

OPERATING INSTRUCTIONS

The OMOTON TP02-Pro offers multiple modes of operation:

1. Magnetic Mounting

Utilize the powerful magnetic base to attach your phone holder to any suitable metal surface. This is ideal for hands-free recording or viewing.

- **Gym Use:** Securely attach the holder to gym equipment (e.g., weight racks, machines) to record workouts or follow exercise routines.
- **Kitchen Use:** Mount it on a refrigerator, range hood, or other metal surfaces for hands-free recipe viewing or recording cooking tutorials.
- **Workshop/Crafting:** Attach to a metal pegboard or workbench for top-down shots or hands-free reference.

Your Solo Creator Sidekick

Go Hands-Free, Shoot Any Angle. Magnetic & Clamp Power for Effortless POV Content.



Image: Magnetic attachment to gym equipment for recording.

Hands-Free Cooking Shots

Snap your iPhone magnetically to the any metal surface.



Image: Magnetic attachment to a kitchen range hood for cooking.

Magnetic Mount to Your Pegboard

Magnetically mount your iPhone for steady, top-down shots while crafting hands-free.




Image: Magnetic mounting on a pegboard for crafting.

Your browser does not support the video tag.

Video: Demonstrates the OMOTON Magnetic Phone Holder's ability to attach to various metal surfaces.

2. Adjustable Phone Stand / Desktop Use

The holder can be unfolded to form a stable desktop stand. Adjust the 3-axis joints and 360° rotation to achieve your desired viewing or recording angle.

- **Desktop Stand:** Place on a flat surface for video calls, watching content, or hands-free interaction.

- **Low Angle Shots:** Position the stand for unique low-angle perspectives.
- **Overhead Shots:** Use the clamp feature to attach to a desk edge for overhead recording.

3. Selfie Stick / Handheld Grip

When folded, the device functions as a comfortable handheld grip or selfie stick for stable mobile photography and videography.

- **Selfie Grip:** Hold the device for steady selfies or vlogging on the go.
- **POV Shots:** Capture immersive point-of-view footage while moving.

Your browser does not support the video tag.

Video: Showcases the OMOTON Mini Selfie Stick functionality for content creators.

4. Multi-Scenario Applications

The TP02-Pro is designed for diverse environments:

In-Flight Use



Selfie Grip



Low Angle Shot



Desktop Stand



Overhead Shot



Tripod Mount



Image: Multiple usage scenarios including in-flight, selfie, desktop, and tripod mounting.

Smooth, Stable POV Shots

Snap your iPhone to the cart and film smooth POV shots while you shop.




Image: Capturing POV shots while shopping by attaching to a cart.

MAINTENANCE

To ensure the longevity and optimal performance of your OMOTON TP02-Pro, follow these maintenance guidelines:

- **Cleaning:** Wipe the holder with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid abrasive cleaners or solvents.
- **Storage:** When not in use, fold the holder into its compact form and store it in a clean, dry place away from extreme

temperatures and direct sunlight.

- **Magnetic Surfaces:** Ensure the metal surfaces you attach the holder to are clean and free of debris to maintain strong magnetic adhesion.
- **Joints:** The joints are designed for smooth operation. Avoid forcing them beyond their intended range of motion. No lubrication is typically required.

TROUBLESHOOTING

If you encounter issues with your OMOTON TP02-Pro, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Phone does not attach magnetically or falls off easily.	◦ Phone/case is not MagSafe compatible. ◦ Metal ring not properly attached or missing. ◦ Surface is not metal or has a thick coating. ◦ Excessive weight or force applied.	◦ Ensure your phone or case is MagSafe compatible. ◦ Apply the included metal ring correctly to non-MagSafe phones/cases. ◦ Attach to a clean, flat metal surface. ◦ Avoid placing excessively heavy phones or applying strong external forces.
Holder joints are stiff or difficult to adjust.	◦ Dust or debris in joints. ◦ Attempting to force movement beyond design limits.	◦ Clean joints with a soft cloth. ◦ Operate joints within their intended range of motion.
Holder feels unstable when used as a stand.	◦ Not fully unfolded or positioned correctly. ◦ Uneven surface.	◦ Ensure all legs are fully extended and locked into position. ◦ Place on a flat, stable surface.

SPECIFICATIONS

Brand	OMOTON
Model Name	TP02-Pro
Material	Aluminum
Color	Orange (This specific variant)
Compatible Devices	Smartphones 4.7-6.5 inches, including iPhone 12-17 series, Samsung S20/S21/S22, Note series, and others (with included metal ring).
Special Features	360 Degree Rotation, Adjustable, Foldable, Hand Free, Magnetic Base, 1/4" Screw Mount, Arca-Swiss Compatible
Maximum Height	160 Centimeters (approx. 63 inches)
Unit Count	1.0 Count

WARRANTY INFORMATION

The OMOTON TP02-Pro Magnetic Phone Holder comes with a **180-day warranty** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper storage. Please retain your proof of purchase for warranty claims.

SUPPORT

For further assistance, technical support, or warranty inquiries, please contact OMOTON customer service through the retailer where you purchased the product or visit the official OMOTON website. Please have your product model number (TP02-Pro) and proof of purchase ready when contacting support.

OMOTON Official Store: [Visit OMOTON Store on Amazon](#)

© 2026 OMOTON. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question