

[Manuals.plus](#) /

› [AODK](#) /

› AODK Electric Standing Desk (Model B03011OKT901021JP) User Manual

AODK B03011OKT901021JP

AODK Electric Standing Desk User Manual

Model: B03011OKT901021JP

1. INTRODUCTION

Thank you for purchasing the AODK Electric Standing Desk. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new desk. Please read these instructions carefully before use and retain them for future reference.

The AODK Electric Standing Desk is designed to offer a versatile and ergonomic workspace, allowing seamless transitions between sitting and standing positions. Its robust construction and intelligent features aim to enhance your productivity and well-being.



Figure 1.1: AODK Electric Standing Desk in use. This image shows a user enjoying the ergonomic benefits of the desk in a standing position.

2. SAFETY INFORMATION

Important Safety Precautions:

- This electric desk has a maximum load capacity of 80 kg. Do not exceed this weight limit to prevent damage or injury.
- Ensure the desk is used on a level surface.
- Keep children and pets away from the desk during height adjustments to prevent accidents. If children are present, consider fixing the desk height to a safe position.
- Do not attempt to adjust the desk height immediately after disconnecting the power.
- Avoid placing liquids directly on the control panel or near electrical components.
- Regularly check all screws and connections to ensure they are secure.
- Do not disassemble or modify the desk's electrical components. Contact qualified personnel for repairs.

3. PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desktop Panels (4 pieces for 180cm width)
- Desk Frame (Legs, Crossbar)
- Control Panel with LED Display
- Power Adapter and Cable
- Headphone/Bag Hooks (2)
- Assembly Hardware (Screws, Allen wrenches, etc.)
- Cable Management Grommets
- Adjustable Foot Caps
- User Manual

4. ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward. It is recommended to assemble the desk with two people. Please follow the detailed assembly guide provided in the package. The desktop consists of four panels for easier handling and transport.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Desk Frame:** Attach the lifting columns to the feet, then connect the crossbar. Ensure all screws are tightened securely.
3. **Attach Desktop Panels:** Connect the four desktop panels together according to the instructions, then secure them to the assembled desk frame.
4. **Install Control Panel and Accessories:** Mount the control panel to the underside of the desk. Attach the headphone hooks to the sides and insert cable management grommets into the desktop holes.
5. **Connect Power:** Plug the power cable into the control box and then into a wall outlet.



Figure 4.1: Desk Dimensions and Components Overview. This image illustrates the various dimensions of the desk, including its adjustable height range and the layout of its main parts, such as the control panel and power cord.

5. OPERATING INSTRUCTIONS

5.1. Height Adjustment

The desk features an intuitive control panel for electric height adjustment. The height can be adjusted smoothly between 71 cm and 117 cm.

- **To Raise:** Press and hold the "Up" arrow button (▲) on the control panel. Release the button when the desired height is reached.
- **To Lower:** Press and hold the "Down" arrow button (▼) on the control panel. Release the button when the desired height is reached.



Figure 5.1: Control Panel. This image shows the desk's control panel, highlighting the up/down buttons, LED display, and two memory preset buttons.

5.2. Memory Function

The desk allows you to save two preferred height settings for quick adjustments.

1. To Set a Memory Position:

- Adjust the desk to your desired height using the Up/Down buttons.
- Press the "M" button (or similar memory set button, if present, otherwise assume direct press on 1 or 2). The LED display may flash.
- Immediately press either "1" or "2" button to save the current height to that preset. The display will confirm the setting.

2. To Recall a Memory Position:

- Simply press the "1" or "2" button. The desk will automatically move to the saved height.

5.3. Obstacle Detection

The AODK Electric Standing Desk is equipped with an obstacle detection feature. If the desk encounters an obstruction during height adjustment, it will automatically stop and reverse slightly to prevent damage or injury. This feature is designed for safety and cannot be disabled.



Figure 5.2: Motor with Collision Prevention. This image highlights the desk's motor, emphasizing its low noise level and integrated collision prevention technology for enhanced safety.

6. ADDITIONAL FEATURES

- **Storage Hooks:** The desk includes convenient hooks on the sides, perfect for hanging headphones, bags, or other accessories, keeping your workspace tidy.
- **Cable Management Holes:** Integrated cable holes help organize and route your power cords and peripheral cables, maintaining a clean and professional look.
- **Low-Noise Operation:** Designed with specialized foot caps and a quiet motor, the desk operates with minimal noise (45-55 dB), ensuring a peaceful environment even during height adjustments.
- **Integrated USB Port:** A built-in USB port allows for convenient charging of your devices directly from the desk.
- **Adjustable Foot Caps:** The desk features adjustable foot caps to compensate for uneven floor surfaces, ensuring stability.



シンプルなタッチ高さ調整

2つのメモリ設定

Figure 6.1: Convenient Features. This image showcases the practical design elements of the desk, including the headphone hook, low-noise foot caps, and a cable hole for organized wiring.

7. MAINTENANCE

To ensure the longevity and optimal performance of your AODK Electric Standing Desk, follow these maintenance guidelines:

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Check Connections:** Periodically inspect all screws and bolts to ensure they are tight. Re-tighten if necessary.
- **Cable Management:** Ensure cables are neatly organized and not pinched or strained, especially during height adjustments.
- **Power Cord:** Check the power cord for any signs of damage. If damaged, discontinue use and contact customer support for a replacement.

8. TROUBLESHOOTING

If you encounter any issues with your desk, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected, motor overload, control panel issue.	Check power connections. Unplug and replug the power cord. Wait 20 minutes if motor was overloaded. Contact support if issue persists.
Desk moves unevenly or makes unusual noise.	Loose connections, uneven load, obstruction.	Check all assembly screws. Redistribute weight evenly on the desktop. Check for any obstructions under the desk.
Memory function not working.	Incorrect setting procedure.	Refer to Section 5.2 for correct memory setting procedure. Ensure you press the memory button immediately after setting the height.
Obstacle detection triggers frequently.	Sensitive setting, actual obstruction.	Ensure there are no objects in the path of the desk's movement. If the issue persists without obstruction, contact customer support.

If these steps do not resolve the issue, please contact AODK customer support for further assistance.

9. SPECIFICATIONS

Feature	Detail
Brand	AODK
Model Number	B03011OKT901021JP
Desk Type	Electric Standing Desk, Computer Desk
Color	White
Desktop Width	180 cm
Desktop Depth	60 cm
Height Adjustment Range	71 cm - 117 cm
Maximum Load Capacity	80 kg
Product Weight	20 kg
Base Material	Metal
Special Features	Electric Height Adjustment, Memory Function (2 presets), Obstacle Detection, Low-Noise Motor (45-55 dB), Storage Hooks, Cable Management Holes, Integrated USB Port, Adjustable Foot Caps
Assembly	Assembly instructions provided, four-panel desktop construction.

10. WARRANTY AND SUPPORT

For warranty information, technical support, or to inquire about replacement parts, please contact AODK customer service. Details can typically be found on the product packaging or the official AODK website.

When contacting support, please have your product model number (B03011OKT901021JP) and purchase date readily available.