

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [FUNYET](#) /

› [FUNYET NY-14 Laptop \(Intel 4425Y\) User Manual](#)

FUNYET NY-14 4425Y

FUNYET NY-14 Laptop (Intel 4425Y) User Manual

Model: NY-14 with Intel 4425Y Processor

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your FUNYET NY-14 Laptop. Please read this manual thoroughly before using your device to ensure proper function and longevity.



Image 1.1: The FUNYET NY-14 Laptop in a closed position, showcasing its sleek design.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 × FUNYET NY-14 Laptop (Intel 4425Y)
- 1 × 12V2A DC Adapter
- 1 × Instruction Manual (this document)
- 1 × Warranty Card

3. SETUP

3.1 Initial Charging and Power On

1. Connect the provided 12V2A DC adapter to the laptop's DC power port and a power outlet.
2. Allow the laptop to charge for at least 30 minutes before initial use.
3. Press and hold the power button for a few seconds until the screen illuminates to power on the device.

3.2 Operating System Setup (Windows 11 Pro)

Upon first boot, you will be guided through the Windows 11 Pro setup process. Follow the on-screen instructions to configure:

- Language and Region
- Network connection (Wi-Fi)
- Microsoft account login or local account creation
- Privacy settings

3.3 Keyboard Configuration

The laptop may come with a non-Italian keyboard layout. To adjust this:

- Go to Windows Settings > Time & Language > Language & Region.
- Add your preferred keyboard layout (e.g., Italian).
- Physical keyboard stickers may be provided to visually match the desired layout. Apply these carefully if needed.

4. OPERATING INSTRUCTIONS

4.1 Power Management

- **Power On:** Press and hold the power button.
- **Sleep Mode:** Briefly press the power button or close the lid.
- **Shut Down:** Click Start > Power > Shut down in Windows.
- **Restart:** Click Start > Power > Restart in Windows.

4.2 Display and Visuals

The FUNYET NY-14 features a 15.6-inch Full HD (1920x1080) IPS display, offering clear visuals and wide viewing angles. The 180° hinge allows for flexible screen positioning, useful for sharing content.

15.6 inch HD Display



full HD 1920*1080



True HD View



IPS



Eyes Protection



Image 4.1: Visual representation of the 15.6-inch Full HD IPS display with features like 1920P resolution, True HD View, IPS technology, and Eyes Protection.

4.3 Connectivity

- **Wi-Fi:** Supports Wi-Fi 5 (802.11 ac) for stable and fast internet connection. Connect via Windows network settings.
- **Bluetooth:** Features Bluetooth 4.2 for connecting wireless peripherals like mice, keyboards, headphones, or speakers. Enable Bluetooth in Windows settings to pair devices.

4.4 Ports and External Devices

The laptop offers a variety of ports for connecting external devices:

- **USB 3.0 Ports (x2):** For high-speed data transfer with USB drives, external hard drives, and other USB peripherals.
- **Mini HDMI Port (x1):** Connect to external monitors or projectors for extended display. An adapter may be required.
- **TF Card Slot (MicroSD):** Insert a TF (MicroSD) card for additional storage or data transfer.

- **3.5mm Headphone Jack:** For connecting headphones or external speakers.




Image 4.2: Overview of the laptop's diverse ports, including TF Card slot, Headphone Jack, USB 3.0, Mini HDMI, and DC Power port.

4.5 Webcam and Microphone

The integrated 1MP front camera and microphone are suitable for video calls and online meetings.

Godere di una comunicazione efficace



1MP Front Camera



Numeric Keypad



BT4.2



WIFI5



Image 4.3: Features for effective communication, highlighting the 1MP front camera, numeric keypad, Bluetooth 4.2, and Wi-Fi 5 connectivity.

4.6 Battery Usage

The laptop is equipped with a 5000mAh battery. For optimal battery life:

- Avoid fully discharging the battery frequently.
- Store the laptop in a cool, dry place when not in use.
- Adjust power settings in Windows to optimize battery consumption.

5000mAh for Extended Battery Life

NY-14 laptop features a high-capacity 5000mAh/38.5Wh battery, freeing you from battery life anxiety.




Image 4.4: Illustration emphasizing the 5000mAh battery capacity designed for extended use.

4.7 Keyboard and Touchpad

The laptop features a full-size keyboard with a numeric keypad for efficient data entry. The touchpad supports multi-touch gestures for navigation.

5. MAINTENANCE

5.1 Cleaning

- Use a soft, lint-free cloth to clean the screen and exterior surfaces.
- For stubborn marks, dampen the cloth slightly with water or a screen-safe cleaner.
- Avoid harsh chemicals, abrasive materials, or excessive moisture.

5.2 Software Updates

Regularly check for and install Windows updates to ensure system stability, security, and performance. Go to Settings > Windows Update.

5.3 Storage Management

The 256GB SSD provides fast performance. To maintain optimal speed:

- Avoid filling the SSD to full capacity. Leave some free space for system operations.
- Regularly delete unnecessary files and uninstall unused applications.

6. TROUBLESHOOTING

This section addresses common issues you might encounter.

6.1 Power Issues

- **Laptop does not turn on:** Ensure the power adapter is securely connected and the battery has sufficient charge. Try holding the power button for 10-15 seconds for a hard reset.
- **Battery drains quickly:** Check power settings in Windows. Reduce screen brightness, close unnecessary applications, and disconnect unused peripherals.

6.2 Display Problems

- **No display:** Connect an external monitor via Mini HDMI to check if the issue is with the laptop's screen or the system.
- **Flickering screen:** Update graphics drivers or adjust display refresh rate in Windows settings.

6.3 Connectivity Issues

- **Wi-Fi not connecting:** Ensure Wi-Fi is enabled in Windows settings. Restart your router and the laptop.
- **Bluetooth device not pairing:** Ensure Bluetooth is enabled on both devices and they are in pairing mode. Remove and re-add the device in Windows settings.

6.4 System Errors

- **Frequent crashes or blue screens:** This can indicate software conflicts or hardware issues. Try reinstalling Windows if the problem persists after driver updates. If the issue continues, contact support.

7. SPECIFICATIONS

Detailed technical specifications for the FUNYET NY-14 Laptop (Intel 4425Y).




Image 7.1: Overview of key specifications including processor, ports, display, battery, and graphics.

Feature	Specification
Brand	FUNYET
Model Name	NY-14
Processor	Intel Core 4425Y (1.7 GHz)
Processor Cores/Threads	2 Cores / 4 Threads
RAM	8 GB DDR3 SDRAM
Storage	256 GB SSD (eSATA Interface)
Display Size	15.6 Inches
Display Resolution	1920 x 1080 Pixels (Full HD IPS)

Feature	Specification
Graphics	Integrated Intel UHD Graphics 615
Operating System	Windows 11 Pro
Wireless Connectivity	Wi-Fi 5 (802.11ac), Bluetooth 4.2
Ports	2x USB 3.0, 1x Mini HDMI, 1x DC Power, 1x 3.5mm Headphone Jack, 1x TF Card Slot
Battery Capacity	5000 mAh
Weight	1.6 Kilograms
Color	Silver
Special Features	HD Audio, Lightweight, Memory card slot, Numeric keypad, 180° hinge

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Your FUNYET NY-14 Laptop comes with a warranty. Please refer to the included Warranty Card for details on coverage, terms, and conditions. Keep your proof of purchase for warranty claims.

8.2 Technical Support

For technical assistance or if you encounter issues not covered in this manual, please contact the seller, Caiyue Electronics, through the Amazon platform. They can provide support and guidance for your device.