

[Manuals.plus](#) /

> [CLP](#) /

> CLP Sirba Ergonomic Office Chair with Massage and Footrest Instruction Manual

CLP 327210

CLP Sirba Ergonomic Office Chair Instruction Manual

Model: 327210

1. INTRODUCTION

Thank you for choosing the CLP Sirba Ergonomic Office Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read it thoroughly before use and retain it for future reference.

Key Features:

- **Ergonomic Design:** Features an ergonomic backrest, padded armrests, and a retractable footrest for optimal comfort.
- **Advanced Seating:** Equipped with a durable pocket spring core for stable and healthy seating.
- **Versatile Adjustments:** Reclines up to 135° with a locking mechanism, adjustable seat height via a Class 4 gas lift, and 360° swivel capability.
- **Luxurious Massage Function:** A 4-point massage system (two in the back, two in the lumbar area) with adjustable intensity and four programs (Standard, Pulse, Pressure, Wave).
- **Integrated Heating:** Lumbar cushion includes a heating function for enhanced comfort.
- **Stable Construction:** Chrome-look metal frame and durable plastic wheels support up to 150 kg. Upholstered in resistant synthetic leather.

2. SAFETY INFORMATION

Please observe the following safety guidelines to prevent injury or damage to the product:

- **Weight Limit:** Do not exceed the maximum weight capacity of 150 kg (330 lbs).
- **Proper Use:** Use the chair only for its intended purpose as an office or desk chair. Avoid standing on the chair or using it as a ladder.
- **Assembly:** Ensure all components are correctly assembled and tightened before use. Regularly check all screws and bolts for tightness.
- **Electrical Safety:** For models with massage and heating functions, ensure the power adapter and cables are not damaged. Do not use if any electrical components are exposed or frayed. Keep liquids away from electrical parts. Unplug the chair when not in use or during cleaning.
- **Children and Pets:** Keep children and pets away from the chair during assembly and operation to prevent accidents.
- **Floor Protection:** Use a floor mat if necessary to protect delicate flooring from wheel marks.

3. PACKAGE CONTENTS

Before assembly, please verify that all parts are present and undamaged. If any parts are missing or damaged, contact customer support.

- Backrest
- Seat with integrated footrest and massage/heating unit
- Armrests (2x)
- Star base
- Wheels (5x)
- Gas lift cylinder with cover
- Mechanism plate
- Remote control with power adapter
- Hardware kit (screws, washers, Allen key)

4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your CLP Sirba office chair. It is recommended to have two people for assembly.

1. **Attach Wheels to Base:** Insert the five wheels into the openings at the end of each leg of the star base until they click securely into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the star base. Cover the gas lift with the telescopic cover.
3. **Attach Mechanism Plate:** Secure the mechanism plate to the underside of the seat using the provided screws. Ensure the front of the mechanism faces the front of the seat.
4. **Attach Armrests:** Fasten the armrests to the sides of the seat using the designated screws. Do not overtighten initially.
5. **Connect Backrest:** Attach the backrest to the seat and armrests using the remaining screws. Once all screws are in place, tighten them firmly but do not overtighten.
6. **Place Seat Assembly on Gas Lift:** Carefully place the assembled seat onto the gas lift cylinder, ensuring it is centered and stable.
7. **Connect Power:** Locate the power cable for the massage and heating unit, usually found under the seat. Connect it to the remote control, then plug the power adapter into the remote control and a suitable power outlet.



Illustration showing key components such as the remote control, 360-degree swivel wheels, and the premium gas lift piston, which are essential for assembly and operation.

5. OPERATING INSTRUCTIONS

5.1. Adjusting Seat Height

To adjust the seat height, pull the lever located under the right side of the seat upwards. To raise the seat, lift the lever while taking your weight off the chair. To lower the seat, lift the lever while seated.

5.2. Recline Function

The chair can recline up to 135 degrees. To recline, pull the lever on the left side of the seat upwards and lean back. Release the lever to lock the backrest in your desired position. To return to an upright position, lean forward slightly while pulling the lever.



ERGONOMÍA EN MOVIMIENTO

Mecanismo de inclinación de 135°, muelles ensacados en el asiento, reposapiés, función de masaje de 4 puntos y cojín lumbar con función de calefacción para sentarse cómodamente en la oficina y en el home office.

The chair's recline function allows for comfortable relaxation, extending up to 135 degrees with an integrated footrest.

5.3. Footrest Operation

To extend the footrest, pull it out from underneath the seat. To retract, push it back in until it is fully stored.

5.4. Massage and Heating Functions

The massage and heating functions are controlled via the wired remote control. Ensure the chair is plugged into a power outlet.

- **Power On/Off:** Press the power button on the remote control to activate or deactivate the massage and heating.
- **Massage Points:** The chair features 4 massage points: two in the back and two in the lumbar area.
- **Massage Programs:** Select from four available programs: Standard, Pulse, Pressure, and Wave. Refer to the remote control's icons for specific program selection.
- **Intensity Adjustment:** Use the '+' and '-' buttons on the remote to increase or decrease the massage intensity.
- **Heating Function:** The heating function is integrated into the lumbar cushion. Activate it via the dedicated button on the remote control.



The 4-point massage system targets the back and lumbar regions, providing soothing relief.



Control intuitivo.

Autoexplicativo
y listo para usar de inmediato.

The intuitive remote control allows for easy adjustment of massage programs, intensity, and heating.

5.5. Swivel Function

The chair is designed to swivel 360 degrees, allowing for easy movement and access within your workspace.

6. MAINTENANCE AND CARE

Regular maintenance will prolong the life and appearance of your chair.

- **Cleaning Synthetic Leather:** Wipe the synthetic leather upholstery with a soft, damp cloth. For stubborn stains, use a mild soap solution and then wipe clean with a dry cloth. Avoid harsh chemicals, abrasive cleaners, or solvents, as these can damage the material.
- **Frame and Base:** Clean the chrome-look metal frame and plastic base with a soft, dry cloth.
- **Wheels:** Periodically check the wheels for accumulated hair or debris and clean them to ensure smooth gliding.
- **Hardware:** Every few months, check all screws and bolts to ensure they are tight. Retighten if necessary to maintain stability.

- **Electrical Components:** Keep the remote control and power adapter dry. Do not attempt to open or repair electrical components yourself.

7. TROUBLESHOOTING

If you encounter any issues with your chair, refer to the following common problems and solutions:

- **Chair is unstable or wobbly:**
Solution: Check all assembly screws and bolts, especially those connecting the seat, backrest, and armrests. Tighten any loose hardware. Ensure the gas lift is properly seated in the star base.
- **Seat height adjustment not working:**
Solution: Ensure the gas lift lever is fully engaged. If the chair does not raise, the gas lift cylinder may be faulty and require replacement. Contact customer support.
- **Massage or heating function not working:**
Solution:
 - a. Verify that the power adapter is securely plugged into both the remote control and a working wall outlet.
 - b. Check if the power button on the remote control is pressed.
 - c. Inspect the power cable for any visible damage or kinks.
 - d. If only the massage works but heating does not (or vice-versa), there might be an internal wiring issue. Contact customer support for assistance.
- **Chair makes squeaking noises:**
Solution: Apply a small amount of silicone spray or lubricant to moving parts, such as the tilt mechanism and the connections between the backrest and seat. Check and tighten all screws.
- **Wheels not rolling smoothly:**
Solution: Remove any hair, dust, or debris that may be caught in the wheel casters. Clean the wheels thoroughly.

8. SPECIFICATIONS

Feature	Specification
Brand	CLP
Model Number	327210
Color	Black
Product Dimensions (D x W x H)	67 cm x 64 cm x 112-120 cm
Product Weight	21 kg
Material	Synthetic Leather (Upholstery), Alloy Steel (Frame)
Maximum Load Capacity	150 kg
Recline Angle	Up to 135°
Swivel	360°

Detalles **Medidas**

NIVEL SUPERIOR

Estabilidad y
Ergonomía



Altura 112 – 120cm

Ancho 64cm

Fondo 67cm

Carga máx. 150kg

Detailed measurements and maximum load capacity of the CLP Sirba office chair.

9. WARRANTY AND SUPPORT

For warranty information, technical support, or replacement parts, please contact the retailer or manufacturer directly. Keep your purchase receipt as proof of purchase.

You can find more information about CLP products and contact details on their official brand store:

[Visit the CLP Brand Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GFDQZG8T>

More documents and user manuals: <https://manuals.plus/>