Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FLEXISPOT E1PRO SET

FLEXISPOT E1PRO SET Electric Standing Desk User Manual

Model: E1PRO SET (White, 160 x 80 cm)

1. Introduction

Thank you for choosing the FLEXISPOT E1PRO SET Electric Standing Desk. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new desk. Please read it thoroughly before use and keep it for future reference.

The FLEXISPOT E1PRO SET features a robust European-made tabletop (160 x 80 cm) crafted from eco-friendly materials, offering a smooth, scratch-resistant, and durable surface. Equipped with a powerful dual-motor system, it allows for stable and efficient height adjustment from 70 cm to 119 cm, supporting a static load of up to 100 kg.



Image: The FLEXISPOT E1PRO SET Electric Standing Desk in an office setting, highlighting its ergonomic design for comfort and productivity.

2. Important Safety Information

- **Warning:** The desk attachment should be properly secured to the floor to prevent dangerous tipping.
- Do not exceed the maximum load capacity of**100 kg**.
- Keep children and pets away from the desk during operation.
- Ensure no obstacles are in the path of the desk's movement (up or down).
- Do not sit or stand on the desk.
- Disconnect power before cleaning or maintenance.
- Use only the provided power adapter and components.

3. Package Contents

Your FLEXISPOT E1PRO SET desk is delivered in two separate packages. Please ensure you have received both before beginning assembly.

- Desk Frame (legs, crossbar, motors, control box, control panel)
- Tabletop (160 x 80 cm, White)
- Assembly Hardware Kit (screws, Allen wrenches, cable ties)
- Power Adapter and Cable
- User Manual

4. Product Specifications

Feature	Specification
Brand	FLEXISPOT
Model Number	E1PRO SET
Tabletop Dimensions	160 cm (Width) x 80 cm (Depth)
Height Adjustment Range	70 cm - 119 cm
Motor Type	Dual Motor
Adjustment Speed	Up to 25 mm/s
Load Capacity (Static)	100 kg
Tabletop Material	Wood (FSC-certified MDF with high-pressure laminate)
Frame Material	Metal
Color	White
Assembly Required	Yes
UPC	840521535762



Image: Close-up of desk tops, emphasizing the 'Made in EU' quality and eco-friendly materials.

5. Assembly Instructions

The FLEXISPOT E1PRO SET is designed for easy assembly. All necessary tools and a step-by-step instruction manual are included. Please follow the provided printed guide for detailed assembly steps.

1. **Unpack Components:** Carefully remove all parts from the two packages. Verify all components are present against the packing list.
2. **Assemble the Frame:** Follow the instructions to connect the desk legs, crossbar, and motors. Ensure all screws are tightened securely.
3. **Attach the Tabletop:** Align the tabletop with the pre-drilled holes on the frame. Secure the tabletop using the provided screws. *Note: Some users have reported minor discrepancies with pre-drilled holes; ensure proper alignment before tightening. If new holes are needed, pre-drill with a 2mm bit to prevent damage.*
4. **Install Control Panel:** Mount the control panel to your preferred side (left or right) using the designated holes.
5. **Connect Wiring:** Connect the motor cables to the control box, and the control panel cable to the control box. Finally, connect the power adapter to the control box and then to a power outlet. Use the included cable management accessories to keep wires tidy.
6. **Initial Calibration:** After connecting power, perform the initial calibration as described in the detailed manual to ensure proper height adjustment functionality.



Image: Visual representation of the desk's height adjustment range (70-119cm) and dual-motor system for stable operation.

6. Operating Instructions

6.1. Height Adjustment

The desk's height can be effortlessly adjusted using the control panel. The dual-motor system ensures smooth and stable movement at a speed of up to 25 mm/s.

- **Up Button (▲):** Press and hold to raise the desk to your desired standing height.
- **Down Button (▼):** Press and hold to lower the desk to your desired sitting height.
- The LED display will show the current height in centimeters.

6.2. Memory Presets

The control panel allows you to save up to four preferred height settings for quick adjustments.

1. **Set a Memory Position:** Adjust the desk to your desired height using the Up/Down buttons. Press the 'M' button (or 'i' depending on control panel version) followed by a number button (1, 2, 3, or 4) to save the current height. The display will confirm the setting.
2. **Recall a Memory Position:** Simply press the corresponding number button (1, 2, 3, or 4) to automatically move the desk to the saved height.



Image: The desk's control panel, featuring an LED display for height and buttons for up, down, and four memory presets.

7. Maintenance

- **Cleaning:** Wipe the tabletop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the surface.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Cable Management:** Ensure all cables are neatly managed and not pinched or tangled, which could affect desk operation or cause damage.

- **Stability:** The desk features rubber pads on the supports and adjustable feet to enhance friction and stability. Ensure these are intact and adjusted for uneven floors to prevent wobbling.



Image: Details on rubber pads for increased friction and adjustable feet for wobble control, ensuring desk stability.

8. Troubleshooting

Problem	Possible Cause	Solution
Desk does not move	Power cable disconnected, control box error, overload.	Check power connections. Unplug and replug the power cable. Reduce weight on the desk. Perform a reset (refer to detailed manual).
Uneven height / Wobbling	Uneven floor, loose connections, damaged leg.	Adjust the leveling feet at the bottom of the desk legs. Ensure all assembly screws are tight. If wobbling persists, check for damage to the frame.

Problem	Possible Cause	Solution
Error code on display	Specific error detected by the control box.	Refer to the detailed manual for specific error code meanings and solutions. Often, a power cycle or reset can resolve minor errors.
Desk stops mid-movement	Overload protection, thermal protection.	Reduce weight on the desk. Allow the motors to cool down for 20-30 minutes if used continuously for an extended period.

9. Warranty Information

The FLEXISPOT E1PRO SET Electric Standing Desk comes with a**Limited Warranty**. Please refer to the warranty card included in your package or visit the official FLEXISPOT website for detailed terms and conditions regarding coverage, duration, and claims procedures.

10. Customer Support

As a local distributor in Germany, FLEXISPOT ensures prompt service. Your order will be dispatched from our local warehouse on the next business day. We are committed to providing excellent customer service.

For any questions, technical assistance, or warranty claims, please contact FLEXISPOT customer support through the following channels:

- **Website:** www.flexispot.com
- **Email:** Refer to your purchase documentation for specific contact email.
- **Phone:** Refer to your purchase documentation for specific contact number.

Please have your model number (E1PRO SET) and purchase date ready when contacting support.

© 2026 FLEXISPOT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GFF74MTT

More documents and user manuals: **https://manuals.plus/**