

NICESOUL LC-BE-LMT-9019

NICESOUL Outdoor Lounge Chair with Ottoman Instruction Manual
Model: LC-BE-LMT-9019

1. SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Weight Capacity:** The lounge chair supports a maximum weight of 400 lbs (181 kg). The ottoman supports a maximum weight of 350 lbs (159 kg). Do not exceed these limits.
- **Intended Use:** This product is designed for outdoor use only. Avoid using it indoors unless specified.
- **Stable Surface:** Always place the chair and ottoman on a flat, stable, and level surface to prevent tipping.
- **Children:** Supervise children when they are near or using the furniture.
- **Moving Parts:** Be cautious of pinch points during assembly and when adjusting the furniture.
- **Weather Conditions:** While designed for outdoor use, prolonged exposure to extreme weather (heavy rain, strong winds, snow) may reduce product lifespan. Consider covering or storing the furniture during harsh conditions.

2. PACKAGE CONTENTS

Before assembly, ensure all parts listed below are present and undamaged. If any parts are missing or damaged, contact NICESOUL customer service.

- Metal Frame (for chair and ottoman)
- Large Seat Cushion
- Mesh Fabric (for chair base)
- Accessory Kit (screws, tools, etc.)
- Installation Manual (this document)



Figure 2.1: Dimensions and weight capacities of the lounge chair and ottoman.

3. ASSEMBLY INSTRUCTIONS

The NICESOUL Outdoor Lounge Chair with Ottoman is designed for straightforward assembly. It is recommended to have two people for easier assembly, though one person can complete it.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify the metal frame pieces for the chair and ottoman.
3. Attach the mesh fabric to the chair frame according to the provided accessory kit instructions. Ensure all connections are secure.
4. Assemble the ottoman frame using the provided hardware.
5. Place the large seat cushion onto the assembled chair frame.
6. Place the smaller cushion onto the assembled ottoman frame.
7. Verify all screws and connections are tightened securely before use.

Assembly Video Guide

Your browser does not support the video tag.

Video 3.1: Step-by-step guide for assembling the NICESOUL Lounge Chair with Ottoman.

4. OPERATING INSTRUCTIONS

The NICESOUL Outdoor Lounge Chair with Ottoman is designed for comfort and versatility in various outdoor settings.

4.1 Using the Lounge Chair

- **Relaxation:** The chair features a gently reclined high back and supportive armrests, providing a comfortable position for lounging, reading, or relaxing.
- **Breathable Design:** The Textilene mesh seat base combined with padded cushions promotes airflow, keeping you comfortable, especially in warmer weather.
- **Easy Standing:** The armrests provide support, making it easier to sit down and stand up from the chair.



Figure 4.1: Demonstrating comfortable lounging with the chair and ottoman.



Figure 4.2: The reclined back and armrests provide enhanced support and relaxation.



Figure 4.3: The breathable mesh base ensures comfort, while non-slip pads protect surfaces.

4.2 Using the Ottoman

- **Footrest:** Use the ottoman to elevate your legs for enhanced relaxation while seated in the lounge chair.
- **Extra Seating:** The ottoman can serve as additional seating for guests when needed.
- **Side Table:** By removing the cushion, the ottoman's frame can function as a small side table for holding drinks, books, or snacks.



Figure 4.4: The ottoman can be used as a footrest or additional seating.



Figure 4.5: The ottoman offers multiple functional uses.

4.3 Placement Options

The NICESOUL lounge chair and ottoman are suitable for various outdoor environments.



Figure 4.6: Examples of suitable outdoor placements for the lounge chair and ottoman.

5. MAINTENANCE

Proper care and maintenance will extend the life and appearance of your NICESOUL lounge chair and ottoman.

5.1 Cushion Care

- **Cleaning:** For general cleaning, spot clean with a mild soap and water solution. For deeper cleaning, dry cleaning is recommended.
- **Water Resistance:** The fabric is water-repellent. Wipe spills immediately to prevent staining.
- **Fade Resistance:** The solution-dyed yarn is highly resistant to UV light and fading. However, prolonged direct sunlight may still cause some color change over time.
- **Storage:** During periods of non-use or harsh weather, store cushions in a dry, protected area to maintain their quality.



Figure 5.1: Cushion fabric features for durability and easy maintenance.

5.2 Frame Care

- **Cleaning:** Wipe the powder-coated steel frame with a damp cloth and mild soap. Dry thoroughly.
- **Rust Prevention:** The powder-coated finish helps reduce rust. Inspect regularly for any scratches or chips in the coating and touch up if necessary to prevent rust.
- **Non-slip Pads:** Ensure non-slip foot pads are intact to protect surfaces and maintain stability.

5.3 Product Feature Video

Your browser does not support the video tag.

Video 5.2: Demonstrating the water-resistant cushions and non-slip feet of the lounge chair.

6. TROUBLESHOOTING

If you encounter issues with your NICESOUL lounge chair and ottoman, refer to the following common solutions.

- **Instability/Wobbling:** Ensure all screws and bolts are fully tightened. Check that the chair and ottoman are placed on a flat, even surface.
- **Missing Parts:** Refer to the "Package Contents" section. If parts are missing upon arrival, contact customer service immediately.

- **Difficulty Assembling:** Review the assembly instructions and video carefully. Ensure you are using the correct hardware for each step. Do not force parts together.
- **Cushion Flatness:** Allow cushions time to expand after unpacking. Fluffing them regularly can help maintain their shape.

7. SPECIFICATIONS

Feature	Detail
Brand	NICESOUL
Model Name	Cushioned Lounge Chair with Ottoman
Model Number	LC-BE-LMT-9019
Color	Beige
Material	Mesh, PP Cotton, Polyester, Powder Coated Alloy Steel
Product Dimensions (Chair)	39.37"D x 26.38"W x 35.43"H (100cm D x 67cm W x 90cm H)
Item Weight	26.4 pounds (12 kg)
Maximum Weight Recommendation (Chair)	400 pounds (181 kg)
Maximum Weight Recommendation (Ottoman)	350 pounds (159 kg)
Indoor/Outdoor Usage	Outdoor
Recommended Uses	Lounging, Reading, Relaxing, Sleeping, Sunbathing
Included Components	Accessory Kit, Installation Manual, Large Seat Cushion, Mesh Fabric, Metal Frame
Product Care Instructions	Dry Clean, Spot Clean, Wipe Clean

8. WARRANTY AND SUPPORT

For warranty information or technical support, please contact NICESOUL customer service. Details regarding specific warranty periods and terms are typically provided with your purchase documentation or can be obtained directly from the manufacturer. Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GFFKG9G2>

More documents and user manuals: **<https://manuals.plus/>**