Bella Depot B0GFTB96NF

Bella Depot 36-inch Farmhouse Ceiling Fan with Light User Manual

Model: B0GFTB96NF

1. Safety Information

Please read and understand this entire manual before attempting to assemble, operate, or install the product. Failure to do so could lead to electric shock, fire, or other injuries.

- **Electrical Safety:** Always disconnect power at the main circuit breaker before installation or servicing. Ensure all electrical connections comply with local codes and ordinances. If you are unsure about wiring, consult a qualified electrician.
- **Mounting:** The fan must be mounted to a structurally sound ceiling joist or outlet box capable of supporting the fan's weight (approximately 15 lbs). Use only the hardware provided.
- **Blade Clearance:** Ensure there is at least 7 feet (2.1 meters) of clearance from the floor to the fan blades and at least 30 inches (76 cm) from the fan blades to any wall or obstruction.
- **Bulbs:** Use E12 base bulbs, maximum 9W LED each. Bulbs are not included.
- **Children and Pets:** Keep children and pets away from the fan during installation and operation.

2. Product Overview

The Bella Depot 36-inch Farmhouse Ceiling Fan with Light combines rustic charm with modern functionality. This fandelier features a light, natural wood-grain finish and a durable metal frame, designed to complement contemporary farmhouse decor. It includes an integrated 8-light chandelier (E12 sockets, bulbs not included) and a quiet, reversible DC motor for year-round comfort.



Figure 2.1: The Bella Depot 36-inch Farmhouse Ceiling Fan with Light installed in a dining room setting.

Key Features:

- **Authentic Light Wood Finish:** Features a natural wood-grain finish on a durable metal frame, offering a warm aesthetic without warping.
- **Standard Ceiling Fit:** Designed for 8-10 ft ceilings with a fixed 19.6-inch downrod for secure, wobble-free installation.

- **Ultra-Quiet DC Motor:** Operates below 35dB, providing quiet airflow with 6-speed control and reversible function for summer and winter.
- **Elegant 8-Light Chandelier:** Eight E12 sockets (max 9W LED each) provide balanced illumination. Bulbs are not included.
- **Remote Control:** Includes a remote for convenient control of fan speeds, light, and timer settings.



Figure 2.2: Material comparison highlighting the durable and stable construction of the Bella Depot fan.

Your browser does not support the video tag.

Video 2.1: An 8-second video showcasing the Bella Depot 36-inch Farmhouse Ceiling Fan with Light, highlighting its design and features.

3. Package Contents

Carefully unpack all components and ensure you have received all items listed below. If any parts are missing or damaged, contact customer support before proceeding with installation.

- Ceiling Fan Assembly (Motor, Blades, Light Kit)
- Downrod (19.6 inches)
- Mounting Hardware Kit
- Remote Control
- Instruction Manual

4. Setup and Installation

Professional installation is recommended for safety and optimal performance. Ensure power is disconnected at the circuit breaker before beginning installation.

Required Tools (Not Included):

- Phillips screwdriver
- Flathead screwdriver
- Adjustable wrench
- Wire strippers

- Electrical tape
- Ladder

Installation Steps:

1. **Turn Off Power:** Locate the circuit breaker for the fan location and turn off the power. Verify power is off using a voltage tester.
2. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling outlet box. Ensure the outlet box is rated for ceiling fan support (at least 35 lbs).
3. **Downrod Assembly:** Insert the downrod through the canopy and coupling. Secure the downrod to the fan motor assembly with the provided pin and screw.
4. **Wiring:** Carefully lift the fan assembly and hang it from the mounting bracket. Connect the electrical wires (live, neutral, ground) from the fan to the corresponding wires from the ceiling outlet box using wire nuts. Ensure all connections are secure.
5. **Secure Canopy:** Tuck the wires into the outlet box and slide the canopy up to the mounting bracket. Secure the canopy with the screws provided.
6. **Install Light Bulbs:** Screw in eight E12 base LED bulbs (max 9W each) into the light sockets.
7. **Restore Power:** Turn the power back on at the circuit breaker.

5. Operating Instructions

The Bella Depot ceiling fan is controlled by the included remote control. Ensure the remote has fresh batteries installed.



Figure 5.1: Fan dimensions and remote control functions.

Remote Control Functions:

- **Light ON/OFF:** Press the light bulb button to turn the chandelier lights on or off.
- **Fan OFF:** Press the fan power button to turn the fan off.
- **Fan Speed (1-6):** Use the numbered buttons (1-6) to select the desired fan speed. 1 is the lowest speed, 6 is the highest.
- **Timer (1H/2H/4H):** Press the timer buttons (1H, 2H, 4H) to set the fan to automatically turn off after the selected duration.
- **Reversible Function:** Press the reversible button (usually indicated by two arrows) to change the direction of

the fan blades.



Figure 5.2: Reversible function for year-round comfort. Downward airflow for summer cooling, upward airflow for winter warmth.

Fan Speed Recommendations:

- **Speed 1-2 (Low):** Ideal for sleeping or gentle air circulation.
- **Speed 3-4 (Medium):** Suitable for working or moderate airflow.
- **Speed 5-6 (High):** Provides strong cooling wind for active periods.



Figure 5.3: Recommended fan speed settings for various activities.

Quiet Operation:

The fan's DC motor operates at a low noise level, typically below 35 decibels, ensuring a quiet environment.

Figure 5.4: The fan's ultra-quiet operation (below 35dB) and timer settings.

6. Maintenance

Regular maintenance helps ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these

may damage the finish. Ensure power is off before cleaning.

- **Bulb Replacement:** Always turn off power at the circuit breaker before replacing bulbs. Allow bulbs to cool completely before touching. Replace with E12 base LED bulbs, maximum 9W each.
- **Tighten Fasteners:** Periodically check all screws and fasteners on the fan and mounting hardware to ensure they are secure.

7. Troubleshooting

If you experience issues with your fan, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low or not paired.	Check circuit breaker; Verify all wire connections are secure; Replace remote battery or re-pair remote.
Light does not work	Bulbs are faulty or loose; No power to the light kit; Loose wire connections.	Replace or tighten bulbs; Check circuit breaker; Verify light kit wiring.
Fan wobbles	Loose mounting screws; Unbalanced blades; Downrod not seated correctly.	Ensure mounting bracket and downrod screws are tight; Check for bent blades; Re-seat downrod.
Remote control not working	Low battery; Remote not paired with fan; Obstruction between remote and receiver.	Replace battery; Follow pairing instructions (if applicable); Ensure clear line of sight.

8. Specifications

Detailed specifications for the Bella Depot 36-inch Farmhouse Ceiling Fan with Light.

Feature	Detail
Brand	Bella Depot
Model Number	B0GFTB96NF
Product Dimensions	36"D x 36"W x 21.7"H
Color	Wood Grain
Style	Farmhouse
Material	Metal
Electric Fan Design	Ceiling Fan
Power Source	DC
Mounting Type	Downrod Mount (19.6" fixed downrod)

Feature	Detail
Controller Type	Remote Control
Number of Speeds	6
Noise Level	35 Decibels (max)
Wattage	65 watts
Number of Blades	5
Light Sockets	8 x E12 (max 9W LED each, bulbs not included)
Special Features	Integrated Chandelier, Ultra-Quiet DC Motor, Reversible, Remote Control with Timer (1H/2H/4H)
Included Components	Hardware, Remote Control




Figure 8.1: Energy efficiency of the DC motor.

9. Warranty and Support

Bella Depot stands behind the quality of its products. For specific warranty details, please refer to the warranty card included with your purchase or contact Bella Depot customer service.

For technical support, replacement parts, or any questions regarding your Bella Depot 36-inch Farmhouse Ceiling Fan with Light, please visit the official Bella Depot store or contact their customer support team.

Bella Depot Store: https://www.amazon.com/stores/BellaDepotInc/page/827ED4E8-A75B-4262-BC37-E2AAA42181C5