

Sweetcrispy SW-SLGWL-6WT-1

Sweetcrispy Plastic Dog Playpen

MODEL: SW-SLGWL-6WT-1 (6-PANEL, 24-INCH)

Instruction Manual

[Contents](#) [Introduction](#) [Assembly](#) [Operation](#) [Safety Information](#) [Maintenance](#) [Package Specifications](#) [Support](#)

1. Introduction

Thank you for choosing the Sweetcrispy Plastic Dog Playpen. This versatile playpen is designed to provide a safe and comfortable space for small to medium-sized pets, including puppies and small dogs weighing up to 44 lbs. Its expandable design allows for flexible configurations, suitable for both indoor and outdoor use. Please read this manual thoroughly before assembly and use to ensure proper setup and pet safety.



Figure 1: Sweetcrispy Plastic Dog Playpen in a typical indoor setup.

2. Safety Information

To ensure the safety of your pet and household, please observe the following precautions:

- Always supervise your pet while they are in the playpen, especially during initial use.
- Ensure all panels are securely connected and the door locking mechanisms are engaged before leaving your pet unattended.
- Do not use the playpen on uneven surfaces. For outdoor use, utilize the provided ground pegs for added stability.
- Keep the playpen away from open flames, heat sources, and electrical outlets.
- Regularly inspect the playpen for any damage or loose parts. Discontinue use if any components are broken or compromised.
- The bar spacing is 4cm apart to prevent pets' heads from getting stuck. Ensure your pet's size is appropriate for this spacing.
- Prolonged outdoor exposure may affect the material's durability. Consider temporary outdoor use.

3. Package Contents

Verify that all components are present before beginning assembly:

- Dog Playpen Panels (6 panels for this model)
- User Manual (this document)
- Suction Cups (2 per panel for indoor use)
- Ground Pegs (7 for 6-panel sets for outdoor use)

4. Assembly Instructions

The Sweetcrispy Dog Playpen features an effortless snap-lock joint system for quick installation without

tools.

1. **Unpack Components:** Carefully remove all panels and accessories from the packaging.
2. **Connect Panels:** Align the snap-lock joints of two panels. Push down firmly until they click into place, ensuring a secure connection. Repeat this process to connect all 6 panels, forming your desired shape (e.g., hexagon, square).
3. **Install Door Panel:** Integrate the panel with the door into your desired configuration. Ensure the door opens and closes smoothly.
4. **Secure for Indoor Use:** For smooth indoor surfaces, attach the provided suction cups to the bottom of each panel. Press down to create a vacuum, preventing movement.
5. **Secure for Outdoor Use:** For outdoor use on grass or soil, insert the ground pegs through the designated holes at the bottom of the panels and push them firmly into the ground.




Figure 2: Visual guide for connecting panels and securing the playpen.



Figure 3: Example of a 6-panel playpen configuration.

Video 1: Sweetcrispy Plastic Dog Pen Assembly Guide. This video demonstrates the assembly process and features of the playpen.

5. Operating Instructions

5.1. Using the Secure Locking Door

The playpen features a sliding lock system designed to be resistant to pet tampering, ensuring your pet remains safely inside. The small door allows for easy entry and exit without needing to lift your pet.

- To open the door: Slide the top and bottom latches to the unlocked position.
- To close and secure the door: Close the door panel and slide both latches into the locked position until they click.



Lockable Door Rail

Enables easy opening and closing, while securely preventing pets from unlocking it.



Figure 4: Detail of the secure sliding lock on the playpen door.

5.2. Indoor and Outdoor Use

The playpen is designed for versatile use:

- **Indoor:** Utilize the suction cups on smooth floors to prevent sliding and wobbling.
- **Outdoor:** Use the ground pegs to anchor the playpen securely on grass or soil.




Figure 5: Indoor stability with suction cups and outdoor stability with ground pegs.

5.3. Space-Saving Design

Each panel is approximately 2cm thick, allowing for compact storage when disassembled. The lightweight design facilitates quick disassembly and portability.

6. Maintenance

To maintain the longevity and cleanliness of your playpen:

- **Cleaning:** Wipe down panels with a damp cloth and mild soap. Rinse thoroughly and dry completely before reassembly or storage. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, disassemble the playpen and store it in a cool, dry place away from direct sunlight to prevent material degradation.
- **Inspection:** Periodically check all connections and locking mechanisms for wear and tear.

7. Troubleshooting

If you encounter any issues with your Sweetcrispy Dog Playpen, refer to the following common solutions:

- **Playpen is unstable:** Ensure all panels are securely snapped together. For indoor use, verify suction cups are properly engaged on a clean, smooth surface. For outdoor use, ensure ground pegs are fully inserted into the soil.
- **Door not locking:** Check that the door panel is correctly aligned with the adjacent panels and that both sliding latches are fully engaged.
- **Difficulty connecting panels:** Ensure the snap-lock joints are aligned correctly. Apply firm, even pressure until a click is heard. Avoid forcing connections.

8. Specifications

Brand	Sweetcrispy
Model Number	SW-SLGWL-6WT-1
Material	Plastic
Color	White
Product Dimensions (L x W x H)	69.29" x 35" x 23.62"
Number of Panels	6
Closure Type	Latch
Assembly Required	Yes

9. Warranty and Support

For warranty information, product support, or to report any issues, please contact Sweetcrispy customer service through the retailer where the product was purchased. Please have your model number (SW-SLGWL-6WT-1) and purchase date available when contacting support.