



Manuals.plus /

› GRUSIGN /

› GRUSIGN 71" Pantry Cabinet with Charging Station Instruction Manual

GRUSIGN BG-CF-BLK

GRUSIGN 71" Pantry Cabinet with Charging Station

INSTRUCTION MANUAL

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your GRUSIGN 71" Pantry Cabinet with Charging Station. Please read carefully before beginning assembly or use. This large capacity kitchen hutch storage cabinet is designed to streamline your kitchen routine by keeping essentials neatly organized and visible. It features a built-in charging station, storage drawers, and adjustable shelves.



Figure 1: GRUSIGN 71" Pantry Cabinet with Charging Station.

2. Safety Information

- Always ensure the cabinet is stable and properly assembled before use.
- Do not overload shelves or the countertop. The countertop supports up to 90 lbs, and adjustable shelves handle 11 lbs each.
- Keep the charging station dry and free from debris.
- Unplug the charging station when not in use or during cleaning.
- Utilize the anti-tipping device to secure the cabinet to the wall, preventing accidental tipping.
- Keep small parts away from children during assembly to prevent choking hazards.

3. Package Contents

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer service.

- Cabinet Panels (various sizes)

- Doors (with pre-drilled hinge holes)
- Drawers (with pre-installed glides)
- Adjustable Shelves
- Hardware Pack (screws, dowels, cam locks, hinges, handles, etc.)
- Charging Station Unit (2 AC outlets, 1 USB, 1 Type-C port)
- Anti-Tipping Device
- Assembly Guide

4. Setup (Assembly Instructions)

Assembly is required for this product. Please follow the detailed, step-by-step instructions provided in the separate assembly guide included with your product. All necessary tools for assembly are included in the hardware pack. Due to the furniture's size, assembly may take some time. It is recommended to have two people for assembly.

A detailed assembly video may also be available on the product page for visual guidance. For any installation questions, our customer service team guarantees a reply within 24 hours.



Figure 2: Cabinet Dimensions and Internal Layout.



Figure 3: Anti-Tipping Device Installation.

5. Operating Instructions

5.1 Adjustable Shelves

The cabinet features customizable 3-level shelving in both the upper and lower sections. To adjust a shelf, carefully remove it from its current position by lifting it off the support pegs. Reinsert the shelf into the desired peg holes, ensuring it is level and securely seated before placing items on it. This allows for personalized storage to accommodate items of various sizes.



Figure 4: Adjustable Shelves for Customized Storage.

5.2 Storage Drawers

The smooth-gliding drawers are designed for easy access to cutlery, utensils, and other smaller kitchen items. Pull gently on the handle to open and push firmly to close. Avoid forcing the drawers, as this may damage the glides.



Figure 5: Smooth-Gliding Storage Drawer.

5.3 Charging Station

The built-in charging station is located on the countertop level and features 2 AC outlets, 1 USB port, and 1 Type-C port. Use these to conveniently power small kitchen appliances like coffee makers or microwaves, or to charge electronic devices. Ensure that the total power draw of connected devices does not exceed the station's rated capacity. Always unplug devices when not in use.




Figure 6: Integrated Charging Station.

6. Maintenance

6.1 Cleaning

To clean the cabinet surfaces, use a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or solvents, as these may damage the finish. For stubborn stains, a mild soap solution can be used, followed by wiping with a clean, dry cloth.

6.2 Surface Care

The cabinet is constructed from high-quality manufactured wood with surfaces designed to be oil-resistant, stain-resistant, and scratch-proof. While durable, it is recommended to promptly wipe up any spills to maintain the cabinet's appearance and integrity over time. Use coasters under hot items to prevent heat damage.



Figure 7: Cabinet Durability Features.

7. Troubleshooting

7.1 Door Alignment Issues

If the cabinet doors appear misaligned, have large gaps, or rub against the frame, this is typically not a product quality problem. These issues can be easily fixed without re-assembly by adjusting the tension of the four screws on the hinges. Refer to the detailed instructions in the assembly manual for specific hinge adjustment procedures. Video tutorials on the product page may also provide visual guidance for this adjustment.

7.2 Cabinet Instability

If the cabinet feels wobbly after assembly, ensure all screws and fasteners are securely tightened. Verify that the anti-tipping device is correctly installed and anchored to a wall stud. Ensure the cabinet is placed on a level surface.

8. Specifications

Brand	GRUSIGN
Model Name	BG-CF-BLK
Color	Black
Material	Engineered Wood, Metal
Product Dimensions	15"D x 41.3"W x 71"H
Item Weight	111 Pounds
Weight Limit (Countertop)	90 Pounds
Weight Limit (Adjustable Shelves)	11 Pounds (each)
Number of Shelves	4
Special Features	Adjustable Shelf, Anti-Tipping, Built-In Charging Station, Heavy Duty, Scratch Resistant
Charging Station	2 AC outlets, 1 USB, 1 Type-C port
Assembly Required	Yes

9. Warranty and Support

For any questions regarding assembly, operation, or if you encounter any issues with your GRUSIGN 71" Pantry Cabinet, please do not hesitate to contact our customer service team. We are committed to providing prompt assistance and guarantee a reply within 24 hours.

Extended protection plans may be available for your product. Please refer to your purchase documentation or contact your retailer for details on available warranty and support options.