

BXQ 165jin

BXQ Dog Bark Collar Model 165jin User Manual

Effective and Humane Bark Control for Your Dog

	Introduction	Safety Information	Package Contents	Product
Overview	Setup	Operation	Maintenance	Troubleshooting
				Specifications

1. INTRODUCTION

Thank you for choosing the BXQ Dog Bark Collar Model 165jin. This device is designed to help manage and reduce excessive barking in dogs through a combination of beep, vibration, and static shock modes. It features adjustable sensitivity and intensity levels, an automatic anti-barking system, and a durable, waterproof design. Please read this manual thoroughly before use to ensure proper and safe operation for your pet.

2. IMPORTANT SAFETY INFORMATION

- **Not for Aggressive Dogs:** Do not use this product on aggressive dogs. If your dog exhibits aggressive behavior, consult a professional dog trainer or veterinarian.
- **Proper Fit is Crucial:** Ensure the collar fits snugly but not too tightly. Two fingers should fit comfortably between the collar and your dog's neck. Improper fit can lead to skin irritation or ineffective operation.
- **Avoid Prolonged Wear:** Do not leave the collar on your dog for more than 12 hours per day. Prolonged wear can cause pressure necrosis (bed sores) on the skin.
- **Regular Inspection:** Check your dog's neck daily for any signs of skin irritation, redness, or sores. If irritation occurs, discontinue use until the skin heals.
- **Supervision:** Always supervise your dog when the collar is in use, especially during initial training.
- **Age and Health:** This collar is suitable for dogs over 8 lbs and with neck sizes between 7-26 inches. Do not use on puppies under 6 months old or dogs with health issues. Consult your veterinarian if unsure.
- **Water Safety:** While the collar is IP65 waterproof, ensure the charging port cover is securely closed before exposing it to water.

3. PACKAGE CONTENTS

Upon opening your BXQ Dog Bark Collar package, you should find the following items:

- BXQ Bark Collar Unit

- Adjustable Nylon Collar Strap
- USB-C Charging Cable
- Test Light Tool
- User Manual

4. PRODUCT OVERVIEW

The BXQ Dog Bark Collar is designed with user-friendly controls and a comfortable fit for various dog sizes.

Suitable for Most Size of Dogs

Adjustable Strap for Dogs(8-130lbs)



8lbs

23inch

130lbs

Image: The BXQ Dog Bark Collar unit attached to an adjustable nylon strap, shown with various dog breeds from small to large, illustrating its suitability for dogs weighing 8-130 lbs and neck sizes 7-26 inches.

Collar Components:

- **Collar Unit:** The main device housing the electronics, display, and contact points.
- **Adjustable Strap:** Made of skin-friendly nylon, designed to fit neck sizes from 7 to 26 inches.
- **Contact Points:** Two metal prongs on the back of the unit that deliver vibration or static shock.
- **LED Display:** Shows sensitivity level, vibration level, shock level, and battery status.

- **Control Buttons:** Buttons for power, mode selection, and intensity adjustment.
- **USB-C Charging Port:** Located on the side of the unit, protected by a waterproof cover.

Anti-Interference Technique

Activated by your dog only, no more false trigger



Dog's Head
Shaking



Other Animal's
Barking



Other
Noise



Image: A detailed view of the BXQ Dog Bark Collar unit, highlighting the metal contact points on the underside and the control buttons on the top surface, along with the digital display.

5. SETUP

5.1 Charging the Collar

1. Locate the USB-C charging port on the side of the collar unit.
2. Open the waterproof rubber cover.
3. Connect the provided USB-C cable to the collar and a suitable USB power source (e.g., wall adapter, computer, power bank).
4. The LED display will indicate charging status. A full charge typically takes about 2 hours.
5. Once fully charged, disconnect the cable and securely close the waterproof cover to maintain IP65 rating.

New Upgraded Design

More Smart, More Humane



7 Sensitivity Levels



Battery Indicator



Beep Mode



Auto-protection Mode



Vibration Mode (7 Level)



Secure wrist strap



Static Shock Mode (7 Level)

Image: The BXQ Dog Bark Collar connected to a USB-C charging cable, demonstrating the charging process. The image also highlights the collar's long battery life of up to 15 days on a single charge.

5.2 Attaching the Strap and Fitting the Collar

1. Thread the nylon strap through the slots on the collar unit.
2. Place the collar around your dog's neck, ensuring the contact points are positioned directly on the dog's skin, beneath the throat.
3. Adjust the strap for a snug fit. You should be able to fit two fingers comfortably between the collar and your dog's neck. The collar should not be too loose, as this can cause rubbing or prevent proper contact.
4. Trim any excess strap length if necessary, and use the provided buckle to secure it.

6. OPERATING INSTRUCTIONS

6.1 Powering On/Off

- **To Power On:** Press and hold the power button until the LED display illuminates.

- **To Power Off:** Press and hold the power button until the LED display turns off.

6.2 Adjusting Sensitivity

The collar has 7 sensitivity levels (1-7) to detect barking. A higher number means higher sensitivity (detects softer barks). Adjust this based on your dog's barking volume and environmental noise.

- Press the sensitivity button (usually marked with an 'S' or a gear icon) to cycle through the levels.
- Start with a lower sensitivity level and increase it if the collar is not activating when your dog barks.

6.3 Selecting Training Modes

The BXQ Bark Collar offers 4 training modes and 7 intensity levels for vibration and static shock.

4 Humanized Training Modes

Stop Barking More Scientific and Easier



No Shock Modes

- 1  Beep
- 2  + 
Beep Vibration

Shock Modes

- 1  + 
Beep + Shock
- 2  +  + 
Beep + Vibration + Shock

Please set to Level 0
if you don't wanna shock your dog.

Image: A visual representation of the four training modes: Beep, Beep + Vibration, Beep + Shock, and Beep + Vibration + Shock. It also advises setting the shock level to 0 if no shock is desired.

1. No Shock Modes:

- **Beep Only:** The collar emits an audible beep when barking is detected.
- **Beep + Vibration:** The collar emits a beep followed by a vibration. Vibration intensity can be adjusted from level 1-7.

2. Shock Modes:

- **Beep + Shock:** The collar emits a beep followed by a static shock. Shock intensity can be adjusted from level 1-7.
- **Beep + Vibration + Shock:** The collar emits a beep, then a vibration, followed by a static shock. Both vibration and shock intensities are adjustable from level 1-7.

To adjust vibration or shock intensity, press the corresponding button (Vibration or Shock) and then use the up/down buttons to select the desired level (1-7). If you do not wish to use the static shock feature, ensure the shock level is set to 0.

6.4 Anti-Interference Technology

The BXQ Bark Collar incorporates an upgraded smart dog barking recognition chip. This technology helps filter out other dogs' barking or environmental noises, ensuring the collar only activates in response to your dog's specific bark. This reduces false triggers and provides more effective training.

IP65 Waterproof

It can be used outdoors in any weather.



Raining



Bathing



Swimming

Image: A visual demonstrating the collar's anti-interference technique, showing that it is activated only by the dog wearing it, not by other dogs barking, dog's head shaking, or other ambient noises.

6.5 Automatic Protection Mode

For your dog's safety, the BXQ Bark Collar includes an automatic protection mode. If the collar triggers more than 7 times within a 30-second period, it will temporarily stop working for 2 minutes. During this time, the digital display will show "E". This prevents over-correction and allows your dog a brief respite.

6.6 Testing the Shock Function (Optional)

A test light tool is included to verify the static shock function. Place the test light across the two contact points. Blow into the microphone hole on the collar unit. If the shock function is active, the test light will illuminate, indicating the static shock is working.

Your browser does not support the video tag.

Video: A demonstration of the BXQ Dog Bark Collar's features, including its fit on a small dog, the adjustable strap, USB-C charging, and how to test the shock function using the provided test light. The video also highlights the adjustable vibration, shock, and sensitivity levels.

7. MAINTENANCE

7.1 Cleaning the Collar

- Regularly clean the collar unit and strap with a damp cloth.
- Ensure the contact points are clean and free of dirt or debris to maintain proper function.
- Do not use harsh chemicals or abrasive cleaners.

7.2 Battery Care

- Charge the collar fully before first use.
- Recharge the collar when the battery indicator shows low power.
- For optimal battery life, avoid completely draining the battery frequently.

7.3 Waterproof Rating (IP65)

The BXQ Bark Collar is rated IP65 waterproof, meaning it is protected against low-pressure water jets from any direction and is dust-tight. This allows your dog to wear it during activities like swimming, bathing, or playing in the rain, provided the charging port cover is securely sealed.

Automatic Bark Control

Turn it on, just enjoy quiet home time, have a peaceful sleep or calm walks.



Image: A Golden Retriever enjoying a swim while wearing the BXQ Dog Bark Collar, illustrating the product's IP65 waterproof capability, suitable for use in various wet conditions like rain, bathing, and swimming.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Collar not activating when dog barks.	Low sensitivity setting; improper fit; low battery.	Increase sensitivity level; ensure contact points touch skin; charge battery.
Collar activating too frequently (false triggers).	High sensitivity setting; environmental noise; other dogs barking.	Decrease sensitivity level; ensure anti-interference is functioning.
Collar not charging.	Loose cable connection; faulty cable/adapter; dirty charging port.	Check connections; try a different cable/adapter; clean charging port.

Problem	Possible Cause	Solution
Skin irritation on dog's neck.	Collar too tight; prolonged wear; dirty contact points.	Loosen collar slightly; remove collar for several hours daily; clean contact points and dog's neck. Consult a vet if irritation persists.
Collar displays "E".	Automatic protection mode activated.	The collar has paused for 2 minutes due to excessive activation. It will resume automatically.

9. SPECIFICATIONS

- **Model Number:** 165jin
- **Brand:** BXQ
- **Training Modes:** Beep, Beep+Vibration, Beep+Shock, Beep+Vibration+Shock
- **Sensitivity Levels:** 7 levels adjustable
- **Vibration/Shock Levels:** 7 levels adjustable
- **Battery Type:** 1 Nonstandard Battery (included)
- **Charging Time:** Approximately 2 hours
- **Usage Time:** Up to 15 days (depending on usage)
- **Waterproof Rating:** IP65
- **Suitable for Dogs:** 8-120 lbs
- **Neck Size Range:** 7-26 inches
- **Package Dimensions:** 3.78 x 3.07 x 2.24 inches
- **Item Weight:** 3.84 ounces

10. WARRANTY AND SUPPORT

For warranty information, product support, or any questions regarding your BXQ Dog Bark Collar, please refer to the contact information provided with your purchase or visit the official BXQ store on Amazon. We are committed to providing safe and effective products for dog training.

Amazon Store Link: [Visit the BXQ Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GG9PXXPV>

More documents and user manuals: <https://manuals.plus/>