

manuals.plus /

- › [Garvee](#) /
- › [Garvee Under Desk Printer Stand Instruction Manual](#)

Garvee BYhz7UNeoNtFyL4KplqF6Qz2gubw

Garvee Under Desk Printer Stand Instruction Manual

Model: BYhz7UNeoNtFyL4KplqF6Qz2gubw

1. INTRODUCTION

Thank you for choosing the Garvee Under Desk Printer Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new printer stand. Please read these instructions carefully before use and retain them for future reference.



Figure 1: The Garvee Under Desk Printer Stand, designed for home and office use.

2. SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the stand on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly, as this may damage the material.
- Distribute weight evenly on the shelves. Do not exceed the maximum weight capacity of the stand.
- Keep small parts away from children to prevent choking hazards.
- Always lock the casters when the stand is in a stationary position to prevent accidental movement.

3. PACKAGE CONTENTS

Verify that all components listed below are included in your package:

- Top Shelf (1)
- Bottom Shelf (1)

- Side Frames (2)
- X-shaped Crossbeams (2)
- Rolling Casters (4, 2 with locks)
- Assembly Hardware (Screws, Allen Wrench)
- Instruction Manual (1)

4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Garvee Under Desk Printer Stand:

1. **Attach Casters:** Insert the four rolling casters into the pre-drilled holes at the bottom of the side frames. Ensure two lockable casters are placed on the front side for easy access. Tighten securely.
2. **Assemble Frame:** Connect the two side frames using the X-shaped crossbeams at the back. Secure them with the provided screws and Allen wrench. Do not fully tighten yet.
3. **Install Bottom Shelf:** Place the bottom shelf onto the lower supports of the assembled frame. Secure it with screws, ensuring it is level.
4. **Install Top Shelf:** The top shelf is height-adjustable. Align the top shelf with your desired height setting on the side frames (there are 5 adjustable positions). Secure it with screws.
5. **Final Tightening:** Once all components are in place and aligned, fully tighten all screws.

PRODUCT DIMENSIONS




Figure 2: Product dimensions for assembly reference. Overall dimensions are approximately 21.5" L x 20" W x 22.4" H.



UNDER DESK PRINTER STAND

Figure 3: The top shelf offers 5 adjustable height positions for versatile storage.



Figure 4: Detail of the stand's sturdy construction, smooth rounded edges, elegant wood grain finish, and four rolling casters.

5. OPERATING INSTRUCTIONS

The Garvee Under Desk Printer Stand is designed for convenient use in your home or office.

5.1 Placing Equipment

Place your printer, scanner, or other office equipment on the top shelf. The bottom shelf can be used for storing paper, ink cartridges, or other supplies. Ensure the weight is distributed evenly.

5.2 Adjusting Shelf Height

To adjust the height of the top shelf, loosen the screws securing it to the side frames. Carefully lift or lower the shelf to one of the 5 available positions, then re-tighten the screws firmly.

5.3 Moving the Stand

Unlock the two front casters to move the stand. Guide the stand to your desired location. Once positioned, lock both front casters to secure the stand and prevent unwanted movement.



Figure 5: The stand features 360-degree rotating casters for easy movement and lockable brakes for stability.

5 ADJUSTABLE HEIGHTS



Figure 6: The Garvee printer stand fits conveniently under most desks, optimizing workspace.

6. MAINTENANCE

To ensure the longevity and appearance of your printer stand:

- **Cleaning:** Wipe the surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Caster Care:** Keep the casters free of debris (hair, dust) to ensure smooth movement.

7. TROUBLESHOOTING

Issue: Stand is wobbly or unstable.

Solution: Ensure all screws are fully tightened. Check that the stand is on a level surface. Redistribute items on the shelves if weight is unevenly distributed.

Issue: Casters do not roll smoothly.

Solution: Check for any debris (e.g., hair, dust) caught in the caster wheels and remove it. Ensure the casters are not locked.

Issue: Shelf height adjustment is difficult.

Solution: Loosen the screws sufficiently before attempting to adjust the shelf. Ensure the shelf is lifted slightly to clear the adjustment pins before moving it to a new position.

8. SPECIFICATIONS

Product Dimensions	21.5 x 20 x 22.4 inches (L x W x H)
Item Weight	21.2 pounds
Material	Particle Board (Desktop), Steel (Frame)
Color	Black
Shelves	2 Tiers, Top Shelf Height Adjustable (5 positions)
Mobility	4 Rolling Casters (2 lockable)

9. WARRANTY & SUPPORT

Garvee products are manufactured with quality and durability in mind. While specific warranty details are not provided in this manual, please refer to your purchase documentation or contact the retailer for information regarding warranty coverage.

For any questions, missing parts, or assistance with assembly or operation, please contact Garvee customer support through the retailer's platform or the official Garvee website.