



[Manuals.plus](#) /

> [vidaXL](#) /

> vidaXL Black Cabinet with Shelf (Model 42026912) Instruction Manual

vidaXL 42026912

vidaXL Black Cabinet with Shelf (Model 42026912)

Instruction Manual

1. INTRODUCTION

Thank you for purchasing the vidaXL Black Cabinet with Shelf. This cabinet is designed to provide a stylish and practical storage solution for both indoor and outdoor environments. Constructed from durable polyester rattan with a sturdy steel frame and an acacia wood top, it offers weather resistance and ample storage space. Please read this manual carefully before assembly and use to ensure proper installation and longevity of your product.



Image: The vidaXL Black Cabinet with Shelf, showcasing its design and functionality in an outdoor patio setting.

2. SAFETY INFORMATION

- Always assemble the cabinet on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten if necessary.
- Do not overload the shelves or cabinet top.
- Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- Avoid climbing or standing on the cabinet.
- Place the cabinet on a level surface to prevent tipping.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Cabinet panels (sides, back, bottom, top)
- Acacia wood top panel
- Internal shelves (2)
- Cabinet doors (2)
- Door hinges and magnetic closures
- Assembly hardware (screws, bolts, nuts, washers, Allen key)
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly is required for this cabinet. It is recommended that two people assemble the unit to ensure stability and ease of construction. Please follow the steps below carefully.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a soft, clean surface. Refer to the parts list to identify each piece.
2. **Assemble the Frame:** Connect the side panels to the back panel using the provided hardware. Ensure all connections are snug but do not overtighten initially.
3. **Install Bottom and Top Panels:** Attach the bottom panel to the assembled frame. Then, place the acacia wood top panel onto the frame, securing it with the appropriate screws.
4. **Insert Shelves:** Position the internal shelves at the desired height. Secure them using the shelf supports or designated fasteners.
5. **Attach Doors:** Mount the hinges to the cabinet doors and then attach the doors to the main cabinet frame. Ensure the doors swing freely and align correctly.
6. **Install Magnetic Closures:** Attach the magnetic closures to the inside of the cabinet and the corresponding plates to the doors to ensure they close securely.
7. **Final Tightening:** Once all components are in place and aligned, carefully tighten all screws and bolts. Avoid overtightening to prevent damage.




Image: Dimensional diagram of the cabinet, illustrating overall size and internal shelf spacing for assembly reference.

Ample Storage Space




Image: An internal view of the cabinet, highlighting its storage compartments and magnetic door closures.

5. OPERATING INSTRUCTIONS

The vidaXL Black Cabinet with Shelf is designed for straightforward use.

- **Opening/Closing Doors:** Gently pull the handles to open the doors. The magnetic closures will hold them shut when closed.
- **Storage:** Utilize the open top compartment for frequently accessed items or decorative displays. The two lower shelves, enclosed by doors, are suitable for storing items that require protection from elements or a tidier appearance.
- **Placement:** This cabinet is suitable for various indoor and outdoor settings, including gardens, patios, porches, balconies, and backyards. Ensure it is placed on a stable, level surface.

Wide Applications

Suitable for both indoor and outdoor settings



Perfect for garden, patio, porch, balcony, lawn, pool area, and backyard

Image: The cabinet displayed in different outdoor environments, illustrating its adaptability for various uses.

6. MAINTENANCE

Proper maintenance will extend the life and appearance of your cabinet.

- **Cleaning:** Wipe the rattan surfaces with a damp cloth and mild soap. Rinse with clean water and dry thoroughly. For the acacia wood top, use a soft cloth and a wood-friendly cleaner. Avoid harsh chemicals or abrasive materials.
- **Wood Top Care:** The acacia wood top has a natural oil finish. To maintain its appearance and weather resistance, it is recommended to re-oil the wood periodically, especially if used outdoors.
- **Weather Protection:** While the cabinet is weather-resistant, prolonged exposure to extreme weather conditions (heavy rain, snow, intense sun) may affect its longevity. Consider using a protective cover or storing it indoors during harsh seasons.
- **Hardware Check:** Periodically inspect all screws and connections to ensure they remain tight. Retighten if any looseness is detected.



Image: Detail of the woven PE rattan, illustrating the material's texture and quality.



Image: A detailed view of the acacia wood top and the surrounding rattan, showing the craftsmanship.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Doors do not close properly or are misaligned.	<ul style="list-style-type: none"> ◦ Hinges are loose or improperly installed. ◦ Magnetic closures are misaligned or weak. ◦ Cabinet is not on a level surface. 	<ul style="list-style-type: none"> ◦ Check and tighten all hinge screws. Adjust hinge position if necessary. ◦ Realign the magnetic closures and their corresponding plates. ◦ Move the cabinet to a level surface or use shims to stabilize it.
Cabinet feels wobbly or unstable.	<ul style="list-style-type: none"> ◦ Loose assembly screws. ◦ Uneven floor surface. 	<ul style="list-style-type: none"> ◦ Ensure all assembly screws and bolts are fully tightened. ◦ Place the cabinet on a level surface.

Problem	Possible Cause	Solution
Rattan appears faded or damaged.	<ul style="list-style-type: none"> ◦ Prolonged exposure to direct sunlight or harsh weather. 	<ul style="list-style-type: none"> ◦ Relocate the cabinet to a shaded area or use a protective cover when not in use. ◦ Regular cleaning and care can help maintain its appearance.

8. SPECIFICATIONS

Feature	Detail
Model Number	42026912
Color	Black
Dimensions (L x W x H)	70 x 50 x 87 cm (27.6" x 19.7" x 34.3")
Item Weight	12.8 Kilograms
Material	Polyester Rattan, Powder-coated Steel Frame, Acacia Wood Top
Assembly Required	Yes
Country of Origin	China

9. WARRANTY AND SUPPORT

vidaXL products are designed for quality and durability. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official vidaXL website. If you encounter any issues or have questions about your product, please contact vidaXL customer support through their website or the retailer where you purchased the item.

Online Support: www.vidaxl.com/customer-service