

[Manuals.plus](#) /

› [Skip Hop](#) /

› Skip Hop Farmstand See & Bee Steering Wheel Instruction Manual

Skip Hop 9T4687101

Skip Hop Farmstand See & Bee Steering Wheel Instruction Manual

Model: 9T4687101

PRODUCT OVERVIEW

The Skip Hop Farmstand See & Bee Steering Wheel is a developmental baby toy designed to support tummy time milestones and seated play. This interactive toy features a unique 2-way tilt steering wheel that adjusts to accommodate your baby's developmental stage, from 3 months and up. It includes engaging bee-inspired activities, a baby mirror for self-recognition, music, and fun sound effects to encourage exploration and learning.

- **2-in-1 Design:** Easily adjusts for tummy time or seated play.
- **Developmental Benefits:** Encourages core, neck, and motor skill development.
- **Interactive Features:** Includes a bouncy bee rattle, click-clack bee, honeycomb spinner, and musical flower button.
- **Sensory Engagement:** Features a baby mirror, 3 sound effects, and 3 playful songs, including "Flight of the Bumblebee."



Image: A baby engaging with the Farmstand See & Bee Steering Wheel while sitting, demonstrating active play.

SAFETY INFORMATION

- Always use this product under adult supervision.
- Inspect the toy before each use. Discard if any part is damaged or broken.
- Keep all packaging materials away from children to prevent choking hazards.
- Do not leave children unattended with the toy.
- This toy is intended for children aged 3 months to 60 months.

PACKAGE CONTENTS

- 1 x Skip Hop Farmstand See & Bee Steering Wheel

SETUP

The Farmstand See & Bee Steering Wheel is designed for two stages of play: tummy time and seated play. The steering wheel mechanism can be tilted to adjust for your baby's comfort and developmental stage.

1. **For Tummy Time (Stage 1):** Gently push the steering wheel down until it locks into a flat position. This allows your baby to interact with the toy while lying on their tummy, encouraging head lifting and reaching.
2. **For Seated Play (Stage 2):** Gently pull the steering wheel up until it locks into an upright position. This configuration is suitable for babies who can sit independently, allowing them to engage with the toy from a seated posture.

2 stages of play



STAGE 1:
tilt down for tummy time





STAGE 2: tilt up for seated play

Image: Visual guide demonstrating the two stages of play: tummy time (steering wheel tilted down) and seated play (steering wheel tilted up).

Adjustable steering wheel tilts up or down



Image: A close-up of a hand adjusting the tilt mechanism of the steering wheel, highlighting its flexibility.

OPERATING INSTRUCTIONS

The Farmstand See & Bee Steering Wheel offers multiple interactive elements to stimulate your baby's senses and encourage cause-and-effect learning.

- **Steering Wheel with Mirror:** The central steering wheel features a baby-safe mirror. Encourage your baby to look into the mirror for self-recognition and facial exploration.
- **Musical Flower Button:** Press the flower-shaped button to activate playful songs and sound effects.
- **Bouncy Bee Rattle:** Interact with the bee figure on the left side. It rattles and bounces when touched, providing auditory and tactile stimulation.
- **Click-Clack Bee:** The bee figure on the right side produces a click-clack sound when moved, engaging your baby's hearing.

- **Honeycomb Spinner:** Spin the textured honeycomb element for visual and tactile engagement.




Image: Diagram highlighting the various interactive components of the toy, including the mirror, musical flower, bee rattle, click-clack bee, and honeycomb spinner.

MAINTENANCE AND CARE

To ensure the longevity and hygiene of your Skip Hop Farmstand See & Bee Steering Wheel, follow these care instructions:

- Wipe clean with a damp cloth and mild soap.
- Do not immerse in water.
- Air dry thoroughly before storing.
- Avoid using harsh chemicals or abrasive cleaners.

TROUBLESHOOTING

If you encounter any issues with your toy, please refer to the following common solutions:

Problem	Solution
Toy not making sounds/music.	Ensure the musical flower button is pressed firmly. As this toy operates manually and does not require batteries, consistent interaction should produce sounds. Check for any obstructions.

Problem	Solution
Steering wheel not tilting smoothly.	Check for any debris or foreign objects obstructing the tilt mechanism. Ensure the mechanism is clean and free to move. Do not force the tilt.
Rattle or spinner not functioning.	Ensure there are no physical obstructions preventing movement. The toy is designed for manual operation.

SPECIFICATIONS

- **Brand:** Skip Hop
- **Model Number:** 9T4687101
- **UPC:** 197233841903
- **Dimensions:** 13.71 x 5.44 x 5.75 inches (L x W x H)
- **Item Weight:** 1.26 Pounds
- **Material Type:** Plastic, Resin, Acrylic, Fabric, Metal
- **Recommended Minimum Age:** 3 Months
- **Recommended Maximum Age:** 60 Months
- **Operation Mode:** Manual
- **Batteries Required:** No
- **Assembly Required:** No

WARRANTY AND SUPPORT

This product is covered by the manufacturer’s standard warranty. For detailed warranty information, product support, or to report any issues, please visit the official Skip Hop website or contact their customer service department. Keep your purchase receipt as proof of purchase.

Online Support: www.skiphop.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question