

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Garvee](#) /
- › [Garvee Tall Kitchen Pantry Cabinet with Charging Station User Manual](#)

Garvee Pantry_PHK_36HJNFWAe0s

Garvee Tall Kitchen Pantry Cabinet with Charging Station User Manual

Model: Pantry_PHK_36HJNFWAe0s

1. INTRODUCTION

Thank you for choosing the Garvee Tall Kitchen Pantry Cabinet with Charging Station. This manual provides important information regarding the safe assembly, operation, and maintenance of your new cabinet. Please read these instructions carefully before beginning assembly or use, and retain them for future reference.



Image 1.1: The Garvee Tall Kitchen Pantry Cabinet, featuring upper and lower storage, drawers, and a central countertop area.

2. SAFETY INFORMATION

Your safety is paramount. Please adhere to the following safety guidelines:

- **Anti-Tip Hardware:** Always secure the cabinet to the wall using the provided anti-tip hardware to prevent tipping. Failure to do so can result in serious injury or death. Follow the manufacturer's instructions for proper installation of the anti-tip device.
- **Weight Distribution:** Distribute weight evenly across shelves and drawers. Avoid placing heavy items on upper shelves to maintain stability.
- **Electrical Safety:** The built-in charging station is designed for standard household use. Do not overload the outlets. Ensure all connected devices are in good working condition and have appropriate power requirements. Keep liquids away from the charging station.

- **Assembly:** Assemble the unit on a soft, clean surface to prevent scratches. Ensure all fasteners are securely tightened before use. Periodically check and re-tighten fasteners as needed.
- **Children and Pets:** Keep children and pets away from the assembly area. Do not allow children to climb on or play with the cabinet.

3. COMPONENTS OVERVIEW

The Garvee Tall Kitchen Pantry Cabinet is designed with various storage solutions. Familiarize yourself with the main components:

- **Upper Storage Compartments:** Four enclosed compartments, some with glass panels, ideal for dishes or decorative items.
- **Thickened Spacious Desktop:** A central open area suitable for small appliances like a microwave or coffee maker.
- **Charging Station:** Integrated into the desktop area, featuring AC outlets and USB ports.
- **Large Drawers:** Two smooth-gliding drawers for utensils, linens, or other small items.
- **Lower Storage Compartments:** Four enclosed compartments providing ample space for larger kitchen essentials.



Image 3.1: Labeled diagram illustrating the various storage sections of the pantry cabinet.

4. SETUP AND ASSEMBLY

Basic assembly is required for this cabinet. Detailed instructions are provided within the product packaging. Please follow these instructions carefully for proper and safe assembly.

1. **Unpack Components:** Carefully unpack all parts and hardware. Verify that all components listed in the assembly guide are present and undamaged.
2. **Prepare Workspace:** Choose a clear, level, and soft surface for assembly to prevent damage to the cabinet parts and your flooring.
3. **Follow Step-by-Step Instructions:** Refer to the included assembly manual for detailed, illustrated steps. Ensure all screws, dowels, and connectors are correctly oriented and tightened.
4. **Install Anti-Tip Hardware:** Once the cabinet is fully assembled and in its final position, securely attach the anti-tip hardware to the wall as instructed. This is a critical safety step.

5. OPERATING INSTRUCTIONS

5.1 Using the Charging Station

The integrated charging station provides convenient power access for your kitchen appliances and mobile devices.

- **Power Connection:** Plug the cabinet's power cord into a standard wall outlet.
- **AC Outlets:** Use the two 120V/12A AC outlets for small kitchen appliances such as coffee makers, blenders, or toasters.
- **USB Ports:** Use the two 5V/2A USB ports to charge smartphones, tablets, or other USB-powered devices.
- **On-Off Switch:** The charging station includes an on-off switch. Ensure it is in the 'On' position for power delivery. Turn it 'Off' when not in use or during cleaning.



Image 5.1: Detail of the charging station with power specifications.

5.2 Using Drawers and Doors

- **Drawers:** The two large drawers feature smooth glides for easy opening and closing. Avoid forcing them if they feel stiff.
- **Doors:** The cabinet doors are equipped with hinges for smooth operation. Ensure they close completely to keep contents secure and dust-free.



Image 5.2: Open drawers demonstrating storage capacity.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your Garvee pantry cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or excessive moisture, which can damage the engineered wood finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten as necessary to maintain structural integrity.
- **Charging Station:** Keep the charging station free of dust and debris. Do not attempt to disassemble or repair the electrical components yourself.



Image 6.1: Details of the cabinet construction, including handles, drawer mechanism, feet, and wood finish.

7. TROUBLESHOOTING

If you encounter issues with your cabinet, refer to the following common solutions:

Problem	Possible Cause	Solution
Cabinet feels wobbly or unstable.	Loose fasteners; uneven floor; anti-tip hardware not installed.	Ensure all assembly fasteners are tightened. Adjust floor levelers if present, or place shims under the base. Install anti-tip hardware securely to the wall.
Drawers are difficult to open/close.	Overloaded drawer; debris in glides; misaligned glides.	Reduce drawer contents. Clean glides of any obstructions. Check assembly instructions for proper glide alignment.

Problem	Possible Cause	Solution
Charging station not providing power.	Power cord unplugged; charging station switch off; overloaded circuit.	Verify the cabinet's power cord is securely plugged into a working wall outlet. Ensure the charging station's on-off switch is in the 'On' position. Unplug some devices to check for overload.

8. SPECIFICATIONS

Feature	Detail
Brand	Garvee
Model Number	Pantry_PHK_36HJNWFWAe0s
Material	Engineered Wood
Product Dimensions (D x W x H)	15" x 47" x 71"
Item Weight	140.48 Pounds
Number of Drawers	2
Number of Shelves	1 (adjustable)
Special Feature	Built-In Charging Station (2 AC Outlets, 2 USB Ports)
Assembly Required	Yes



Image 8.1: Dimensional drawing of the pantry cabinet.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Garvee customer service through the retailer where the product was purchased. Keep your purchase receipt for warranty claims.