Minthouz MT-L018F

Minthouz MT-L018F Clip-On Rechargeable Fan

User Manual

1. Introduction

Thank you for choosing the Minthouz MT-L018F Clip-On Rechargeable Fan. This portable fan is designed to provide personal cooling with its versatile mounting options, long-lasting battery, and multiple speed settings. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. Safety Instructions

- Do not insert fingers or any objects into the fan grille when the fan is operating.
- Keep the fan away from water or other liquids to prevent electric shock.
- Do not disassemble or modify the fan. Repairs should only be performed by qualified personnel.
- Ensure the fan is placed on a stable surface or securely clipped to prevent it from falling.
- Keep out of reach of children.
- Use only the provided USB-C charging cable or a certified equivalent.
- Avoid exposing the fan to extreme temperatures or direct sunlight for prolonged periods.

3. Package Contents

- 1 x Minthouz Clip Desk Fan
- 1 x USB-C Cable

4. Product Features

- **8000mAh Battery Capacity:** Provides extended operating time, up to 32 hours depending on speed setting.
- **Digital Display Screen:** Shows current battery level for convenient monitoring.
- **5-Gear Wind Settings:** Includes Sleep, Natural, Cool, Strong, and Circulating modes to suit various preferences.
- **720° Rotation:** Allows for 360° horizontal and 360° vertical adjustment of the fan head.
- **3-in-1 Functionality:** Can be used as a clip-on fan, a desk fan, or hung using the integrated hook.
- **Low Noise Operation:** Operates quietly, between 25-40dB, suitable for various environments.
- **Remote Control:** Conveniently adjust settings from a distance.
- **USB-C Rechargeable:** Easy and fast charging via USB-C port.

5. Product Overview

Familiarize yourself with the components of your Minthouz fan.




Image: Overview of the Minthouz Clip-On Fan, highlighting the digital display, USB-C charging port, remote control, and gear button.



Image: Demonstrates the fan's versatility, showing it used on a table, clipped to a surface, and hung from a hook.

6. Setup and Installation

6.1 Positioning the Fan

The Minthouz fan offers three primary ways to position it:

- **Clip-On:** Use the strong spring clip to attach the fan to desks, shelves, strollers, or other surfaces. Ensure the surface is stable and the clip is securely fastened.
- **Desk Stand:** Place the fan on any flat surface using its stable base.
- **Hanging:** Utilize the integrated hook on the bottom of the clip to hang the fan from a rod, tent, or similar fixture.

6.2 Adjusting Rotation

The fan head supports 360° horizontal and 360° vertical rotation. Gently adjust the fan head to direct airflow as desired.

Note: If the fan head does not rotate smoothly or feels loose, check the screws located under the clip and adjust them slightly with a Philips screwdriver if necessary.

7. Operating Instructions

7.1 Power On/Off and Speed Control

The fan can be operated using the gear button on the fan or the included remote control.

- **To Turn On:** Press the gear button once or the power button on the remote. The fan will start at the lowest speed setting.
- **To Change Speed:** Press the gear button repeatedly or the speed adjustment buttons on the remote to cycle through the 5 wind modes: Sleep, Natural, Cool, Strong, and Circulating.
- **To Turn Off:** Long press the gear button for three seconds from any speed setting, or press the power button on the remote.



Image: Illustration of the five wind mode settings and their corresponding battery life durations.

7.2 Battery Level Indicator

The digital display screen on the fan shows the current battery percentage, allowing you to monitor power usage and know when to recharge.

8. Charging

The Minthouz fan is equipped with an 8000mAh rechargeable battery and charges via a USB-C port.

- Connect the provided USB-C cable to the charging port on the fan.
- Connect the other end of the USB-C cable to a compatible USB power adapter (not included) or a USB port on a computer.
- The digital display will show the charging status. A full charge typically takes approximately 5.5 hours.




Image: The fan being charged via USB-C, illustrating the 8000mAh battery and charging duration.

9. Maintenance

- **Cleaning:** Ensure the fan is turned off and unplugged before cleaning. Use a soft, dry cloth to wipe the exterior of the fan. For the fan blades, use a soft brush or compressed air to remove dust. Do not use abrasive cleaners or immerse the fan in water.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, away from direct sunlight and extreme temperatures.

10. Troubleshooting

- **Fan does not turn on:**
  - Check if the battery is charged. Recharge the fan if the battery level is low.
  - Ensure the power button is pressed correctly (short press for on, long press for off).
- **Fan head does not rotate smoothly:**
  - Adjust the screws located under the clip slightly to ensure proper movement.
- **Weak airflow:**
  - Increase the fan speed setting.
  - Ensure the fan grille and blades are free from dust and obstructions.
- **Remote control not working:**
  - Ensure there are no obstructions between the remote and the fan.
  - Check the remote control's battery and replace if necessary.

11. Specifications

Feature	Detail
Brand	Minthouz
Model Number	MT-L018F

Colour	White
Power Source	Battery Powered (8000mAh)
Electric Fan Design	Table Fan / Clip Fan
Number of Speeds	5
Noise Level	25-40 Decibels
Rotation	720° (360° Horizontal, 360° Vertical)
Product Dimensions (D x W x H)	8.2D x 15.4W x 20H Centimetres
Item Weight	0.6 Kilograms
Control Method	Push Button, Remote
Material Type	Acrylonitrile Butadiene Styrene

12. Warranty and Support

This Minthouz product comes with a**1 Year Manufacturer Warranty**.

For any product inquiries, technical support, or warranty claims, please contact the manufacturer directly:

Manufacturer Contact: WINSTARS TECHNOLOGY LTD

Minthouz is committed to providing high-quality customer service. If you encounter any issues, please reach out to us for assistance.

© 2026 Minthouz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question