

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [coioc](#) /

› [coioc S18-2 Portable Bluetooth Speaker User Manual](#)

coioc S18-2

coioc S18-2 Portable Bluetooth Speaker User Manual

Model: S18-2

INTRODUCTION

Thank you for purchasing the coioc S18-2 Portable Bluetooth Speaker. This speaker delivers 30W of powerful stereo sound with dual bass drivers, offering up to 30 hours of playtime. It features TWS pairing for an immersive audio experience, dynamic RGB lighting, and IPX7 waterproofing, making it suitable for various environments. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance.



Image: The coioc S18-2 Portable Bluetooth Speaker, showcasing its sleek design and portable form factor.

WHAT'S IN THE BOX

Please check the package contents upon unboxing:

- coioc S18-2 Bluetooth Speaker (x1)
- AUX Cable (x1)
- Type-C Charging Cable (x1)
- User Manual (x1)

Size Reference

Speaker Size

3.21*3.21*7.4 inches
1.15LB

Package Size

3.5*3.5*7.67 inches
1.36LB



Image: The speaker, its packaging, and all included accessories: AUX cable, Type-C charging cable, and user manual.

PRODUCT OVERVIEW AND CONTROLS

Familiarize yourself with the speaker's buttons and ports for optimal use.

Controllo Intelligente dei Pulsanti



Image: A detailed diagram illustrating the smart button controls on the speaker, showing functions for power, lighting, volume, track control, EQ, and TWS pairing.

Button Functions:

- **Power Button:** Press and hold for 2 seconds to Power ON/OFF.
- **Light Button:** Press once to cycle through RGB lighting modes. Press three times to turn off lights.
- **Volume Down:** Press once to decrease volume. Press and hold for 2 seconds for previous track.
- **Volume Up:** Press once to increase volume. Press and hold for 2 seconds for next track.
- **EQ Button:** Press once to switch EQ modes (Normal/Vocal).
- **TWS Button:** Press twice to initiate TWS pairing.
- **Play/Pause Button:** Press once to Play/Pause music.
- **Call Button:** Press once to Answer/End a call. Press and hold for 2 seconds to Reject a call.

Video Demonstration of Controls and Lights:

Your browser does not support the video tag.

Video: A short demonstration showing how to operate the speaker's buttons, including changing RGB light modes and adjusting volume.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided Type-C charging cable to the speaker's charging port and a USB power adapter (not included). The LED battery indicator will show the charging progress from 1% to 100%. A full charge provides up to 30 hours of playtime (at 30% volume with lights off).



Image: The speaker displaying its battery level and indicating 30 hours of playtime with Type-C fast charging capability.

2. Power On/Off

- To Power ON: Press and hold the Power button for 2 seconds.
- To Power OFF: Press and hold the Power button for 2 seconds.

3. Bluetooth Pairing

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing Bluetooth icon.
2. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
3. Select "coioc S18-2" from the list.
4. Once connected, the speaker will emit a confirmation sound, and the Bluetooth icon will stop flashing.

OPERATING INSTRUCTIONS

1. Connection Methods

The coioc S18-2 speaker supports multiple connection options:

- **Bluetooth (BT):** For wireless audio streaming from compatible devices.
- **AUX:** Connect via the 3.5mm audio cable for wired playback.
- **TF Card:** Insert a MicroSD (TF) card with music files for direct playback.
- **USB:** Connect a USB drive with music files for direct playback.



Image: The speaker highlighting its four versatile connection methods: Bluetooth, AUX, TF card, and USB.

2. TWS (True Wireless Stereo) Pairing

For an immersive stereo experience, you can pair two coioc S18-2 speakers together:

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press the TWS button twice. It will enter TWS pairing mode.
3. The primary speaker will automatically search for and connect to the secondary speaker.
4. Once successfully paired, both speakers will emit a confirmation sound.

5. Now, connect your device to the primary speaker via Bluetooth as described in the 'Bluetooth Pairing' section. Audio will play in stereo through both speakers.

TWS Wireless Pairing

Connect two speakers together to get stereo sound and enjoy fully immersive audio.



Image: Two coioc S18-2 speakers wirelessly connected to a laptop via Bluetooth 5.4, illustrating the TWS pairing feature for enhanced stereo audio.

3. RGB Lighting Modes

The speaker features dynamic RGB lighting. To control the lighting:

- Press the Light button once to cycle through different RGB lighting effects.
- Press the Light button three times to turn off the lights.



Image: The speaker showcasing its RGB multicolor breathing light effects, alongside an illustration of its IPX7 waterproof rating.

4. EQ Modes

The speaker offers different Equalizer (EQ) modes to optimize your listening experience:

- Press the EQ button once to switch between available modes.
- Available modes include: **Normal** and **Vocal**.



Image: A visual representation of the speaker's EQ modes, highlighting 'Normal' and 'Vocal' settings to suit different musical preferences.

WATERPROOFING (IPX7)

The coioc S18-2 speaker is IPX7 waterproof, meaning it can be submerged in water up to 1 meter for 30 minutes. This makes it ideal for use by the pool, at the beach, or in rainy conditions. Ensure the charging port cover is securely closed before exposing the speaker to water.



Image: The coioc S18-2 speaker partially submerged in water, illustrating its IPX7 waterproof capability.

MAINTENANCE

- Clean the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Store the speaker in a cool, dry place when not in use.
- Avoid exposing the speaker to extreme temperatures or direct sunlight for prolonged periods.
- Ensure the port cover is sealed when not charging or using wired connections to maintain waterproofing.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Speaker does not turn on	Low battery	Charge the speaker fully.
Cannot pair via Bluetooth	Speaker not in pairing mode / Device Bluetooth off / Too far from device	Ensure speaker is in pairing mode. Turn on Bluetooth on your device. Move speaker closer to device (within 10 meters).
No sound	Volume too low / Incorrect input source / Device not connected	Increase speaker and device volume. Check connection method (Bluetooth, AUX, TF, USB). Re-pair Bluetooth if necessary.
TWS pairing fails	Speakers too far apart / Already connected to another device	Ensure both speakers are close to each other. Disconnect speakers from other Bluetooth devices before TWS pairing.

SPECIFICATIONS

Feature	Detail
Model Name	S18-2
Brand	coioc
Color	Black
Speaker Output Power	30 Watts
Connectivity Technology	Bluetooth 5.4
Wireless Communication Range	Up to 30 meters (100 feet)
Audio Output Mode	Stereo
Power Source	Battery Powered (4000 mAh)
Playtime	Up to 30 hours
Waterproof Rating	IPX7
Special Features	Stereo Pairing (TWS), Bass Boost, Dustproof, Noise Cancellation, LED Battery Indicator, Lightweight, LED Light, Built-in Microphone, USB Port, AUX, TF Card Slot
Product Dimensions	5D x 5W x 5H cm (approximately 2D x 2W x 2H inches)
Compatible Devices	Phone, Tablet, Computer, Television

WARRANTY AND SUPPORT

The coioc S18-2 Portable Bluetooth Speaker comes with a limited warranty. For detailed warranty information or technical support, please refer to the warranty card included in your package or contact coioc customer service through the retailer where you purchased the product. Please retain your proof of purchase for warranty claims.

