

flyEVfish JT156M-H01

flyEVfish 15.6 Inch Digital Calendar Instruction Manual

Model: JT156M-H01

1. INTRODUCTION

The flyEVfish 15.6 Inch Digital Calendar is an interactive touchscreen display designed to streamline family schedules and routines. This device serves as a central hub for managing calendars, tasks, meal plans, and displaying photos, aiming to enhance household organization.

	flyEVfish	Other Digital Calendars
Two-way Sync	Google, Outlook Limited	✗ Limited
Meals	✓	✗ Paid
Rewards	✓	✗ Paid
Photo Screensaver	✓	✗ Paid
Device Sharing	✓	✗ Limited
Flexible Options	✓	✗ Limited

Image: Comparison of flyEVfish Digital Calendar features against other digital calendars.

2. KEY FEATURES

- Smart Digital Calendar:** A 15.6-inch HD touchscreen family planner and chore chart. It allows for assigning colors to individuals, adding tasks, and managing events across various views.
- Easy Setup & Instant Sync:** Connects to Wi-Fi and syncs with popular calendar services such as Google, Outlook, iCloud, Cozi, and Yahoo. Events can be added directly on the device or via the eCalendar app.
- Interactive Task Chart & Meal Plans:** Features a task system where routines and to-dos can be assigned, allowing users to earn stars and unlock rewards. Includes a dedicated section for displaying weekly meal plans.
- Photo Display & Custom Lists:** Functions as a digital photo frame when not actively in use, allowing organization of photos into

albums. Supports creation of custom lists for various purposes, such as packing or groceries.

- **Weather & Sleep Mode:** Provides precise weather forecasting for event locations for up to three days. Includes a customizable sleep mode to automatically turn the screen off and on.
- **Versatile Mounting Options:** Designed for both wall mounting and desktop placement, integrating seamlessly into different home environments.




Image: The flyEVfish Digital Calendar showcasing its family affairs management hub, including customizable profiles, colors, schedules, and more.

3. SETUP GUIDE

3.1 Unboxing and Initial Power-On

1. Carefully remove the digital calendar and all accessories from the packaging.
2. Connect the power adapter to the device's power port and plug it into a standard US-style electrical outlet.
3. The device will automatically power on. Follow the on-screen prompts for initial setup.

3.2 Wi-Fi Connection

1. On the initial setup screen, select your preferred language.
2. Choose your Wi-Fi network from the list of available networks.
3. Enter your Wi-Fi password and tap "Connect".
4. Once connected, the device will proceed to the next setup step.

3.3 Calendar Synchronization

The flyEVfish Digital Calendar supports seamless synchronization with various online calendar services.

1. From the main menu, navigate to the "Sync" or "Settings" section.
2. Select "Sync a New Calendar" and choose your desired service (Google, Outlook, iCloud, Cozi, Yahoo).
3. Follow the on-screen instructions to log in to your account and grant necessary permissions for synchronization.
4. For Google and Outlook, two-way sync is supported, meaning changes made on the device will reflect in your online calendar and vice-versa. Other services may offer one-way sync.
5. Synchronization typically takes a few minutes.

Complete Tasks, Redeem Rewards

Enhance parent-child interaction and boost motivation






Image: Screenshot of the flyEVfish Digital Calendar's setup interface, showing options for syncing with Google, Outlook, iCloud, Cozi, and Yahoo calendars.

4. OPERATING INSTRUCTIONS

4.1 General Navigation

The device features a responsive touchscreen. Tap to select items, swipe to scroll through lists or calendar views, and use pinch-to-zoom gestures where applicable.

4.2 Calendar Management

- **Adding Events:** Tap the '+' icon or an empty time slot on the calendar view. Enter event details such as title, date, time, and participants.
- **Editing Events:** Tap an existing event to open its details. Make necessary changes and tap 'Save'.
- **Assigning Colors:** Assign unique colors to different family members or event categories for easy visual identification.

Sync in Minutes – Works with






Image: The flyEVfish Digital Calendar showing a detailed weekly schedule with color-coded events for different family members.

4.3 Task Management and Rewards

- **Creating Tasks:** Navigate to the "Tasks" section. Tap '+' to add a new task, assign it to a family member, set a due date, and optionally add a description.
- **Marking Tasks Complete:** Tap on a task to mark it as completed.
- **Rewards System:** Set up a reward system where completing tasks earns stars. Define custom rewards that can be redeemed once a certain number of stars are accumulated.



Complete Tasks, Redeem Rewards

Help children develop good habits

Help dry dishes

Monday, March 2, 2026 : All day

☆ 1

Assigned to

Ethan
Olivia

Make Bed

Monday, March 2, 2026 : All day

☆ 1

Assigned to

Olivia

Image: The flyEVfish Digital Calendar displaying the interactive task chart and reward system, encouraging children to complete chores.

4.4 Meal Planning

- Access the "Meals" section to plan your weekly breakfast, lunch, dinner, and snacks.
- Add specific meal items for each day. This feature helps in organizing meal times for the entire family.

No more "What's for dinner?"



Image: The flyEVfish Digital Calendar showing a weekly meal plan, helping families organize their daily meals.

4.5 Photo Display

- In the "Photos" section, you can upload your favorite images to be displayed as a screensaver when the calendar is not actively being used.
- Organize photos into albums for customized display options.



Image: The flyEVfish Digital Calendar functioning as a smart photo display, showcasing family memories.

4.6 Custom Lists

- Create and manage various custom lists, such as grocery lists, packing lists, or to-do lists, within the "Lists" section.
- These lists can be accessed and updated directly on the device or through the eCalendar app.

4.7 Weather and Sleep Mode

- The device displays current weather conditions and a three-day forecast.
- Configure "Sleep Mode" in the settings to set specific times for the screen to turn off and on, conserving energy and reducing light pollution during rest periods.

The Best Gift for Your Family

Perfect for Mother's Day, birthdays, and Christmas



Image: Overview of additional features including automatic brightness adjustment, auto-rotation for landscape or portrait, sleep mode, weather display, multi-language support, and touchscreen functionality.

5. MOUNTING OPTIONS

5.1 Desk Mount

The digital calendar includes an integrated stand for desktop placement. Simply unfold the stand at the back of the device to position it upright on any flat surface.

5.2 Wall Mount

For wall mounting, secure appropriate screws (not included) into your desired wall location, ensuring they are spaced correctly to align with the mounting holes on the back of the device. Hang the calendar securely on the screws.



Image: Rear view of the flyEVfish Digital Calendar, illustrating the integrated desk stand and the mounting points for wall installation.

6. MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to gently wipe the screen and device exterior. Avoid abrasive cleaners or sprays directly on the screen.
- **Software Updates:** Periodically check for software updates in the device settings to ensure optimal performance and access to new features. Updates may resolve minor glitches.
- **Power Cycle:** If the device becomes unresponsive, disconnect the power adapter, wait 10 seconds, and then reconnect it to perform a power cycle.

7. TROUBLESHOOTING

Issue	Possible Cause	Solution
Device does not power on.	Power adapter not connected or faulty outlet.	Ensure the power adapter is securely connected to the device and a working electrical outlet. Try a different outlet.
Cannot connect to Wi-Fi.	Incorrect password, out of range, or network issue.	Verify Wi-Fi password. Move the device closer to the router. Restart your router.
Calendar not syncing.	Incorrect account credentials, network issue, or sync settings.	Check your account login details in the sync settings. Ensure a stable Wi-Fi connection. Re-establish the calendar sync connection.
Tasks reappear after being marked complete.	Software glitch or sync conflict.	Check for available software updates and install them. If the issue persists, contact customer support.
Screen is unresponsive.	Temporary software freeze.	Perform a power cycle by unplugging and re-plugging the device.

8. SPECIFICATIONS

Brand: flyEVfish

Model Number: JT156M-H01

Screen Size: 15.6 Inch

Display Type: HD Touchscreen

Item Weight: 1.54 kg


UPC: 789091411413

Manufacturer: flyEVfish

15.6" HD Touchscreen

15.7"

9.8"



5.89"

2.81"




Image: Diagram illustrating the dimensions of the 15.6-inch flyEVfish Digital Calendar.

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official flyEVfish website. You may also contact customer service through the retailer where the product was purchased.

© 2026 flyEVfish. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution.
[Privacy details.](#)

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question