Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bestier 67 Inch with Drawer

Bestier 67-Inch Modern TV Stand User Manual

Model: 67 Inch with Drawer | Brand: Bestier

1. Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Anti-Tipping Device:** Always secure the TV stand to the wall using the provided anti-tipping devices to prevent tipping and potential injury. This is crucial for safety, especially in households with children or pets.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 200 lbs for the tabletop and 30 lbs for each open shelf. Overloading can cause instability and damage.
- **Placement:** Place the TV stand on a flat, stable, and level surface. Uneven surfaces can lead to instability.
- **Ventilation:** Ensure adequate ventilation around electronic devices placed on the shelves to prevent overheating.
- **Cleaning:** Wipe with a damp cloth. Avoid harsh chemicals that may damage the finish.

2. Package Contents

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 67-Inch High Gloss TV Stand components
- Hardware Pack (screws, dowels, cam locks, etc.)
- Step-by-Step Assembly Manual
- Storage Drawer components
- LED lighting kit with remote control
- Two anti-tipping kits

3. Assembly Instructions

Assembly typically requires 1-2 people and takes approximately 0.5-1 hour. Follow the step-by-step instructions provided in the included manual and refer to the video for visual guidance.

3.1 Assembly Overview

The TV stand consists of a main frame, a central drawer, and two open storage shelves. The assembly process involves attaching the LED lights, constructing the main frame, assembling the drawer, and finally installing the anti-tipping devices.




Figure 1: Product Dimensions and Component Overview. The TV stand measures 66.9 inches in length, 13.8 inches in depth, and 15.9 inches in height. The main top supports up to 200 lbs, and each open shelf supports 30 lbs. The drawer measures 23.6 inches wide, 11.8 inches deep, and 6.4 inches high, with a capacity of 22 lbs.

3.2 Step-by-Step Assembly Video

Your browser does not support the video tag.

Video 1: Installation Guide for Bestier Modern TV Stand. This video provides a detailed visual walkthrough of the assembly process, from unboxing to final setup, including LED light installation and anti-tipping device attachment.

3.3 Key Assembly Steps

1. **Prepare Components:** Unpack all parts and lay them out. Identify each piece using the labels in the manual.
2. **Install LED Lights:** Attach the LED strips to the designated areas on the main panels using the provided screws. Ensure the wiring is routed correctly.
3. **Assemble Main Frame:** Connect the side panels, bottom panel, and back panel using cam locks and dowels.

Secure with screws as indicated.

4. **Assemble Drawer:** Construct the drawer box and attach the drawer slides.
5. **Install Drawer:** Carefully slide the assembled drawer into the main frame.
6. **Attach Stone-Patterned Doors:** Secure the decorative stone-patterned doors to the side sections.
7. **Install Anti-Tipping Devices:** Attach the anti-tipping brackets to the top rear of the TV stand and secure them to a wall stud using the provided hardware.

4. Operating Instructions

4.1 LED Lighting System

Your Bestier TV stand features an integrated LED lighting system with 22 dynamic modes and 7 main colors to enhance your living space. The lights are controlled via a remote control.

- **Power On/Off:** Use the power button on the remote to turn the LED lights on or off.
- **Color Selection:** Press the color buttons on the remote to select from the 7 main colors (Red, Green, Blue, White, Yellow, Cyan, Purple).
- **Dynamic Modes:** Cycle through the 22 dynamic modes using the 'Mode' button to experience various lighting effects.
- **Brightness Adjustment:** Use the brightness buttons to adjust the intensity of the lights.
- **Remote Range:** The remote control has a maximum range of 49 feet. Ensure a clear line of sight to the receiver for optimal performance.



Figure 2: LED Lighting Features. The remote control allows selection of 7 main colors and 22 dynamic modes, with a maximum range of 49 feet.

4.2 Storage and Organization

The TV stand is designed with practical storage solutions to keep your living room tidy.

- **Central Drawer:** A spacious central drawer is ideal for storing remote controls, small accessories, and other items out of sight.
- **Open Shelves:** Two open shelves provide space for media consoles, soundbars, gaming systems, or decorative items. The LED lighting illuminates these shelves, creating an attractive display.



Figure 3: Ample Storage Space. The TV stand features one large central drawer and two open storage shelves for organizing media and accessories.

4.3 Product Features Overview Video

Your browser does not support the video tag.

Video 2: Bestier 67" TV Stand Features. This video highlights the key features of the TV stand, including its high gloss finish, stone-patterned doors, ample storage, LED lighting, and anti-tipping design.

5. Maintenance

To maintain the appearance and longevity of your TV stand, follow these simple care instructions:

- **Cleaning:** Regularly wipe surfaces with a soft, damp cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the high gloss finish.
- **Spills:** Promptly wipe up any spills to prevent staining or damage to the material.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.

- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.

6. Troubleshooting

If you encounter any issues with your Bestier TV stand, please refer to the following common solutions:

- **LED Lights Not Working:**
  - Check if the power adapter is securely plugged into both the wall outlet and the LED controller.
  - Ensure the remote control has working batteries and a clear line of sight to the LED receiver.
  - Verify all LED strip connections are secure.
- **Drawer Not Sliding Smoothly:**
  - Ensure the drawer slides are correctly installed and aligned.
  - Check for any obstructions in the drawer tracks.
  - Lubricate the drawer slides with a silicone-based lubricant if needed.
- **Stand is Wobbly:**
  - Ensure the TV stand is placed on a level surface.
  - Check all assembly hardware (cam locks, screws) and tighten them securely.
  - Verify that the anti-tipping devices are properly installed and anchored to the wall.

If the problem persists, please contact Bestier customer support for assistance.

7. Specifications

Feature	Specification
Model	67 Inch with Drawer
Color	Black
Material Type	Engineered Wood
Item Dimensions (L x W x H)	67 x 13.78 x 15.75 inches
Item Weight	45.42 Pounds
TV Size Compatibility	55 to 75 Inch TVs
Tabletop Weight Capacity	Up to 200 lbs
Shelf Weight Capacity	30 lbs per shelf
Drawer Weight Capacity	22 lbs
Style	Modern, Gaming
Required Assembly	Yes
Included Components	TV Stand, Hardware Pack, Manual, Storage Drawer

8. Warranty and Support

Bestier is committed to providing high-quality products and customer satisfaction. For any questions, concerns, or assistance with your product, please contact our customer support team.

8.1 Customer Support Contact Information

Region	Contact Details
North American	Phone: 888-666-1086 Email: Service.US@bestier.net
Europe	Email: Service.UK@bestier.net, Service.FR@bestier.net, Service.DE@bestier.net, Service.IT@bestier.net, Service.ES@bestier.net
Asia	Phone: 04-8888-0283 Email: Service.JP@bestier.net
Global	Email: Service@bestier.net

Please have your model number and purchase information ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GGJS1RS7

More documents and user manuals: **https://manuals.plus/**