



[Manuals.plus](#) /

› [GAOMON](#) /

› GAOMON 10'X14' Wall-Mounted Lean-to Gazebo Instruction Manual

GAOMON OS8Kv5eb_FQcSoXzfsprTQ0w

GAOMON 10'X14' Wall-Mounted Lean-to Gazebo Instruction Manual

Model: OS8Kv5eb_FQcSoXzfsprTQ0w

1. INTRODUCTION

Thank you for choosing the GAOMON 10'X14' Wall-Mounted Lean-to Gazebo. This gazebo is designed to provide a durable and versatile outdoor living space, featuring a galvanized steel roof, integrated gutters, and sliding netting/curtains. This manual provides essential information for the safe assembly, operation, and maintenance of your new gazebo. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image 1.1: The GAOMON 10'X14' Wall-Mounted Lean-to Gazebo providing a shaded outdoor area next to a modern home and pool.

2. SAFETY INFORMATION

Please observe the following safety precautions to ensure safe use and prevent injury or damage:

- Always assemble this gazebo on a flat, stable surface.
- Secure the gazebo to the ground using the provided anchors to prevent it from tipping over in windy conditions.
- Keep children and pets away from the gazebo during assembly and disassembly.

- This gazebo is not intended for use by children without adult supervision.
- Do not exceed the weight limit of 304.24 pounds for the gazebo.
- Regularly inspect all connections and anchors to ensure they remain secure.
- In extreme weather conditions (e.g., heavy snow, strong winds), it is recommended to remove curtains/netting and, if possible, temporarily disassemble or reinforce the structure to prevent damage.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. Refer to the separate parts list provided in your packaging for detailed identification. Key components include:

- Aluminum Frame Components
- Galvanized Steel Roof Panels (6 mm thick polycarbonate panels)
- Steel Columns and Beams (1.0 mm wall thickness)
- Sliding Netting and Curtains
- Integrated Gutter System Components
- Fasteners and Anchoring Hardware
- Assembly Tools (if included, otherwise standard tools required)

If any parts are missing or damaged, do not proceed with assembly. Contact GAOMON customer support for assistance.

4. SETUP AND ASSEMBLY

Assembly requires at least two adults. Ensure you have sufficient space and all necessary tools before starting. Components are pre-labeled for easier identification.

4.1 Site Preparation

1. Choose a flat, level, and stable surface for installation. The gazebo is designed to be wall-mounted, so ensure the wall is structurally sound and capable of supporting the gazebo's weight.
2. Clear the area of any obstructions, debris, or vegetation.
3. Ensure adequate clearance around the gazebo for future maintenance and use of curtains/netting.

4.2 Frame Assembly

1. Unpack all components and lay them out according to the parts list.
2. Begin by assembling the main support beams and columns. Connect the steel columns to the base plates and upper frame sections using the provided fasteners.
3. Attach the wall-mounting brackets to the upper frame, ensuring they align with your chosen wall location.
4. Carefully lift and secure the assembled frame to the wall using appropriate wall anchors (may vary based on wall material, consult a professional if unsure).
5. Connect the remaining frame components, ensuring all bolts are tightened securely but not over-tightened to avoid stripping.




Image 4.1: Structural diagram illustrating the dimensions and key frame components for assembly.

4.3 Roof Panel Installation

1. Install the galvanized steel roof panels (polycarbonate panels) onto the roof frame. Ensure panels are correctly oriented and seated in their channels.
2. Secure the panels using the designated clips and fasteners, following the specific instructions in your detailed assembly guide.
3. Install the integrated gutter system along the edges of the roof to direct rainwater away from the gazebo.

4.4 Netting and Curtain Installation

1. Attach the sliding netting and curtains to the designated tracks on the gazebo frame.
2. Ensure the netting and curtains slide smoothly and can be fully opened or closed.

4.5 Final Securing

1. Once the gazebo is fully assembled, double-check all connections and fasteners to ensure they are tight and secure.
2. Anchor the gazebo to the ground using the provided ground stakes or other suitable anchoring methods for your specific surface.

5. OPERATING INSTRUCTIONS

5.1 Sliding Netting and Curtains

The gazebo features a dual-track system for sliding netting and curtains, allowing for versatile use:

- **Open View:** Slide both netting and curtains to the sides for an unobstructed 360-degree view and maximum airflow.
- **Bug Protection:** Close the netting to keep insects out while maintaining ventilation.
- **Privacy and Shade:** Close the curtains for privacy or to block direct sunlight.

Freedom to Choose Your View

Detachable Netting & Curtains



Image 5.1: Demonstrating the flexible options for privacy, ventilation, and bug protection using the detachable netting and curtains.

5.2 Galvanized Steel Roof and Gutters

The galvanized steel roof with 6 mm thick polycarbonate panels provides protection from various weather conditions. The integrated gutter system is designed to channel rainwater efficiently, preventing accumulation on the roof and directing it away from the gazebo's base.

All-Weather Protection

Built for harsh conditions



Image 5.2: The gazebo's roof demonstrating its all-weather protection capabilities, including rain resistance.

6. MAINTENANCE

Regular maintenance will extend the life and appearance of your GAOMON gazebo.

- **Cleaning:** Clean the frame, roof panels, netting, and curtains periodically with mild soap and water. Rinse thoroughly with clean water and allow to air dry. Avoid abrasive cleaners or brushes that could scratch surfaces.
- **Roof Care:** Regularly clear leaves, debris, and snow from the roof to prevent excessive weight accumulation, especially during winter months. The integrated gutters should also be kept clear to ensure proper drainage.

- **Frame Inspection:** Annually inspect all bolts, screws, and connections for tightness. Re-tighten as necessary. Check for any signs of rust or damage to the steel components. The 8-level salt spray resistance helps prevent rust, but regular inspection is still recommended.
- **Fabric Care:** The netting and curtains can be removed for cleaning or storage during harsh weather. Follow care instructions on the fabric labels.
- **Anchoring:** Periodically check the ground anchors to ensure they remain firmly secured, especially after strong winds.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your gazebo.

- **Gazebo feels unstable:**
 - Ensure all frame bolts and screws are securely tightened.
 - Verify that the gazebo is properly anchored to both the wall and the ground.
 - Confirm the installation surface is flat and level.
- **Water pooling on the roof:**
 - Check if the roof panels are correctly installed and seated in their channels.
 - Clear any debris from the roof and gutters that might be obstructing water flow.
- **Netting/Curtains do not slide smoothly:**
 - Inspect the tracks for any obstructions or damage.
 - Clean the tracks and curtain/netting hooks to remove dirt or grime.
 - Ensure the tracks are properly aligned.
- **Parts missing or damaged during assembly:**
 - Do not proceed with assembly. Contact GAOMON customer support immediately with your product model number and details of the issue.

8. SPECIFICATIONS

Brand	GAOMON
Model Number	OS8Kv5eb_FQcSoXzfsprTQ0w
Product Dimensions (L x W x H)	170.5"L x 108"W x 103"H (approx. 14.2 ft x 9 ft x 8.5 ft)
Floor Area	168 Square Feet
Item Weight	304.2 Pounds
Frame Material	Metal (Aluminum frame, Steel columns/beams)
Roof Material	Galvanized Steel with 6 mm Polycarbonate Panels
Water Resistance Level	Waterproof (Tested to withstand 17 L/m ² .h water spray)
Wind Resistance	Withstands 10-12 m/s wind speeds
UV Protection	Polycarbonate panels with UPF>40
Temperature Range	-20°C to 50°C

Assembly Required	Yes
Color	Blue (curtains/netting) / Black (frame) / Amber (PC panels)

9. WARRANTY AND SUPPORT

GAOMON stands behind the quality of its products. For specific warranty details, please refer to the warranty card included with your purchase or visit the official GAOMON website. If you have any questions, require replacement parts, or need technical assistance, please contact GAOMON customer support. Have your model number (OS8Kv5eb_FQcSoXzfsprTQ0w) and purchase information ready when contacting support.