Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aoxun 8x8

Aoxun 8x8 Outdoor Gazebo Instruction Manual

Model: 8x8 Navy Blue

1. Important Safety Information

Please read and understand all instructions and warnings before assembling and using this gazebo. Failure to follow these instructions may result in injury or damage to the product.

- **Assembly:** This gazebo requires at least two adults for safe assembly. Do not attempt to assemble alone.
- **Anchoring:** Always secure the gazebo to the ground using the provided stakes, ropes, or expansion bolts. In windy conditions, additional anchoring may be required.
- **Weather Conditions:** This gazebo is designed for temporary outdoor use. Do not use in extreme weather conditions such as heavy winds, snow, or thunderstorms. Disassemble and store the canopy during severe weather to prevent damage.
- **Fire Safety:** Keep all flame and heat sources away from the gazebo fabric. The fabric is not fireproof.
- **Children:** Keep children away from the assembly area. Do not allow children to play with or climb on the gazebo structure.
- **Maintenance:** Regularly inspect the frame and canopy for any signs of wear or damage. Replace damaged parts immediately.

2. Package Contents

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Steel Frame Components (Legs, Beams, Connectors)
- Main Canopy Fabric
- Top Canopy Fabric (Double Roof)
- Mosquito Netting (4 panels)
- Privacy Curtains (4 panels)
- Hardware Kit (Bolts, Screws, Washers, Wrenches)

- Ground Stakes and Wind Ropes
- Instruction Manual



Image: Overview of the Aoxun 8x8 Gazebo structure and fabric components.

3. Assembly Instructions

Follow these steps carefully for proper assembly. Two adults are recommended for this process.

3.1. Frame Assembly

1. Unpack all components and verify against the parts list.
2. Lay out the base frame components (legs and lower beams) on a flat, level surface.
3. Connect the leg posts to the lower beams using the provided hardware. Do not fully tighten bolts until the entire frame is assembled.

4. Attach the upper beams and roof support structure to the leg posts. Ensure all connections are secure.
5. Once the main frame is upright, fully tighten all bolts.



Image: The sturdy steel frame provides strong support and stability.

3.2. Canopy and Roof Installation

1. Carefully unfold the main canopy fabric and drape it over the assembled roof frame. Ensure the corners align with the frame posts.
2. Secure the main canopy to the frame using the integrated straps or ties.
3. Install the smaller top canopy onto the upper roof structure, aligning it with the main canopy's opening. This creates the double-roof design for ventilation.
4. Ensure both canopies are taut and securely fastened to prevent water pooling and wind damage.



Image: Detail of the ventilated double roof design.

3.3. Mosquito Netting and Privacy Curtains

1. Attach the mosquito netting panels to the designated hooks or rings on the gazebo frame. Ensure zippers are facing inwards for easy access.
2. Hang the privacy curtains on the outer track or rings.
3. Use the integrated velcro straps to secure the netting and curtains to the frame posts when not in use, or to each other for full enclosure.



Image: The Aoxun 8x8 Gazebo fully assembled with curtains.

3.4. Anchoring the Gazebo

After assembly, securely anchor the gazebo to the ground.

- For soft ground (lawn, garden): Use the provided ground stakes and wind ropes.
- For hard surfaces (deck, concrete patio): Use appropriate expansion bolts (not always included, may need to be purchased separately) to secure the leg plates.

4. Operating Your Gazebo

4.1. Using Mosquito Netting and Privacy Curtains

- **Mosquito Netting:** Zip the netting panels together to create an enclosed, insect-free space. The netting allows for

air circulation while keeping mosquitoes out.

- **Privacy Curtains:** Draw the curtains closed for privacy or protection from sun and wind. Tie them back to the posts when an open view is desired.



Image: The mosquito netting provides an insect-free outdoor space.

4.2. Utilizing Accessory Hooks

The gazebo is equipped with features for customization:

- **Top Hooks:** Use the central hooks to hang a chandelier for lighting or a fan for cooling.
- **Corner Rings:** The four corner rings can be used to hang string lights, decorative ornaments, or flags.



Image: DIY configuration options with corner rings and J-shaped hooks.

4.3. Gazebo Modes

The design allows for versatile use:

- **Expansive View:** With curtains and netting tied back, enjoy an open outdoor space.
- **Anti-Mosquito:** Zip up the netting to protect against insects.
- **Private Space:** Close the privacy curtains for seclusion and shade.



Image: The gazebo offers three distinct modes for various outdoor needs.

5. Maintenance and Care

Proper maintenance will extend the life of your gazebo.

- **Cleaning Canopy:** Clean the canopy fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Allow to air dry completely before storage.
- **Cleaning Frame:** Wipe the metal frame with a damp cloth. For stubborn dirt, use mild soap and water. The powder coating helps prevent rust, but regular cleaning maintains its appearance.
- **Seasonal Storage:** During off-seasons or prolonged periods of non-use, it is recommended to disassemble the canopy and store it in a dry, protected area to prevent damage from extreme weather.
- **Fastener Check:** Periodically check all bolts and connections to ensure they remain tight and secure.
- **Water Drainage:** The gazebo features leakage holes on the top to help drain water and reduce pressure on the canopy. Ensure these holes remain clear of debris.

- **Fabric Integrity:** Inspect the fabric for any small tears or fraying. Address minor damage promptly to prevent it from worsening.



Image: Product details showing water leakage holes and extra velcro straps for securing curtains.

6. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Water pooling on canopy	Canopy not taut; debris blocking drainage holes.	Ensure canopy is stretched tightly. Clear any debris from drainage holes.

Problem	Possible Cause	Solution
Gazebo feels unstable	Not properly anchored; loose frame connections.	Verify all anchoring points are secure. Tighten all frame bolts. Do not use in high winds.
Mosquitoes entering gazebo	Netting not fully zipped or gaps present.	Ensure all netting zippers are closed and check for any gaps where netting meets the frame or ground.
Difficulty with assembly	Instructions not followed; attempting alone.	Review instructions carefully. Ensure two adults are assisting. Do not overtighten bolts until instructed.

7. Specifications

Feature	Detail
Brand	Aoxun
Model	8x8 Outdoor Gazebo
Color	Navy Blue
Product Dimensions (L x W x H)	96.5"L x 96.5"W x 104.3"H (8ft x 8ft x 8.6ft)
Item Weight	50 Pounds
Frame Material	Steel with powder coating (listed as Aluminum in some specs, but feature bullets mention steel)
Canopy Material	Waterproof Polyester Fabric (UV-resistant UPF 50+)
Water Resistance Level	Waterproof
Ultraviolet Light Protection	Yes
Assembly Required	Yes
Special Features	Double Roof, Mosquito Netting, Privacy Screens, Corner Rings, Top Hooks, Leakage Holes



Image: Detailed dimensions of the 8x8 Aoxun Gazebo.

8. Warranty Information

This Aoxun gazebo comes with a manufacturer's warranty against defects in materials and workmanship. The specific terms and duration of the warranty may vary. Please retain your proof of purchase for warranty claims.

For detailed warranty information or to make a claim, please refer to the warranty card included with your product or contact Aoxun customer support directly.

9. Customer Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Aoxun customer support.

- **Online Support:** Visit the official Aoxun website for FAQs and support resources.
- **Email Support:** Refer to your product packaging or warranty card for contact email.
- **Phone Support:** Refer to your product packaging or warranty card for contact phone number.

Please have your model number (8x8 Navy Blue) and purchase date ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GGNMYCH2

More documents and user manuals: **https://manuals.plus/**