

[Manuals.plus](#) /

› [VECYS](#) /

› VECYS Water Dispenser Filter Instruction Manual for FY1185 and FY605

VECYS FY1185, FY605

VECYS Water Dispenser Filter Instruction Manual

Models: FY1185, FY605

1. INTRODUCTION

This manual provides essential instructions for the installation, operation, maintenance, and troubleshooting of your VECYS Water Dispenser Filter set. This filter set is designed for use with VECYS water cooler models FY1185 and FY605 to ensure clean and purified drinking water.

2. PRODUCT OVERVIEW

The VECYS Water Dispenser Filter set consists of four stages: PP (Polypropylene), CTO (Carbon Block), UF (Ultrafiltration), and a final CTO (Carbon Block) filter. These filters work in sequence to reduce sediment, chlorine, odors, and other impurities from your drinking water.



Image 1: The VECYS Water Dispenser Filter Set, including PP, CTO, UF, and CTO filters.

Compatibility

This filter set is specifically designed for VECYS water cooler models FY1185 and FY605.

3. SETUP AND INSTALLATION

Before installing new filters, ensure your water dispenser is turned off and disconnected from the power supply. It is recommended to flush new filters before first use to remove any carbon fines.

Filter Replacement Procedure (General Guide)

1. **Turn off Water Supply:** Locate the water inlet valve to your dispenser and turn it off.
2. **Depressurize System:** Dispense water from the cold and hot taps to release any pressure in the system.
3. **Access Filter Compartment:** Open the filter access panel on your VECYS water dispenser.
4. **Remove Old Filters:** Depending on your model, filters may twist off or unclip. Follow the specific

instructions for your FY1185 or FY605 model. Be prepared for some water spillage.

5. **Install New Filters:** Insert the new filters into their designated slots. Ensure they are securely twisted or clipped into place. Pay attention to the order of the filters (PP, CTO, UF, CTO).
6. **Restore Water Supply:** Slowly turn the water inlet valve back on. Check for leaks around the new filters.
7. **Flush Filters:** Dispense several liters of water through the cold tap to flush out air and carbon fines. Continue until the water runs clear and free of air bubbles.
8. **Reconnect Power:** Plug the water dispenser back into the power outlet.

Your browser does not support the video tag.

Video 1: A general demonstration of an EZ-twist filter replacement system in a bottleless water cooler. This video illustrates a common method for changing filters, which may be similar to your VECYS model.

4. OPERATING INSTRUCTIONS

Once the filters are installed and flushed, your VECYS water dispenser is ready for use. The filters work continuously to purify the water as it passes through the system.

General Water Dispenser Operation

- **Power On:** Ensure the dispenser is plugged in and the power switch (usually located at the back) is turned on.
- **Hot Water:** For hot water, activate the hot water function (if applicable) and press the hot water dispense button. Many models include a child safety lock for hot water.
- **Cold Water:** For cold water, activate the cold water function (if applicable) and press the cold water dispense button.
- **Normal/Ambient Water:** Some models offer ambient temperature water, dispensed by pressing the corresponding button.

Your browser does not support the video tag.

Video 2: Overview of the VECYS Bottom Loading Water Cooler BY1185, demonstrating its features and general operation. This provides context for how your filter-equipped dispenser functions.

Your browser does not support the video tag.

Video 3: A demonstration of a VECYS Bottom Loading Water Dispenser, showcasing its design and water dispensing capabilities, including the child safety lock for hot water.

5. MAINTENANCE

Filter Replacement Schedule

For optimal performance and water quality, it is recommended to replace your VECYS water dispenser filters every 6 months or after dispensing approximately 1,500 gallons of water, whichever comes first. Refer to your water dispenser's specific manual for any additional filter replacement indicators or schedules.

Cleaning the Water Dispenser

Regular cleaning of your water dispenser is essential to maintain hygiene and prolong its lifespan. Follow the cleaning instructions provided in your VECYS water cooler's user manual.

6. TROUBLESHOOTING

If you encounter issues with your water dispenser after filter installation, consider the following common troubleshooting steps:

- **Slow Water Flow:** This can indicate clogged filters. Ensure filters are installed correctly and not past their service life. If new, ensure they were properly flushed.
- **Unusual Taste or Odor:** If new filters, flush them thoroughly. If old filters, they may be exhausted and require replacement.
- **Leaks:** Check that filters are securely seated and tightened. Inspect O-rings for damage. Ensure all connections to the water dispenser are tight.
- **No Water Dispensing:** Verify the water supply valve is fully open and the dispenser is powered on. Check for kinks in the water line.

For persistent issues, consult the full user manual for your VECYS water cooler model (FY1185 or FY605) or contact VECYS customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	VECYS
Filter Type	PP, CTO, UF, CTO (4-stage filtration)
Compatible Models	VECYS Water Cooler FY1185, FY605
Material	Plastic
Product Dimensions	34.8D x 7.6W x 28.7H Centimetres
Number of Items	4 (filters)
Model Number (Filter Set)	CA-VE-WDFT-4
Manufacturer	AQUART

8. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the documentation included with your VECYS water dispenser or visit the official VECYS website. Specific warranty details for the filter set may be available through the retailer or manufacturer.