

DUMOS KFH-GDZ4CJD-40WT-ZYX-01

DUMOS 40 Inch Computer Desk with 4 Drawers, Power Outlets, and LED Lights

User Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your DUMOS 40 Inch Computer Desk. Please read this manual thoroughly before assembly and use to ensure proper function and safety. Keep this manual for future reference.

SAFETY INFORMATION

Always follow the assembly instructions carefully to avoid injury. Be cautious when handling electrical components and ensure proper grounding. Do not overload the desk with heavy items as it may cause instability. Always unplug the power hub before cleaning or making any adjustments to the electrical components.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact DUMOS customer support.

- Desk Frame Components
- Desktop Panels
- Monitor Riser
- 4 Fabric Drawers
- Assembly Hardware (screws, bolts, etc.)
- LED Light Strip with Controller
- Integrated Power Hub
- Assembly Instructions Manual

SETUP AND ASSEMBLY

The DUMOS 40 Inch Computer Desk is designed for straightforward assembly. All parts are numbered, and clear instructions are provided to facilitate quick setup. Assembly typically takes less than an hour.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Match each component with the corresponding labels in the assembly instructions.
3. **Assemble Frame:** Follow the step-by-step diagrams to connect the metal frame components. Ensure all connections are secure.
4. **Attach Desktop and Monitor Riser:** Secure the desktop panels and then the monitor riser to the assembled frame.
5. **Install Drawer Unit:** The 4-drawer unit can be mounted on either the left or right side of the desk, depending on your preference and room layout. Follow the instructions for reversible installation.
6. **Insert Fabric Drawers:** Place the fabric drawers into the designated slots within the drawer unit.
7. **Connect LED Lights and Power Hub:** Integrate the LED light strip and power hub according to the electrical connection instructions. Ensure all cables are managed neatly.
8. **Adjust Feet:** Use the adjustable feet at the base of the desk to ensure stability on uneven surfaces.

Product Dimensions





Image: This illustration shows the overall dimensions of the DUMOS 40 Inch Computer Desk, including the monitor shelf and drawer unit. It also highlights the reversible design of the drawer unit, allowing it to be placed on either side of the desk. Key dimensions are provided in inches.



3 AC Outlets
125 V/12A



1 Type-C
5V-2A



2 USB Ports
5V-2A





Image: A full view of the assembled DUMOS 40 Inch Computer Desk, showcasing its structure, the integrated monitor shelf, and the four fabric drawers. This image provides a visual reference for the completed assembly.

OPERATING INSTRUCTIONS

1. RGB LED Lighting System

The desk features a built-in multicolor LED light strip to enhance your workspace ambiance. The lights are USB-powered.

- **Remote Control:** Use the included remote to select from 12 preset lighting modes, adjust brightness, and change colors.
- **App Control:** Download the free companion app to unlock advanced features, including over 60,000 color options, music synchronization, and custom timers.



Ergonomic Monitor Platform

Elevate your monitor to free up space, improve posture, and reduce strain.

Image: This graphic illustrates the RGB LED light strip features, including 60,000 colors, various scene modes, music sync, timing mode, and control via both a physical remote and a mobile application. It shows the light strip integrated under the monitor shelf.

2. Integrated Power Hub

The monitor riser includes a convenient power station to keep your devices charged and organized.

- **AC Outlets:** Features 3 AC outlets (125V/12A) for powering monitors, laptops, or other electronics.
- **USB Ports:** Includes 1 USB port (5V-2A) and 1 Type-C port (5V-2A) for charging smartphones, tablets, and other USB-powered devices.
- **Cable Management:** Utilize the integrated design to route cables neatly, reducing desktop clutter.



Image: A detailed view of the power hub located on the monitor riser, showing 3 AC outlets, 1 Type-C port, and 2 USB ports. A smartphone and tablet are depicted charging, demonstrating the hub's functionality.

3. Ergonomic Monitor Riser

The elevated monitor shelf is designed to improve your posture by raising your screen to a comfortable viewing height, which can help reduce neck and back strain during extended use.

4 Storage Fabric Drawers for Storage

Ample space to organize all your essentials neatly




Image: This illustration demonstrates the ergonomic benefits of the monitor riser. It shows a user with correct posture when using the elevated monitor platform, contrasting it with incorrect posture that can lead to neck and back strain without a riser.

4. 4-Drawer Storage System

The desk includes four spacious, removable fabric drawers for organizing your essentials. The reversible design allows the drawer unit to be positioned on either side of the desk.



**Easy Clean/
Wear-Resistant**



Adjustable Feet



Reinforced Bracket

Image: A close-up view of the four fabric storage drawers, shown partially open to reveal their capacity for organizing various items such as books, stationery, and accessories. The drawers are integrated into the desk's side unit.

MAINTENANCE

1. Cleaning

The desk surface is designed to be easy to clean and wear-resistant.

- Wipe surfaces with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the finish.
- For spills, wipe immediately to prevent staining.

2. General Care

- Regularly check all screws and bolts to ensure they remain tight. Retighten as necessary.

- Ensure the power hub is unplugged before performing any cleaning or adjustments to electrical components.
- Do not place excessively hot or cold items directly on the desk surface without protection.
- Avoid dragging the desk; lift it when moving to prevent damage to the frame and floor.

Product Dimensions



Reversible Design




Image: This image highlights key features for maintenance and stability, including the easy-clean and wear-resistant surface, adjustable feet for leveling, and reinforced brackets for structural integrity.

TROUBLESHOOTING

If you encounter any issues with your DUMOS Computer Desk, refer to the following common problems and solutions:

- **Desk is Unstable/Wobbly:**

Ensure all assembly screws and bolts are tightened securely. Adjust the leveling feet at the bottom of the desk legs to compensate for uneven floor surfaces.

- **LED Lights Not Working:**

Check if the USB power cable for the LED strip is securely connected to a power source (e.g., the integrated power

hub or a USB adapter). Verify that the remote control batteries are functional, or try controlling via the app.

• **Power Outlets/USB Ports Not Functioning:**

Ensure the main power cable for the integrated power hub is securely plugged into a wall outlet. Check if the wall outlet itself is functional by testing with another device. Avoid overloading the power hub with too many high-power devices.

• **Drawers Do Not Slide Smoothly:**

Ensure the fabric drawers are correctly inserted into their slots and are not overloaded. Check for any obstructions within the drawer unit.

• **Missing Parts During Assembly:**

Review the package contents list. If parts are genuinely missing, contact DUMOS customer support with your purchase details.

SPECIFICATIONS

Feature	Specification
Brand	DUMOS
Model Number	KFH-GDZ4CJD-40WT-ZYX-01
Product Dimensions (D x W x H)	100D x 87.5W x 50H Centimeters (approx. 39.37D x 34.45W x 19.69H Inches)
Color	White
Material	Wood (Top), Metal (Frame)
Finish Type	Oil Rubbed
Number of Drawers	4 (Fabric, Removable)
Monitor Riser Height	19.69 Inches (Minimum/Maximum)
Power Hub	3 AC Outlets (125V/12A), 1 USB Port (5V-2A), 1 Type-C Port (5V-2A)
LED Lighting	RGB LED Strip, App & Remote Control, 12 Preset Modes, 60,000+ Colors, Music Sync, Timers
Assembly Required	Yes (Instructions Included)
Item Weight	13.4 kg
Special Features	Ergonomic Monitor Shelf, Reversible Drawer Layout, Adjustable Feet

WARRANTY AND SUPPORT

For warranty information, product support, or to report missing/damaged parts, please contact DUMOS customer service through the retailer where the product was purchased or visit the official DUMOS website. Please have your model

number (KFH-GDZ4CJD-40WT-ZYX-01) and purchase details ready.

© 2026 DUMOS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page
<https://manuals.plus/asin/B0GGRG3338>

More documents and user manuals: <https://manuals.plus/>