



9514285429148

# Generic YDCC-B Wire Controller Display Control Panel User Manual

Model: 9514285429148

## 1. INTRODUCTION

This manual provides essential instructions for the installation, operation, and maintenance of the Generic YDCC-B Wire Controller Display Control Panel. This device is designed to interface with compatible systems such as RHMYDCC-B-TH, WVH-02-GY, YORK-WCT-004-HL, SAP:1199118, and 025W46984-000, providing a user interface for system control and monitoring. Please read this manual thoroughly before installation and use to ensure proper function and safety.



Figure 1: Generic YDCC-B Wire Controller Display Control Panel. This image shows the front view of the control panel, featuring a display screen and several control buttons.

## 2. SAFETY INFORMATION

- Always disconnect power to the system before installing or servicing the control panel.
- Installation should be performed by a qualified technician in accordance with local electrical codes.
- Do not expose the control panel to moisture, extreme temperatures, or direct sunlight.
- Avoid using abrasive cleaners or solvents on the display or casing.
- Ensure all connections are secure and properly insulated to prevent electrical hazards.

## 3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Generic YDCC-B Wire Controller Display Control Panel (Model: 9514285429148)
- 1 x User Manual (this document)

## 4. SETUP

1. **Power Disconnection:** Before beginning installation, ensure that the main power supply to the system is completely disconnected.
2. **Mounting:** Select a suitable location for the control panel, typically an indoor wall at an accessible height. Secure the control panel to the wall using appropriate fasteners (not included), ensuring it is level and stable.
3. **Wiring:** Connect the wire controller to the main system unit using the designated wiring terminals. Refer to the wiring diagram provided with your main system for specific connection points. Ensure correct polarity and secure all wire connections.
4. **Power Connection:** Once all wiring is complete and verified, restore power to the system. The control panel should power on and display its initial screen.

## 5. OPERATING INSTRUCTIONS

---

The YDCC-B Wire Controller Display Control Panel provides an interface for managing your connected system. Specific functions may vary based on the main system it is connected to.

- **Power On/Off:** Press the designated power button (if available) to turn the display on or off.
- **Navigation:** Use the arrow buttons (Up, Down, Left, Right) to navigate through menu options on the display.
- **Selection/Confirmation:** Press the 'Enter' or 'OK' button to select an option or confirm a setting.
- **Mode Selection:** Access the 'Mode' menu to select operating modes (e.g., heating, cooling, fan only).
- **Temperature Adjustment:** Use the Up/Down arrows to adjust the desired temperature setting.
- **Fan Speed:** Adjust fan speed settings through the appropriate menu.
- **Timer/Schedule:** If supported by your system, set timers or operating schedules via the control panel interface.

## 6. MAINTENANCE

---

- **Cleaning:** Gently wipe the display and casing with a soft, dry, lint-free cloth. For stubborn marks, slightly dampen the cloth with water. Do not use chemical cleaners.
- **Inspection:** Periodically check the wiring connections for any signs of wear or looseness. Ensure the control panel is securely mounted.
- **Software Updates:** If your system supports software updates for the control panel, follow the manufacturer's instructions for performing these updates.

## 7. TROUBLESHOOTING

---

- **No Display/Power:**
  - Check the main power supply to the system.
  - Verify all wiring connections between the control panel and the main system.
  - Ensure the control panel's power button (if applicable) is engaged.
- **Incorrect Readings/Functionality:**
  - Ensure the control panel is correctly configured for your specific system.
  - Restart the main system and the control panel by cycling the power.
  - Consult the manual for your main system for compatibility and configuration details.

- **Buttons Unresponsive:**

- Gently clean around the buttons to ensure no debris is obstructing them.
- Perform a power cycle of the control panel.

If issues persist, contact your system installer or the manufacturer for further assistance.

## 8. SPECIFICATIONS

Feature	Specification
Model Number	9514285429148
Brand	Generic
Compatibility	RHMYDCC-B-TH, WVH-02-GY, YORK-WCT-004-HL, SAP:1199118, 025W46984-000
Number of Items	1
Batteries Required	No
Country/Region of Origin	China

## 9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact the seller directly. The warranty period and terms are subject to the policies of the retailer or manufacturer at the time of purchase.