

[Manuals.plus](#) /

> [VOCIC](#) /

> VOCIC AX35 PRO Movable Electric Chair Lift User Manual

VOCIC AX35 PRO

VOCIC AX35 PRO Movable Electric Chair Lift User Manual

Model: AX35-PRO-A-BK-X

1. INTRODUCTION

Thank you for choosing the VOCIC AX35 PRO Movable Electric Chair Lift. This manual provides essential information for the safe and effective operation, assembly, and maintenance of your new chair lift. Please read this manual thoroughly before initial use and retain it for future reference. This device is designed to assist individuals with limited mobility in transitioning from a seated position on the floor to standing or sitting, and for short-distance transfers.

2. SAFETY INFORMATION

Your safety and the safety of the user are paramount. Adhere to all warnings and instructions provided in this manual.

- **Maximum Weight Capacity:** Do not exceed the maximum weight capacity of 440 pounds (200 kg).
- **Safety Belt:** Always ensure the adjustable, heavy-duty safety belt is properly secured around the user before initiating any lifting or movement to prevent accidental slips.
- **Supervision:** This device is intended for use by elderly individuals and those with limited mobility. Appropriate supervision is recommended during operation.
- **Clear Area:** Ensure the area around the chair lift is clear of obstructions before operating.
- **Stable Surface:** Operate the chair lift on a flat, stable, and level surface.
- **Power Source:** Use only the provided charging cable and adapter. Do not use damaged cables or adapters.
- **Modifications:** Do not attempt to modify the chair lift. Unauthorized modifications can compromise safety and void the warranty.
- **Emergency Stop:** Familiarize yourself with the remote control's functions, including any emergency stop features.

3. PRODUCT OVERVIEW

The VOCIC AX35 PRO is an advanced electric chair lift designed for comfort, stability, and ease of use. Key features include:

- **Rapid Floor-to-Stand Recovery:** Engineered to provide a smooth, stable lift from the floor to a standing or sitting position with one-button operation.

- **Premium Comfort & Pressure Relief:** Features a composite seat with high-density sponge and a supportive wooden base for firm yet plush cushioning, distributing body pressure effectively.
- **Ultimate Stability with Dual-Lead Screws:** An advanced dual-lead screw motor structure ensures ultra-steady vertical lifting, minimizing wobbling.
- **Enhanced Mobility & Easy Transfers:** Equipped with four high-quality caster wheels for smooth short-distance mobility. Flip-up armrests create space for lateral transfers.
- **Comprehensive Safety Design:** Includes an adjustable, heavy-duty safety belt and a reinforced frame for a secure environment.
- **Heavy-Duty Weight Capacity:** Supports users up to 440 pounds with robust construction.

Included Components

The VOCIC AX35 PRO package typically includes the following items:

- Lift Chair Base
- Seat Cushion & Backrest
- Safety Belt
- Remote Control
- Charging Cable & Adapter
- User Manual
- Assembly Tools



Figure 3.1: Included Components

4. SETUP

The VOCIC AX35 PRO is designed for quick and straightforward assembly.

1. **Unpack Components:** Carefully remove all components from the packaging and verify that all items listed in Section 3 are present.
2. **Attach Handles:** Secure the handles to the main lift chair base using the provided assembly tools and screws. Ensure they are firmly attached.
3. **Install Seat and Backrest:** Place the seat cushion and backrest onto the designated areas of the frame. These typically click into place or are secured with minimal fasteners.
4. **Initial Charge:** Before first use, connect the charging cable and adapter to the chair lift and a power outlet. Allow the battery to fully charge. The indicator light on the remote control or charging unit will typically change color to indicate a full charge.
5. **Safety Check:** Once assembled and charged, perform a brief functional test without a user to ensure all

mechanisms operate smoothly.

5. OPERATING INSTRUCTIONS

Follow these steps for safe and effective operation of the VOCIC AX35 PRO.

5.1. Preparing for Use

- Ensure the chair lift is fully charged.
- Position the chair lift on a stable, level surface near the user.
- Ensure the area around the chair is clear of any obstacles.

5.2. Lifting from the Floor

1. **Position the Chair:** Carefully slide the chair lift's base under the user while they are on the floor, ensuring the seat is in its lowest position (2.4 inches from the ground).
2. **Assist User onto Seat:** Help the user to sit comfortably and securely on the chair lift's seat.
3. **Secure Safety Belt:** Fasten the safety belt around the user's waist and adjust it for a snug, secure fit.
4. **Initiate Lift:** Using the remote control, press and hold the 'Up' button. The chair will smoothly and steadily lift the user to the desired height.
5. **Transfer:** Once at a suitable height (e.g., standing or level with a bed/wheelchair), assist the user in transferring. The flip-up armrests can be raised to facilitate lateral transfers.
6. **Lowering:** To lower the chair, press and hold the 'Down' button on the remote control.




Figure 5.1: Floor-to-Stand Recovery

5.3. Short-Distance Mobility

The AX35 PRO features caster wheels for easy movement.

- Ensure the user is securely seated and the safety belt is fastened.
- Gently push or pull the chair lift using the handles to move it over short distances.
- Avoid moving the chair lift over uneven surfaces or thresholds that could cause instability.

Softer, more comfortable



Figure 5.2: Effortless Gliding with Upgraded Casters

6. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your VOCIC AX35 PRO.

- **Cleaning:** Wipe down all surfaces with a soft, damp cloth. Use mild soap if necessary. Avoid abrasive cleaners or solvents. Ensure no liquid enters electrical components.
- **Battery Care:** Recharge the battery regularly, even if the chair lift is not in frequent use, to maintain battery health. Avoid completely draining the battery.
- **Inspection:** Periodically inspect the frame, seat, safety belt, and wheels for any signs of wear, damage, or loose components.
- **Lubrication:** The dual-lead screw mechanism is designed for low maintenance. Do not attempt to lubricate internal components unless specifically instructed by VOCIC support.
- **Storage:** Store the chair lift in a dry, cool place away from direct sunlight and extreme temperatures.



Figure 6.1: Sturdy Carbon Steel Frame

7. TROUBLESHOOTING

If you encounter issues with your VOCIC AX35 PRO, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Chair does not lift or lower.	Battery is low or depleted. Power cable is disconnected. Remote control malfunction.	Charge the battery fully. Ensure power cable is securely connected. Check remote control battery (if applicable) or contact support.
Chair movement is jerky or unstable.	Overload (exceeding weight capacity). Uneven surface. Loose components.	Ensure user weight is within limits. Move to a flat, stable surface. Inspect for loose screws and tighten if necessary.
Remote control is unresponsive.	Remote control battery is low or dead. Connection issue.	Replace remote control batteries (if applicable). Ensure remote is within range and properly paired (if wireless).
Unusual noises during operation.	Foreign object obstruction. Component wear.	Inspect for any obstructions. If noise persists, discontinue use and contact customer support.

If the problem persists after attempting these solutions, please contact VOCIC customer support for assistance.

8. SPECIFICATIONS

Detailed technical specifications for the VOCIC AX35 PRO Movable Electric Chair Lift.

Feature	Specification
Brand	VOCIC
Model Name	AX35 PRO
Model Number	AX35-PRO-A-BK-X
Color	Black
Materials	Aluminum, Carbon Steel, Leather, High-Density Sponge
Product Dimensions (D x W x H)	14"D x 15.7"W x 19.7"H (seated position)
Item Weight	40 pounds (18.1 kg)
Maximum Weight Capacity	440 pounds (200 kg)
Seat Depth	14 inches
Seat Height (Min/Max)	2.4 inches / 19.7 inches
Indoor/Outdoor Usage	Indoor
UPC	810190251829



Figure 8.1: Product Dimensions and Weight



Figure 8.2: Premium Leather and Memory Foam Seat

9. WARRANTY AND SUPPORT

VOCIC is committed to providing high-quality products and customer satisfaction.

9.1. Warranty Information

The VOCIC AX35 PRO comes with lifetime support. Please refer to your purchase documentation for specific warranty terms and conditions, which may cover manufacturing defects and operational failures under normal use.

9.2. Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty claims, please contact VOCIC customer support:

- **Website:** Visit the official VOCIC website (link not provided in source data)
- **Email:** Contact support via email (email address not provided in source data)
- **Phone:** Call our customer service line (phone number not provided in source data)

Please have your model number (AX35-PRO-A-BK-X) and purchase date available when contacting support.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GH6B3H3R>

More documents and user manuals: **<https://manuals.plus/>**