

[Manuals.plus](#) /

› [Garvee](#) /

› Garvee 13 Gallon Battery Powered Sprayer with Wheeled Cart User Manual

Garvee B0GH6QBF1F

Garvee 13 Gallon Battery Powered Sprayer with Wheeled Cart User Manual

Model: B0GH6QBF1F

1. INTRODUCTION

Thank you for choosing the Garvee 13 Gallon Battery Powered Sprayer with Wheeled Cart. This electric sprayer is designed for efficient and convenient application of liquids for lawn care, gardening, and other tasks. Featuring an 18V 4Ah battery, adjustable pressure, and multiple nozzles, it provides a versatile solution for your spraying needs. Please read this manual thoroughly before operation to ensure safe and effective use.



Image: The Garvee 13 Gallon Battery Powered Sprayer with Wheeled Cart, showcasing its main design.

Large Capacity & Long Battery Life

50L



Image: The Garvee sprayer in use, highlighting its 13-gallon (50L) capacity, 18V 4Ah battery, 4-6 hour runtime, and 80 PSI maximum pressure.

2. SAFETY INFORMATION

WARNING: Read all safety warnings and instructions. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- Always wear appropriate personal protective equipment (PPE) such as gloves, eye protection, and a mask when operating the sprayer, especially when handling chemicals.
- Do not spray flammable liquids, strong acids, or corrosive chemicals. Use only liquids recommended for sprayers.
- Keep children and pets away from the spraying area.

- Ensure all connections are tight before operation to prevent leaks.
- Do not immerse the battery or motor unit in water.
- Charge the battery in a well-ventilated area, away from flammable materials.
- Store the sprayer in a cool, dry place, out of reach of children.
- Disconnect the battery before performing any maintenance or cleaning.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Garvee 13 Gallon Sprayer Unit with Wheeled Cart
- 1 x 18V 4Ah Battery
- 1 x Battery Charger
- 6 x Interchangeable Nozzles (Single head plastic, Flower, Fan-shaped, Brass, Three-heads, Two-end plastic)
- 2 x Wands (one metal, one plastic)
- 1 x 50ft Hose
- 1 x Roll of Teflon Tape
- 1 x User Manual (this document)

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your Garvee sprayer.



Image: Diagram showing key components including Kit Box, 50ft hose, Trigger-Lock, 9-inch wheel, 4000mAh battery, and 3-6 hour runtime indicator.

- **Tank:** 13-gallon capacity for liquid solutions.
- **Wheeled Cart:** For easy mobility and transportation.
- **Handle:** Ergonomic design for comfortable pulling/pushing.
- **Battery Compartment:** Houses the 18V 4Ah battery.
- **Hose:** 50ft long for extended reach.
- **Wands:** Includes a metal wand (adjustable length) and a plastic wand.
- **Nozzles:** Six types for various spray patterns.
- **Control Panel:** Features a power switch, voltmeter, charger socket, and pressure regulating knob.
- **Trigger Lock:** For continuous spraying and reduced hand fatigue.

Durable Design, Superior Battery



Anti Clogging



Durable Hose



18V 4AH



Image: Close-up of the sprayer highlighting durable design, anti-clogging filter (5.12in diameter), durable hose, and the 18V 4Ah battery.

5. SETUP

5.1. Assembly

1. **Attach the Lid:** Securely place the lid onto the tank opening.
2. **Connect the Hose:** Attach the 50ft hose to the sprayer unit and the wand. Ensure all connections are tight to prevent leaks. Use the provided Teflon tape on threaded connections if necessary.
3. **Attach the Wand:** Connect your preferred wand (metal or plastic) to the hose.
4. **Select and Attach Nozzle:** Choose one of the six interchangeable nozzles and attach it to the end of the wand.

5.2. Battery Installation and Charging

1. **Install Battery:** Open the battery compartment and insert the 18V 4Ah battery. Ensure it clicks into place.
2. **Initial Charge:** For first-time use, fully charge the battery. Connect the charger to the charger socket on the control panel and plug it into a standard electrical outlet. The voltmeter will indicate charging status.
3. **Charging Time:** A full charge typically takes 4-6 hours. Do not overcharge.

6. OPERATING INSTRUCTIONS

6.1. Filling the Tank

1. Ensure the sprayer is on a level surface.
2. Remove the tank lid.
3. Carefully pour the desired liquid solution into the 13-gallon tank. Do not overfill.
4. Replace the tank lid securely.

6.2. Selecting and Adjusting Nozzles

The sprayer comes with 6 interchangeable nozzles for various applications:

Multi-Function Nozzle-6 Nozzles



Image: Visual representation of the six nozzle types: Single head plastic, Flower, Fan-shaped, Brass, Three-heads, and Two-end plastic nozzles.

- **Single Head Plastic Nozzle:** General purpose, adjustable stream.
- **Flower Nozzle:** Gentle, wide spray for delicate plants.
- **Fan-shaped Nozzle:** Flat, even spray for broad coverage.
- **Brass Nozzle:** Durable, adjustable stream for various tasks.
- **Three-Heads Nozzle:** Increased coverage with multiple streams.
- **Two-End Plastic Nozzle:** Dual stream for targeted application.

To change a nozzle, unscrew the current nozzle from the wand and screw on the desired one. Ensure it is hand-tight.

6.3. Powering On and Spraying

1. Turn on the power switch located on the control panel. The voltmeter will illuminate, indicating battery charge.
2. Adjust the pressure regulating knob to your desired spray pressure (up to 80 PSI).

3. Point the wand towards the target area and press the trigger on the handle to begin spraying.
4. For continuous spraying, engage the trigger lock by pushing it forward while the trigger is pressed. Release the trigger lock to stop continuous spraying.
5. When finished, release the trigger and turn off the power switch.



Image: Close-up of the sprayer's control panel, showing the power switch, voltmeter, charger socket, and pressure regulating knob for easy access and operation.



Image: The ergonomic handle of the Garvee sprayer, highlighting the trigger lock feature for comfortable, continuous spraying and reduced hand fatigue.

6.4. Usage Scenarios



Image: Various applications of the Garvee sprayer, including garden spraying, pet bathing, use in vegetable greenhouses, and car cleaning, demonstrating its versatility.

7. MAINTENANCE

7.1. Cleaning After Use

1. Empty any remaining liquid from the tank.
2. Rinse the tank thoroughly with clean water.
3. Fill the tank with clean water and spray for a few minutes to flush the hose, wand, and nozzle.
4. Clean the exterior of the sprayer with a damp cloth. Do not use harsh chemicals.
5. Remove and clean nozzles separately to prevent clogging.

7.2. Battery Care and Storage

- Store the battery in a cool, dry place, away from direct sunlight and extreme temperatures.
- For long-term storage, charge the battery to approximately 50% capacity.
- Recharge the battery every 3-6 months during storage to maintain its lifespan.

7.3. General Storage

- Store the sprayer in a dry, frost-free environment.
- Ensure the tank is empty and clean before storage.
- Keep the sprayer out of reach of children.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Sprayer not turning on	Battery not charged or improperly installed. Power switch off.	Ensure battery is fully charged and correctly inserted. Turn on the power switch.
No spray or weak spray	Tank empty. Nozzle clogged. Pressure setting too low. Hose kinked.	Refill tank. Clean nozzle. Increase pressure with regulating knob. Straighten hose.
Leaks from connections	Loose connections. Worn O-rings/seals.	Tighten all hose and wand connections. Apply Teflon tape if needed. Inspect and replace O-rings/seals if damaged.
Wand connector broke	Excessive force or material fatigue.	Contact Garvee customer support for replacement parts. Handle with care during use and storage.

9. SPECIFICATIONS

Feature	Detail
Brand	Garvee
Model	B0GH6QBF1F
Tank Volume	13 Gallons (50 Liters)
Battery	18V 4Ah Lithium-ion
Runtime	4-6 Hours (Max)
Maximum Pressure	80 PSI
Hose Length	50 feet
Nozzles Included	6 (Single head plastic, Flower, Fan-shaped, Brass, Three-heads, Two-end plastic)
Wands Included	2 (Metal, Plastic)
Item Weight	28.4 pounds
Dimensions (W x H)	15.75"W x 25.2"H (Sprayer Unit)

Product Dimensions



Image: Detailed product dimensions for the Garvee sprayer, including the main unit (37in H, 18.1in W, 16.5in D), and the two wands (38.6in and 19.7in).

10. WARRANTY AND SUPPORT

Garvee products are designed for reliability and performance. While specific warranty details are not provided in this manual, we recommend retaining your proof of purchase.

For warranty claims, technical support, or replacement parts, please contact Garvee customer service through the retailer where you purchased the product or visit the official Garvee website.

Garvee Store Link: [Visit the Garvee Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question