

## Outsunny 84C-583V00CW

# Outsunny 3 x 2.5m Garden Pergola Instruction Manual

Model: 84C-583V00CW

[Information](#) [Setup](#) [Operation](#) [Maintenance](#) [Overview](#) [Safety](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

## 1. PRODUCT OVERVIEW

---

The Outsunny 3 x 2.5m Garden Pergola is designed to enhance your outdoor living space, providing shade and shelter. This pergola features a robust metal frame and a weather-resistant polyester roof, making it suitable for various outdoor settings.

- **Weather-Resistant Roof:** Constructed from durable 180 g/m<sup>2</sup> polyester, the roof offers protection against light rain and includes 16 drainage holes to prevent water accumulation.
- **Robust Construction:** The powder-coated metal frame ensures enhanced stability and longevity. Ground stakes and expansion screws are provided for secure outdoor fastening.
- **Wall-Mounted Design:** This lean-to pergola is designed for wall attachment, seamlessly extending your indoor comfort to the fresh air of your garden.
- **Versatility:** With its elegant curved design, this outdoor pergola is ideal for various uses such as a barbecue area, spa shelter, or an outdoor dining space.



Image 1.1: The Outsunny Garden Pergola providing shade over a seating area on a wooden deck.



Image 1.2: Another view of the Outsunny Garden Pergola enhancing an outdoor living space.

## 2. SAFETY INFORMATION

---

Please read and understand all safety instructions before assembly and use of the pergola.

- **Weather Conditions:** Do not use the pergola in strong winds or storms. High winds can cause structural damage or collapse, leading to injury or property damage.
- **Secure Anchoring:** It is crucial to anchor the structure securely to the ground or wall for safe use. Use the provided ground stakes for soft ground or expansion screws for hard surfaces.
- **Assembly:** Ensure all components are correctly assembled and tightened according to the instructions to maintain structural integrity.
- **Regular Inspection:** Periodically check all connections and anchoring points to ensure they remain secure.



Image 2.1: Illustration of stable positioning using ground stakes for soft ground and expansion screws for hard ground.

### 3. SETUP AND ASSEMBLY

---

Assembly of the Outsunny Garden Pergola is required. It is recommended to have at least two people for assembly. Please follow the detailed instructions provided in the separate assembly manual (if applicable) or the included diagrams.

#### 3.1. Before You Begin

- Unpack all components and verify against the parts list.
- Ensure you have all necessary tools (e.g., wrench, screwdriver).
- Choose a flat, stable surface for installation, preferably against a sturdy wall for the wall-mounted design.

#### 3.2. Assembly Steps (General Guidelines)

1. Assemble the main metal frame components, ensuring all bolts are finger-tight initially.
2. Attach the wall-mounted section to a suitable, sturdy wall using appropriate fasteners (not always included, depending on wall type).
3. Connect the freestanding support posts to the main frame.

4. Once the frame is complete, securely tighten all bolts.
5. Install the polyester roof fabric, ensuring it is taut and correctly positioned to allow for water drainage.
6. Anchor the pergola to the ground using the provided ground stakes or expansion screws, as appropriate for your surface.

## 4. OPERATION AND USAGE

---

The Outsunny Garden Pergola is designed for providing shade and light rain protection in your outdoor space.

- **Shade Provision:** The polyester roof effectively blocks sunlight, creating a comfortable shaded area for relaxation or dining.
- **Rain Protection:** The 180 g/m<sup>2</sup> polyester roof is resistant to light rain. The integrated 16 drainage holes are designed to prevent water from pooling on the canopy, which could otherwise cause damage or collapse.
- **Versatile Use:** Utilize the pergola for various outdoor activities such as hosting barbecues, creating a cozy spa retreat, or setting up an elegant outdoor dining area.




Image 4.1: The waterproof roof with drainage holes, demonstrating its weather-resistant features.



## PERGOLA ADOSSÉE AU MUR

Prolongez votre intérieur vers l'extérieur,  
agrandissez votre maison

Image 4.2: The wall-mounted design seamlessly integrates with your home, extending your living space outdoors.



Image 4.3: The pergola creating a comfortable outdoor dining area.

## 5. MAINTENANCE

---

Proper maintenance will extend the life and appearance of your Outsunny Garden Pergola.

- **Cleaning the Frame:** Clean the metal frame with a damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals that could damage the powder coating.
- **Cleaning the Canopy:** The polyester canopy can be cleaned with a soft brush, water, and mild soap. Rinse thoroughly and allow to air dry completely before storage or re-installation.
- **Seasonal Storage:** During periods of strong winds, heavy snow, or when not in use for extended periods, it is recommended to remove the canopy to prevent damage. Store the canopy in a dry, protected area.
- **Anchoring Check:** Regularly inspect the ground stakes or expansion screws to ensure they remain firmly anchored. Re-tighten or re-secure as needed.

## 6. TROUBLESHOOTING

---

Here are some common issues and their potential solutions:

- **Water Accumulation on Canopy:** Ensure the canopy is installed correctly and taut. Verify that all 16 drainage holes are clear of debris. If water still pools, check the frame for any bending or unevenness that might prevent proper water runoff.
- **Pergola Instability:** Check all frame connections and ensure bolts are securely tightened. Verify that the ground stakes or expansion screws are firmly in place and the pergola is properly anchored to the wall. If installed on soft ground, ensure stakes are driven deep enough.
- **Difficulty with Assembly:** Refer to the detailed assembly instructions and diagrams. Ensure all parts are correctly identified and oriented. Do not force parts together; if a part does not fit, re-check the instructions.
- **Damage from Wind:** If the pergola was exposed to strong winds, inspect the frame for any bends or cracks and the canopy for tears. In such cases, replacement parts may be necessary. Always remove the canopy in anticipation of strong winds.

## 7. SPECIFICATIONS

---

<b>Brand</b>	Outsunny
<b>Model Number</b>	84C-583V00CW
<b>Material</b>	Metal, Polyester
<b>Color</b>	Cream
<b>Item Weight</b>	21 Kilograms
<b>Product Dimensions (L x W x H)</b>	2.98L x 2.48W x 2.5H meters
<b>Floor Area</b>	6.8 square meters
<b>Minimum Ceiling Height</b>	200 centimeters
<b>Cover</b>	Rain-resistant polyester roof with drainage holes
<b>UV Protection</b>	Yes
<b>Water Resistance Level</b>	Waterproof
<b>Assembly Required</b>	Yes



Image 7.1: Detailed dimensions of the pergola.

## 8. WARRANTY AND SUPPORT

---

### 8.1. Manufacturer's Warranty

This Outsunny Garden Pergola comes with a **2-year manufacturer's warranty**. Please retain your proof of purchase for any warranty claims. The warranty covers defects in materials and workmanship under normal use.

### 8.2. Customer Support

For any questions, concerns, or assistance with your product, please contact our Specialized Customer Support. Refer to your purchase documentation or the retailer's website for contact details.

When contacting support, please have your model number (84C-583V00CW) and purchase date readily available.

