

[Manuals.plus](#) /

› [Ninja](#) /

› Ninja HyperHeat 9-in-1 Electric Pressure Cooker | 6.5 Qt Multi Cooker | PC201GY Instruction Manual

Ninja PC201GY

Ninja HyperHeat 9-in-1 Electric Pressure Cooker Instruction Manual

Model: PC201GY | Brand: Ninja

INTRODUCTION

Welcome to your new Ninja HyperHeat 9-in-1 Electric Pressure Cooker. This versatile appliance is designed to simplify your cooking process, offering multiple functions in one compact unit. Please read this manual thoroughly before first use to ensure safe and optimal operation. This multi-cooker features HyperHeat technology for faster cooking and a PFAS-free SimpliServe pot for easy cleanup.

WHAT'S INCLUDED

Your Ninja HyperHeat Pressure Cooker package includes the following components:

- 1200-Watt Powerful HyperHeat™ Base
- 6.5-qt Removable SimpliServe Pot (PFAS-free nonstick ceramic-coated)
- Pressure Cooker Lid
- Quick Start Guide with 5+ Chef-Developed Recipes

9 Unique Cooking Functions



PRESSURE



PASTA



SOUS VIDE



SLOW COOK



SEAR/SAUTÉ



YOGURT



RICE



STEAM



KEEP WARM

Image: Components of the Ninja HyperHeat Pressure Cooker, including the main unit, SimpliServe pot, and pressure lid.

PRODUCT OVERVIEW

The Ninja HyperHeat Pressure Cooker combines multiple cooking functions into a single appliance, featuring a user-friendly control panel and a durable design. Its 9.5-inch diameter cooking surface provides ample space for various culinary tasks.



Image: Front view of the Ninja HyperHeat 9-in-1 Electric Pressure Cooker in dark gray, showcasing its control panel and sleek design.



Image: A lifestyle image of the Ninja HyperHeat Pressure Cooker on a kitchen counter with various cooked dishes, highlighting its multi-functionality.

INITIAL SETUP AND FIRST USE

Follow these steps before using your appliance for the first time:

1. **Unpacking:** Carefully remove all components from the packaging. Remove any stickers or protective films.
2. **Cleaning:** Wash the SimpliServe Pot and pressure cooker lid with warm, soapy water. Rinse thoroughly and dry completely. Wipe the main unit with a damp cloth.
3. **Placement:** Place the main unit on a clean, dry, level surface away from walls and heat sources. Ensure adequate ventilation.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

Your browser does not support the video tag.

Video: This video demonstrates the unboxing and initial setup of the Ninja HyperHeat Pressure Cooker, including placing the pot and lid.

OPERATING INSTRUCTIONS

Your multi-cooker offers 9 unique cooking functions. Use the control dial and buttons to select your desired function, temperature, and time.



Image: Diagram illustrating the 1200-watt heating system and HyperHeat technology for faster cooking.

Pressure Cook

Use the Pressure Cook function for rapid cooking of meals. Ensure the pressure lid is securely locked and the pressure release valve is in

the SEAL position. HyperHeat technology builds pressure quickly to speed up cooking time.

Your browser does not support the video tag.

Video: This video demonstrates the pressure cooking function, highlighting its speed and large capacity for various dishes.

Slow Cook

For tender, flavorful results over an extended period, select the Slow Cook function. Use the pressure lid with the valve in the VENT position, or a compatible glass lid (not included).

Sear/Sauté

This function allows you to brown meats and sauté vegetables directly in the SimpliServe Pot before other cooking methods, building rich flavors. The wide 9.5" diameter surface gives you more room to sear and sauté evenly without overcrowding.



COOK
Sear & sauté with a large cooking surface

SERVE
Serve up to 10 dishes in one cook

HOST
Easily transfer the SimpliServe Pot™ from cooker to table

EVERYTHING YOU NEED

Pressure Release Valve
Easily release pressure.

Pressure Lid

Image: Image showing the versatile cooking surface being used for searing and sautéing ingredients directly in the pot.

Rice/Pasta

Prepare perfect rice and pasta with dedicated settings. Follow recipe guidelines for liquid ratios and cooking times. White rice can be made in as little as 8 minutes or quinoa in as little as 5 minutes (excludes time to build and release pressure).



Fast Rice & Grains

Quinoa in as little as 5 minutes*.
White rice in as little as 8 minutes*.

*EXCLUDES TIME TO BUILD PRESSURE AND RELEASE

Image: Image showing cooked rice being served from the SimpliServe pot, emphasizing fast cooking for grains.

Sous Vide

Achieve precise and consistent cooking results for meats, fish, and vegetables using the Sous Vide function.

Steam

Gently cook vegetables, seafood, and more using the Steam function. Ensure adequate water in the pot and use a steaming rack if provided (not included).

Yogurt

Make homemade yogurt with ease using the Yogurt function.



Family-Sized Capacity

6.5-qt cooking pot fits up to 4 lbs of braised meat or a 5-lb roast. Feeds 8-10 people.

Image: Image of homemade yogurt with fruit and granola, illustrating the yogurt-making capability.


Keep Warm

The Keep Warm function automatically activates after some cooking cycles to maintain food at a serving temperature.

CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and performance of your Ninja HyperHeat Pressure Cooker.

- **Unplug:** Always unplug the unit before cleaning.
- **SimpliServe Pot:** The removable ceramic nonstick pot is 100% PFAS-free and designed for easy cleaning. It is dishwasher safe.
- **Lid:** Wash the pressure cooker lid and its components (gasket, pressure release valve) with warm, soapy water. Ensure all food residue is removed. The lid is dishwasher safe.
- **Main Unit:** Wipe the exterior of the main unit with a clean, damp cloth. Never immerse the main unit in water.



Effortless At-Home Yogurt

Enjoy fresh, preservative-free yogurt. Great for breakfast bowls, smoothies, or a guilt-free snack.

Image: A person cleaning the removable SimpliServe pot under running water in a sink, demonstrating its easy cleanup.

TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

- **Unit not powering on:** Ensure the power cord is securely plugged into a grounded electrical outlet.
- **Pressure not building:** Check that the pressure lid is correctly sealed and the pressure release valve is in the SEAL position. Ensure sufficient liquid is in the pot.
- **Food not cooking evenly:** Ensure the pot is not overcrowded. For searing/sautéing, use the wide 9.5" diameter surface to avoid overcrowding.
- **Error codes:** Refer to the Quick Start Guide for specific error code meanings and resolutions.

PRODUCT SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	Ninja
Model Number	PC201GY
Capacity	6.5 Quarts
Wattage	1200 watts
Material	Stainless steel (exterior), Ceramic nonstick (pot)
Color	Grey
Product Dimensions	13.89"D x 14.76"W x 12.24"H
Item Weight	15.9 Pounds
Control Method	Push Button, Digital Dial
Dishwasher Safe	Yes (Removable Pot)



Image: Image displaying the dimensions of the Ninja HyperHeat Pressure Cooker: 13.89 inches deep, 14.76 inches wide, and 12.24 inches high.

WARRANTY AND CUSTOMER SUPPORT

For detailed warranty information, product registration, or further assistance with your Ninja HyperHeat Pressure Cooker, please refer to the Quick Start Guide included with your product. You may also visit the official Ninja website for comprehensive support resources and frequently asked questions.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

The QR code for recipes on my Ninja PC201GY HyperHeat Pressure Cooker is not working; where can I find a working link?

It is common for printed QR codes on Quick Start Guides to become outdated or point to broken links. While the specific URL for the Ninja PC201GY recipe book is not provided in the...

[Read full answer](#)