Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aoxun G30043-1010LG

Aoxun 10' x 10' Outdoor Wood Gazebo Instruction Manual

Model: G30043-1010LG | Brand: Aoxun

1. Introduction

Thank you for choosing the Aoxun 10' x 10' Outdoor Wood Gazebo. This manual provides essential information for the safe assembly, operation, and maintenance of your new gazebo. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Figure 1: Assembled Aoxun 10' x 10' Outdoor Wood Gazebo.

2. Safety Information

To ensure safe use and prevent injury or damage, please adhere to the following safety guidelines:

- Always assemble this gazebo on a flat, stable surface.
- Secure the gazebo to the ground using the provided hardware to prevent tipping.
- Do not leave children unattended near the gazebo.
- This gazebo is heavy and may not be suitable for all surfaces.
- Always follow the assembly instructions carefully to avoid injury.
- Consult a professional if you are unsure about any aspect of the assembly or use of this product.

3. Product Features

- **Widened Cedar Wood Frame:** Features 4.7"x4.7" cedar wood columns for enhanced strength and stability, complementing outdoor aesthetics.
- **Dual Roof Design:** Innovative double roof promotes airflow for cooling and allows efficient rain and snow runoff, providing year-round protection.
- **All-Weather Suitability:** Designed to withstand 15 inches of snow loading depth and wind resistance up to 9 (47-54mph) when secured with expansion bolts.
- **Versatile Ceiling Hooks:** Includes ceiling hooks with a capacity of up to 44 lbs, suitable for hanging fans, lights, or heaters.
- **Timeless Design:** Classic and elegant design seamlessly integrates with various yard or patio styles.



Figure 2: Key product details and features.



Figure 3: Illustration of the wider wood frame for improved stability.



Figure 4: All-weather suitability and wind resistance rating.

4. Setup and Assembly

Assembly of the Aoxun Wood Gazebo requires careful attention to detail. It is recommended to have 3 people for assembly, with an estimated installation time of 3.5 hours. Necessary tools include a 2m ladder, level, socket wrench, Phillips screwdriver, pistol drill, and protective gloves.

4.1 Pre-Assembly Checklist

- Check all parts against the packing list and sort them before installation.
- Ensure the ground surface is level and stable.
- Wear protective gloves during assembly.

4.2 Assembly Video Guide

Your browser does not support the video tag.

Video 1: Detailed installation video for the Aoxun wooden pavilion. (Duration: 4:23)

Your browser does not support the video tag.

Video 2: Overview of the Aoxun Outdoor Wood Gazebo assembly. (Duration: 0:32)

4.3 Step-by-Step Assembly (Refer to videos for visual guidance)

1. **Assemble the Base Frame:** Connect the main wooden beams (parts 01-07) using the specified connectors and screws. Ensure all connections are secure.
2. **Install Corner Brackets:** Attach the corner brackets (B2) to the top of the main posts (part 20) and secure them with bolts (AA, BB, JJ, KK).
3. **Erect the Posts:** Carefully raise the assembled posts and connect them to form the main structure.
4. **Assemble the Top Frame:** Connect the metal top frame components (G, H, N, Q) as per the instructions, ensuring all bolts (LL) are tightened.
5. **Install Roof Panels:** Remove the protective film from the roof panels (R2, R3, R4, R7, R8, R9) and carefully attach them to the top frame using the provided screws (LL, GG, RR).
6. **Secure the Gazebo:** For permanent installation, fix the gazebo to the ground. For soft foundations, use anchoring stakes. For hard foundations, use expansion bolts (QQ) and a 6mm drill bit.

5. Operating Instructions

Your Aoxun Wood Gazebo is designed for versatile outdoor use. The dual roof system provides natural ventilation, keeping the area comfortable. The integrated ceiling hooks allow for customization with outdoor fans, lighting, or heaters (ensure these accessories are suitable for outdoor use and properly installed).

6. Maintenance

Regular maintenance will prolong the life and appearance of your gazebo:

- **Cleaning:** Clean the wood frame and metal roof panels periodically with mild soap and water. Avoid harsh chemicals that may damage the finish.
- **Wood Care:** Inspect the cedar wood frame annually for any signs of wear, rot, or insect damage. Apply a wood sealant or stain as needed to protect the wood from weathering.
- **Fasteners:** Periodically check all bolts and screws to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.
- **Snow Removal:** While the roof is designed for snow loading, heavy accumulation should be cleared to prevent excessive stress on the structure.

7. Troubleshooting

If you encounter any issues with your gazebo, consider the following:

- **Stability Issues:** Ensure all fasteners are securely tightened. Verify that the gazebo is installed on a level surface and properly anchored to the ground.
- **Water Leakage:** Check that all roof panels are correctly installed and overlapping as designed. Ensure all screws are tight and any seals are intact.
- **Missing or Damaged Parts:** If you find any parts missing or damaged upon unpacking, please contact Aoxun customer support immediately for assistance.

8. Specifications

Attribute	Detail
Brand	Aoxun
Model Number	G30043-1010LG
Product Dimensions	120"L x 120"W x 120"H (10' x 10' x 10')
Item Weight	370 Pounds
Frame Material	Wood (Cedar) and Metal
Roof Material	Galvanized Steel
Water Resistance Level	Waterproof
Ultraviolet Light Protection	Yes
Assembly Required	Yes
Color	Gray

9. Warranty and Support

Aoxun offers a 30-day easy return policy for this product. For any questions, concerns, or support needs regarding your gazebo, please contact Aoxun Direct customer support. Details for contacting customer support can typically be found on the product packaging or the retailer's website where the purchase was made.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GHQ4FZC1

More documents and user manuals: **https://manuals.plus/**