

[Manuals.plus](#) /

› [WAMPAT](#) /

› WAMPAT Farmhouse TV Stand with Charging Station (Model W01FA097A+W11F4046A-TS-N1-US)

WAMPAT W01FA097A+W11F4046A-TS-N1-US

WAMPAT Farmhouse TV Stand with Charging Station

Model: W01FA097A+W11F4046A-TS-N1-US

Brand: WAMPAT

1. INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your WAMPAT Farmhouse TV Stand. This versatile 3-in-1 unit can function as a TV console, a kitchen sideboard, or an entryway console table, and includes an integrated charging station. Please read these instructions carefully before assembly and use to ensure safe and proper operation.



Figure 1.1: Fully assembled WAMPAT Farmhouse TV Stand.

2. SAFETY INFORMATION

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and retighten as necessary.
- Do not overload the shelves or drawers. Distribute weight evenly.
- Keep small parts and packaging materials away from children and pets to prevent choking hazards.
- The unit features curved edges to minimize accidental injuries, especially in households with children.
- For the charging station, use only with compatible devices and ensure the power cable is not pinched or damaged.

3. PACKAGE CONTENTS

Your WAMPAT Farmhouse TV Stand is shipped in three separate packages. Please ensure all packages have arrived before beginning assembly. Carefully unpack all components and verify against the included parts list (not provided in this document, refer to your physical manual) to ensure all pieces are present and undamaged.

Display Personality

Comes With
2
Packages



Figure 3.1: Individual component dimensions of the TV stand.

The packages typically contain:

- Main cabinet panels and hardware
- Two side table panels and hardware
- Drawers, doors, and associated hardware
- Integrated charging station with power cable
- Assembly instructions (physical copy)

4. SETUP AND ASSEMBLY

Assembly of the WAMPAT Farmhouse TV Stand is designed to be straightforward. Follow the detailed step-by-step instructions provided in your physical assembly manual. It is recommended to have two people for assembly to ensure stability and ease of handling larger components.

4.1 Assembly Steps Overview:

1. **Unpack and Identify Parts:** Lay out all panels and hardware. Match them with the parts list in your manual.
2. **Assemble the Main Cabinet:** Follow the instructions to construct the central TV console unit.
3. **Assemble the Side Tables:** Construct the two individual side tables. Note that one side table includes the charging station.
4. **Install Drawers and Doors:** Attach the smooth metal drawer sliders and hang the cabinet doors.
5. **Connect Charging Station:** Ensure the charging station is properly installed in the designated side table and the power cable is routed safely.
6. **Final Placement:** Position the assembled units as desired. They can be used together as a large TV stand or separately as a main cabinet and two side tables.



Figure 4.1: The TV stand can be configured as a single unit or as a main cabinet with two separate side tables.

5. OPERATING INSTRUCTIONS

5.1 Using the Charging Station

One of the side tables is equipped with a charging station. To use it:

1. Plug the 6.5-foot power cable into a standard wall outlet.
2. The charging station provides two standard AC outlets and two USB ports.
3. Connect your electronic devices (e.g., mobile phones, tablets, lamps) to the appropriate ports for charging.



120V/12A
{2 AC Outlets}



120V/12A
{2 USB Ports}



6.5-Foot
{Power Cord}

Figure 5.1: Detail of the charging station with AC and USB ports.

5.2 Storage and Display

The TV stand features three sliding drawers and three storage cabinets, offering ample space for various items:

- **Drawers:** Ideal for smaller items, remotes, or personal belongings. The smooth metal drawer sliders ensure easy opening and closing.
- **Cabinets:** Suitable for media devices, books, DVDs, or decorative items. The internal shelves provide organized storage.



Figure 5.2: Example of a side table used for storage and display.

6. MAINTENANCE

6.1 Cleaning

The rustic white finish and distressed wood surface are designed for easy maintenance:

- Wipe the surface with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- The surface is waterproof, allowing for easy cleanup of spills.



Figure 6.1: The waterproof surface allows for easy cleaning.

6.2 General Care

- Periodically check all connections and tighten any loose screws to maintain stability.
- Avoid placing extremely hot or cold items directly on the surface without protection.
- Keep the unit away from direct sunlight and excessive humidity to prevent material degradation.

7. TROUBLESHOOTING

If you encounter any issues with your WAMPAT Farmhouse TV Stand, refer to the following common solutions:

- **Wobbly Unit:** Ensure all screws are fully tightened. Check that the unit is placed on a level surface. Adjust the feet if applicable.
- **Drawers Not Sliding Smoothly:** Verify that the drawer sliders are correctly installed and aligned. Ensure no obstructions are present in the tracks.
- **Charging Station Not Working:** Check that the power cable is securely plugged into both the unit and a functional wall outlet. Test the outlet with another device. Ensure devices are properly connected to the AC or USB ports.
- **Missing Parts:** If you find any parts missing during assembly, please contact WAMPAT customer service immediately.

8. SPECIFICATIONS

Feature	Detail
Model Number	W01FA097A+W11F4046A-TS-N1-US
Overall Dimensions (L x W x H)	66.9 x 15.7 x 30.9 inches (170 x 40 x 78.5 cm)
Main Cabinet Dimensions (L x W x H)	33.9 x 15.7 x 30.9 inches (86 x 40 x 78.5 cm)
Side Table Dimensions (L x W x H)	16.5 x 15.7 x 30.9 inches (42 x 40 x 78.5 cm)
Material	High-grade Certified MDF (Wood)
Color	Rustic White
TV Size Compatibility	Up to 75 inches
Storage	3 Sliding Drawers, 3 Storage Cabinets, 6 Shelves
Charging Station	2 AC Outlets, 2 USB Ports
Power Cable Length	6.5 feet




Figure 8.1: TV size compatibility for the WAMPAT TV stand.

9. WARRANTY AND SUPPORT

WAMPAT is committed to providing professional service and support for its products. While specific warranty details are not provided in this document, if you have any questions, concerns, or require assistance with your WAMPAT Farmhouse TV Stand, please do not hesitate to contact WAMPAT customer service. Refer to your purchase documentation or the WAMPAT official website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question