



[Manuals.plus](#) /

> [Fire-Boltt](#) /

> Fire-Boltt Aero Glide Open Ear Wireless TWS Earbuds User Manual

Fire-Boltt BE1700

Fire-Boltt Aero Glide Open Ear Wireless TWS Earbuds User Manual

Model: BE1700

INTRODUCTION

Thank you for choosing the Fire-Boltt Aero Glide Open Ear Wireless TWS Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds. Please read it carefully before use to ensure optimal performance and longevity of your device.

WHAT'S IN THE BOX

- Fire-Boltt Aero Glide Open Ear Wireless TWS Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual

PRODUCT OVERVIEW

The Fire-Boltt Aero Glide earbuds feature an open-ear design for comfort and situational awareness, along with advanced audio technologies.

FIRE⚡**BOLTT**

(Aero)
Glide



Image: Fire-Boltt Aero Glide earbuds and their compact charging case.



Image: Close-up of an earbud, highlighting the speaker grille and charging contacts.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case. Place the earbuds into the charging case. Connect the USB charging cable to the charging port on the case and to a power source. The indicator light on the case will show charging status.

MINIMAL MODERN MAGNETIC



Image: Earbuds correctly placed in the charging case for power replenishment.

- **Charging Time:** Approximately 3 hours for a full charge.
- **Fast Charging:** 5 minutes of charging provides up to 300 minutes of playback.
- **Battery Life:** Up to 50 hours total playback with the charging case.

2. Pairing with Your Device

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing LED light.
3. On your device (smartphone, tablet, etc.), go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices and select "Fire-Boltt Aero Glide" from the list.
5. Once connected, the LED indicator on the earbuds will stop flashing.

The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

1. Wearing the Earbuds

The Aero Glide earbuds feature an open-ear design with an earhook for a secure and comfortable fit. Gently place the earbud over your ear, ensuring the speaker is positioned near your ear canal without entering it. Adjust the earhook for stability.

<h1>SECURE FIT</h1>	Forget you're wearing them. Our ergonomic open-ear fit delivers weightless, pressure-free fit for all-day listening comfort.
-------------------------	--



The image shows a woman with braided hair wearing a white Aero Glide earbud. Three callout boxes point to specific features: 'Skin-friendly Earhook' at the bottom left, 'Enhanced Air Circulation' at the top right, and 'Less Earwax Buildup' at the middle right. In the top left corner of the image area, there are two vertical arrows, one pointing up and one pointing down, indicating the placement of the earbud.

Image: Proper placement of the open-ear earbud for a secure and comfortable fit.

2. Touch Controls

The earbuds are equipped with touch-sensitive controls for easy management of audio and calls. Specific functions can be customized via the FirePods App.

Action	Function
Single Tap	Play/Pause Music, Answer/End Call
Double Tap (Left Earbud)	Previous Track
Double Tap (Right Earbud)	Next Track
Triple Tap	Activate Voice Assistant
Long Press (2 seconds)	Reject Call, Toggle Gaming Mode (customizable)

3. FirePods App and Custom EQ

Download the FirePods App from your device's app store to unlock full customization options. The app allows you to:

- Personalize sound with custom EQ modes.
- Adjust touch control functions.
- Switch themes within the app.
- Monitor battery levels of each earbud and the charging case.



Image: The FirePods App displaying various equalizer presets and customization options.

4. Gaming Mode (Low Latency)

Activate the 50ms ultra-low latency gaming mode for synchronized audio during gaming or video playback. This mode minimizes audio delay, providing a more immersive experience. Refer to the FirePods App or your customized touch controls for activation.

5. Calling with Quad Mic ENC

The earbuds feature Quad Mic Environmental Noise Cancellation (ENC) to reduce background noise during calls, ensuring clear voice transmission. This is automatically active during phone calls.




Image: Exploded view illustrating the Quad Mic setup for Environmental Noise Cancellation.

MAINTENANCE

1. Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Ensure charging contacts on both earbuds and case are clean and free of debris to maintain proper charging.

2. Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place away from extreme temperatures and direct sunlight.

TROUBLESHOOTING

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Place earbuds back in case, close, then reopen to re-enter pairing mode. Try pairing with another device to rule out device issues.
Only one earbud working	Place both earbuds back in the charging case, close the lid, wait a few seconds, then open again. Ensure both earbuds are charged. Re-pair the earbuds with your device.
Low volume or poor sound quality	Check device volume. Ensure earbuds are clean and free of debris. Adjust EQ settings in the FirePods App. Ensure earbuds are properly seated on your ears.
Charging issues	Ensure the charging cable is securely connected. Check the charging contacts on both earbuds and case for dirt or obstruction. Try a different USB port or charging adapter.
Earbuds disconnect frequently	Ensure your device is within the Bluetooth range (typically 10 meters/33 feet). Avoid obstacles between the earbuds and your device. Close and reopen the charging case to reset the connection.

SPECIFICATIONS

Feature	Detail
Model Name	FirePods Aero Luxe (BE1700)
Brand	Fire-Boltt
Ear Placement	Open Ear
Form Factor	True Wireless
Bluetooth Version	5.4
Playtime (with case)	Up to 50 Hours
Fast Charging	5 min charge = 300 min playback
Low Latency	50ms (Gaming Mode)
Noise Control	Quad Mic Environmental Noise Cancellation (ENC)
Water Resistance	IPX4
Control Type	Touch, App Control
Impedance	32 Ohms
Frequency Response	20,000 Hz
Item Weight	30 Grams

WARRANTY AND SUPPORT

The Fire-Boltt Aero Glide Open Ear Wireless TWS Earbuds come with a **1-year brand warranty** from the date of purchase. This warranty covers manufacturing defects.

For warranty claims, technical support, or any inquiries, please contact Fire-Boltt customer service. Contact details can typically be found on the official Fire-Boltt website or on the product packaging.

Manufacturer: Boltt Games Pvt Ltd