

## ghd 99400000388

# Ghd Speed Ionic Hair Dryer User Manual

Model: Speed (99400000388)

## 1. INTRODUCTION

Thank you for choosing the Ghd Speed Ionic Hair Dryer. This advanced hair dryer is designed to provide efficient and controlled hair drying with innovative features. Please read this manual thoroughly before first use to ensure safe operation and optimal performance.

The Ghd Speed features ghd halo technology with dual hot and cold airflow, a powerful brushless DC motor, and multiple heat and speed settings for a customized drying experience.

## 2. SAFETY INFORMATION

**Important Safety Instructions:** When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- Always unplug the appliance immediately after use.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- If an appliance falls into water, unplug it immediately. Do not reach into the water.
- This appliance is for household use only.
- Do not operate any appliance with a damaged cord or plug, or if the appliance malfunctions or has been dropped or damaged in any manner.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.

- Do not direct hot air towards eyes or other heat-sensitive areas.
- Attachments may be hot during use. Allow them to cool before handling.
- Do not place the appliance on any surface while it is operating.
- Always store the appliance in a location free from moisture.

### 3. PRODUCT OVERVIEW

The Ghd Speed Ionic Hair Dryer is engineered for professional-grade performance and user comfort.

#### Key Features:

- **Ghd Halo Technology:** Dual hot & cold airflow for reduced hair temperature and zero heat damage.
- **Powerful Brushless DC Motor:** Delivers highly concentrated airflow up to 176 km/h for fast drying.
- **Multiple Settings:** Four heat levels and four speed settings for precise control.
- **Cool Shot Button:** For setting your style.
- **Control Lock Button:** Recalls stored settings.
- **Ergonomic Design:** Professional and comfortable to handle.
- **Magnetic Attachments:** Secure and cool-to-touch for easy removal.
- **Universal Voltage:** Suitable for worldwide use.



Figure 3.1: Ghd Speed Ionic Hair Dryer, main unit.



Figure 3.2: Illustration of ghd halo dual airflow technology.



Figure 3.3: Overview of available magnetic attachments (some sold separately).

## 4. SETUP

1. **Unpacking:** Carefully remove the hair dryer and all accessories from the packaging. Retain packaging for storage or future transport.
2. **Inspect:** Check the appliance for any signs of damage. Do not use if damaged.
3. **Attach Nozzle:** Select the desired magnetic attachment (e.g., concentrator nozzle) and securely attach it to the front of the hair dryer. The magnetic connection ensures a firm fit.
4. **Power Connection:** Plug the hair dryer into a suitable electrical outlet (220-240V).

## 5. OPERATING INSTRUCTIONS

1. **Power On:** Press the power button to turn on the hair dryer.
2. **Adjust Speed:** Use the speed control button to select one of the four airflow speeds. The current setting will be indicated on the digital display.

3. **Adjust Heat:** Use the heat control button to select one of the four heat levels. The current setting will be indicated on the digital display.
4. **Cool Shot:** Press and hold the cool shot button for a burst of cool air to set your style.
5. **Control Lock:** To prevent accidental changes during use, press the control lock button. This will lock the current speed and heat settings. Press again to unlock.
6. **Drying Technique:**
  - For general drying, hold the hair dryer at a comfortable distance from your hair, moving it continuously to avoid concentrating heat in one area.
  - For voluminous styling, pre-dry hair to approximately 80%. Then, using a brush and the concentrator nozzle, lift sections of hair from the roots and direct airflow downwards.
  - For straightening, use the concentrator nozzle and a brush to pull sections of hair taut while directing airflow along the hair shaft.
7. **Power Off:** Press the power button again to turn off the hair dryer. Unplug the appliance from the power outlet after use.



Figure 5.1: Demonstrating use with cool-to-touch feature.



Figure 5.2: Using the hair dryer with a comb attachment (attachment sold separately).

## 6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Ghd Speed Ionic Hair Dryer.

- **Cleaning the Air Filter:** Periodically check and clean the rear air filter to prevent lint and dust buildup, which can affect performance and lead to overheating.
  - a. Ensure the hair dryer is unplugged and completely cool.
  - b. Gently twist or pull off the rear filter cover (refer to product diagram if unsure).
  - c. Remove any accumulated lint or dust using a soft brush or cloth. Do not use water.
  - d. Replace the filter cover securely.
- **Cleaning the Exterior:** Wipe the exterior of the hair dryer with a soft, damp cloth. Do not use abrasive cleaners or

solvents.

- **Storage:** When not in use, store the hair dryer in a dry, safe place. Do not wrap the power cord tightly around the appliance, as this can damage the cord.

## 7. TROUBLESHOOTING

If you encounter issues with your Ghd Speed Ionic Hair Dryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Hair dryer does not turn on.	No power supply. Damaged power cord/plug.	Ensure the hair dryer is properly plugged into a working outlet. Check for tripped circuit breakers. If cord/plug is damaged, do not use and contact customer support.
Weak airflow or overheating.	Blocked air intake filter.	Unplug the hair dryer and allow it to cool. Clean the rear air filter as described in the Maintenance section.
Settings change unexpectedly.	Control lock not activated.	Activate the control lock button during use to prevent accidental changes.
Unusual noise or smell.	Internal malfunction.	Immediately unplug the hair dryer and discontinue use. Contact customer support.

If the problem persists after attempting these solutions, please contact Ghd Customer Support.

## 8. SPECIFICATIONS

- **Model Name:** Speed
- **Model Number:** 99400000388
- **Brand:** ghd
- **Color:** White
- **Power:** 2100 watts
- **Voltage:** 220-240 Volts
- **Number of Heat Settings:** 4
- **Number of Speed Settings:** 4
- **Airflow Speed:** Up to 176 km/h
- **Drying Technology:** Brushless DC motor, ghd Halo Technology (dual hot & cold airflow)
- **Product Dimensions (DxWxH):** 33 x 9.7 x 24.4 cm
- **Item Weight:** 816 grams
- **Material:** Plastic
- **Country of Origin:** China
- **Recommended Uses:** Drying, Straightening
- **Hair Type:** All hair types

## 9. WARRANTY AND SUPPORT

Ghd products are manufactured to the highest quality standards. For information regarding your product's warranty, please refer to the warranty card included with your purchase or visit the official Ghd website.

For technical support, troubleshooting assistance, or to inquire about replacement parts and accessories, please contact Ghd Customer Support through their official website or the contact information provided in your product packaging.

**Official Ghd Website:** [www.ghdhair.com](http://www.ghdhair.com)

