

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [De'Longhi](#) /

› [De'Longhi TrueBrew CAM51035M Drip Coffee Maker Instruction Manual](#)

## De'Longhi CAM51035M

# De'Longhi TrueBrew CAM51035M Drip Coffee Maker Instruction Manual

Model: CAM51035M | Brand: De'Longhi

## 1. IMPORTANT SAFEGUARDS

---

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and personal injury, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off," then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the brewing cycles.

## 2. PRODUCT OVERVIEW

---

The De'Longhi TrueBrew Drip Coffee Maker offers a versatile brewing experience with integrated grinding and multiple customization options.

### Key Features:

- **Built-in Conical Burr Grinder:** Ensures fresh coffee by grinding whole beans for each brew.
- **Bean Extract Technology:** Automatically grinds, doses, and brews for optimal flavor.
- **6 Brew Sizes:** From 3 oz espresso style to 40 oz carafe, including 8 oz, 12 oz, 16 oz, and 24 oz cup sizes.
- **5 Brew Styles:** Light, Gold, Bold, Over Ice, and Espresso Style.
- **Zero Waste:** Eliminates the need for plastic pods or paper filters, using only whole beans.

### Included Components:

- De'Longhi TrueBrew Coffee Maker
- 40 oz Carafe
- Measuring Scoop
- Water Hardness Test Kit

### Product Dimensions:



Figure 1: Product dimensions of the De'Longhi TrueBrew Coffee Maker. The unit measures approximately 12 inches wide, 15 inches deep, and 15.8 inches high.

### One-Touch Simplicity:

# ONE-TOUCH SIMPLICITY



Select from 6 sizes & 5 brew types

Figure 2: The control panel allows for easy selection of 6 sizes and 5 brew types with a single touch.

**Bean Extract Technology:**

# BEAN EXTRACT TECHNOLOGY



Automatically  
Grinds, Doses & Brews



Built-in  
Burr Grinder



6 Sizes,  
5 Styles

Figure 3: De'Longhi's proprietary technology ensures optimal flavor by automatically grinding, dosing, and brewing each cup.

## **Built-in Burr Grinder:**

# BUILT-IN BURR GRINDER



Freshly Ground  
Coffee

Explore Bean  
Varieties

Bypass for  
Ground Coffee

Figure 4: The built-in conical burr grinder allows for freshly ground coffee, exploration of various bean varieties, and a bypass option for pre-ground coffee.

## Easy-to-Read Indicators:

# EASY-TO-READ INDICATORS



Figure 5: The clear display indicates brewing status and features a built-in clock for convenience.

## 3. SETUP

### 3.1 Initial Cleaning

Before first use, wash all removable parts (water tank, carafe, filter basket, drip tray) with warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the machine with a damp cloth.

### 3.2 Water Tank Installation and Filling

Remove the water tank from the side of the unit. Fill it with fresh, cold water up to the MAX line indicated on the tank. Ensure the tank is securely placed back into its position on the coffee maker.

### 3.3 Bean Hopper Filling

Open the lid of the bean hopper located on top of the machine. Pour whole coffee beans into the hopper. Close the lid securely. The machine will automatically grind the required amount for each brew.

### 3.4 First Use Rinse Cycle

To prime the system and clean any manufacturing residue, perform a rinse cycle without coffee. Fill the water tank to the MAX level. Place the empty carafe on the warming plate. Select a large brew size (e.g., 40 oz carafe) and initiate a brew cycle. Discard the hot water after the cycle is complete.

### Setup and Initial Use Demonstration:

Video 1: This video demonstrates the initial setup and first use procedures for a similar coffee maker, including filling the water tank and performing a rinse cycle. Note: The video features a CM6110 model, but the general setup steps are applicable.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Power On

Press the power button on the control panel to turn on the coffee maker. The display will illuminate.

### 4.2 Select Brew Size

Use the 'Size' selection buttons to choose your desired brew volume: 3 oz (espresso style), 8 oz, 12 oz, 16 oz, 24 oz, or 40 oz (carafe). Place the appropriate cup or carafe under the dispenser.

### 4.3 Select Brew Style/Strength

Use the 'Strength' selection buttons to choose your preferred coffee strength: Light, Gold, Bold, Over Ice, or Espresso Style.

### 4.4 Start Brewing

Once your selections are made, press the 'Brew' button. The machine will begin grinding beans (if whole beans are in the hopper) and then start the brewing process. The display will show 'Brewing In Progress'.

### 4.5 Using Pre-Ground Coffee

If using pre-ground coffee, open the bypass chute (refer to product diagram for location) and add the desired amount of ground coffee using the provided scoop. Ensure the bean hopper is empty or the grinder is set to 'Grind Off' (if applicable). Select your brew size and style, then press 'Brew'.

### 4.6 Delay Brew Function

To set a delayed brew, fill the water tank and bean hopper (or add ground coffee). Press the 'Delay Brew' button and use the time adjustment buttons to set your desired brew time. Confirm the settings, and the machine will start brewing automatically at the programmed time.

## 5. MAINTENANCE AND CLEANING

---

### 5.1 Daily Cleaning

- **Carafe and Lid:** Wash with warm, soapy water after each use.
- **Filter Basket:** Remove and rinse the filter basket. Discard used coffee grounds.
- **Drip Tray:** Empty and clean the drip tray regularly to prevent overflow and maintain hygiene.
- **Exterior:** Wipe down the exterior of the machine with a soft, damp cloth.

### 5.2 Grinder Cleaning

Regular cleaning of the conical burr grinder is essential for optimal performance and flavor. Refer to the product manual for detailed instructions on how to disassemble and clean the burr grinder components. Use the provided brush to remove any residual coffee grounds.

### 5.3 Descaling

Over time, mineral deposits (limescale) can build up in your coffee maker, affecting performance and taste. The machine may have a 'Clean' indicator or a recommended descaling schedule. Use a descaling solution specifically designed for coffee makers, following the manufacturer's instructions. Typically, this involves running a solution through the machine, followed by several rinse cycles with fresh water.

## 6. TROUBLESHOOTING

---

If your De'Longhi TrueBrew coffee maker is not functioning as expected, please consult the following common issues and solutions:

Problem	Possible Cause	Solution
Coffee not brewing	No water in tank; machine not powered on; brew cycle not initiated.	Fill water tank; ensure power is on; press 'Brew' button.
Weak coffee	Insufficient coffee grounds; 'Light' strength selected; clogged grinder.	Add more beans/grounds; select 'Bold' or 'Gold' strength; clean grinder.
Grinder jammed	Foreign object in grinder; beans too oily or moist.	Unplug and carefully remove any obstructions; use drier beans.
Water leaking	Water tank not properly seated; drip tray full.	Ensure water tank is correctly installed; empty and clean drip tray.

## 7. SPECIFICATIONS

---

- **Brand:** De'Longhi
- **Model Name:** TrueBrew Drip Coffee Maker
- **Model Number:** CAM51035M
- **Color:** Stainless
- **Material:** Stainless Steel
- **Special Feature:** Auto Shut-Off, Integrated Coffee Grinder, Programmable, Thermal
- **Specific Uses For Product:** Coffee Maker, Espresso Style Coffee, Iced Coffee
- **Included Components:** Carafe, De'Longhi True Brew Coffee Maker, Measuring Scoop, Water Hardness Test
- **Voltage:** 120 Volts
- **Product Dimensions:** 15 x 12 x 15.8 inches
- **Item Weight:** 20.1 pounds
- **Capacity:** 3.8 Pounds (referring to bean hopper capacity or overall capacity, typically for water/beans)
- **UPC:** 728434146803

## 8. WARRANTY AND SUPPORT

---

For warranty information, product registration, and customer support, please refer to the official De'Longhi website or the documentation included with your product. You can also scan the QR code below for more information, FAQs, and live demonstrations.

# HAVE A QUESTION?



**Get Started**

Schedule your live demonstration, FAQ's and more...



Screenshot and tap the QR Code for more



**CALL US:**  
**(866) 528-8323**

Figure 6: Scan this QR code for quick access to support resources.

Alternatively, visit: <https://qrco.de/bdYTYB>

For direct assistance, you may call: (866) 528-8323