

[Manuals.plus](#) /

› [Frigidaire](#) /

› Frigidaire Touchscreen Nugget Ice Maker EFIC2320BLK Instruction Manual

## Frigidaire EFIC2320BLK

# Frigidaire Touchscreen Nugget Ice Maker EFIC2320BLK Instruction Manual

Model: EFIC2320BLK

## 1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Frigidaire Touchscreen Nugget Ice Maker, Model EFIC2320BLK. This countertop ice machine produces soft, chewable nugget ice, ideal for various beverages. Please read all instructions carefully before initial use and retain this manual for future reference.

# SLEEK AND PRACTICAL ICE MAKER

PRODUCES UP TO 33 LBS. OF NUGGET ICE DAILY



Figure 1.1: Frigidaire Touchscreen Nugget Ice Maker (Slate)

## 2. SAFETY INFORMATION

To prevent personal injury or property damage, observe all safety precautions. This appliance is for household use only.

- Always unplug the ice maker before cleaning or performing any maintenance.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure the power outlet is properly grounded.
- Keep the ice maker away from heat sources and direct sunlight.
- Do not operate the appliance with a damaged cord or plug.
- Supervise children when the appliance is in use.
- Use only potable water in the water tank.
- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

### 3. PACKAGE CONTENTS

---

Verify that all items are present in the packaging:

- Frigidaire Touchscreen Nugget Ice Maker
- Ice Bin
- Ice Scoop
- Drip Tray
- Instruction Manual (this document)

### 4. PRODUCT OVERVIEW AND FEATURES

---

The Frigidaire Touchscreen Nugget Ice Maker is designed for convenience and performance, producing up to 33 lbs of nugget ice daily.

#### Key Features:

- **Soft Chewable Nugget Ice:** Produces light, crunchy, chewable ice.
- **Effortless Touchscreen Control:** Intuitive LED control panel for managing ice production.
- **Automatic Cleaning Cycle:** Self-cleaning function for easy maintenance.
- **Manual Fill Design:** No plumbing required; features a 1.8 L water tank.
- **Generous Ice Storage:** Holds 1.2 L (approximately 0.7 kg) of nugget ice.
- **Smart Status Indicators:** Alerts for "Add Water," "Ice Full," "Ice Making," and "Water Level."
- **Interior Illumination:** Built-in light for clear visibility of ice levels.



Figure 4.1: Key Features

# Intuitive Digital LED Control Panel



**Add Water  
Notification**



**Ice Full  
Notification**



**Ice Making  
Notification**



**Automated  
Self-cleaning**



*Figure 4.2: Intuitive Digital LED Control Panel*

## 5. SETUP

Follow these steps for initial setup of your ice maker.

### 5.1 Unpacking and Placement

1. Remove all packaging materials and inspect the ice maker for any damage.
2. Place the ice maker on a flat, stable surface, away from direct sunlight and heat sources. Ensure there is adequate ventilation around the unit (at least 5 inches of space on all sides).
3. Allow the unit to stand upright for at least 2 hours before plugging it in, especially if it was transported horizontally. This allows the refrigerant to settle.

### 5.2 Power Connection

1. Ensure the voltage indicated on the appliance matches your local power supply.
2. Plug the power cord into a grounded electrical outlet.

## 5.3 Filling the Water Tank

1. Open the water tank lid located on top of the unit.
2. Fill the water tank with potable water up to the MAX fill line. Do not overfill.
3. Close the water tank lid securely.

## 6. OPERATING INSTRUCTIONS

---

Learn how to make and dispense ice with your new Frigidaire ice maker.

### 6.1 Initial Ice Production

1. After filling the water tank and plugging in the unit, press the **Ice/Clean** button on the touchscreen control panel to begin ice production. The "Ice Making" indicator will illuminate.
2. The first batch of ice nuggets will be ready in approximately 10-15 minutes.
3. Discard the first 2-3 batches of ice to ensure cleanliness.

### 6.2 Dispensing Ice

1. Place a glass or container under the ice dispenser chute.
2. Press the ice dispensing lever or button (refer to control panel diagram) to release ice.
3. Release the lever/button to stop dispensing.

# Fast, Chewable Nugget Ice at Home

Enjoy soft, restaurant-style nugget ice at home. This ice maker delivers perfectly chewable ice - faster and more enjoyable than standard hard cubes - right from your countertop.



Figure 6.1: Fast, Chewable Nugget Ice

## 7. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your ice maker.

### 7.1 Automatic Self-Cleaning Cycle

1. Ensure the water tank is filled with clean water.
2. Press and hold the **Ice/Clean** button for 3 seconds to activate the self-cleaning cycle. The "Clean" indicator will illuminate.
3. The cycle will run for approximately 20 minutes.
4. Once complete, drain any remaining water from the unit (refer to manual for drain plug location).

### 7.2 Manual Cleaning

1. Unplug the ice maker from the power outlet.
2. Remove the ice bin and wash it with mild soap and warm water. Rinse thoroughly and dry.

3. Wipe the interior of the ice maker with a soft cloth dampened with a mild detergent solution. Rinse with a clean, damp cloth.
4. Clean the exterior with a soft, damp cloth.
5. Ensure all parts are completely dry before reassembling and operating the unit.

## 8. TROUBLESHOOTING

Refer to this table for common issues and their solutions.

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in tank; Power issue; Unit too warm.	Fill water tank; Check power connection; Ensure proper ventilation.
"Add Water" indicator is on.	Water tank is empty or low.	Refill the water tank with potable water.
"Ice Full" indicator is on.	Ice bin is full.	Remove ice from the ice bin.
Ice has an unusual taste or odor.	Stale water; Unit needs cleaning.	Replace water; Run self-cleaning cycle or perform manual cleaning.
Unit is noisy.	Normal operation sounds; Unit not level.	Ensure unit is on a flat, stable surface. Some operational noise is normal.

## 9. SPECIFICATIONS

Technical details for the Frigidaire Touchscreen Nugget Ice Maker.

Specification	Detail
Brand	Frigidaire
Model Name	EFIC2320BLK
Product Dimensions (D x W x H)	16.75" x 11.75" x 20.25"
Capacity (Ice Production per Day)	33 Pounds
Wattage	192 watts
Voltage	120 Volts
Refrigerant	R410a
Material Type	Plastic, Stainless Steel
Water Tank Capacity	1.8 Liters
Ice Storage Capacity	1.2 Liters (approx. 0.7 kg)



FRIGIDAIRE is a pending or registered trademark of Electrolux Consumer Products, Inc. and used under a license from Electrolux Consumer Products, Inc.

Figure 9.1: Product Dimensions

## 10. WARRANTY AND SUPPORT

Your Frigidaire Touchscreen Nugget Ice Maker comes with a 1-year limited warranty. For warranty claims or technical support, please contact Frigidaire customer service. Keep your purchase receipt as proof of purchase.

For further assistance, please visit the official Frigidaire support website or contact their customer service line. Contact information can typically be found on the manufacturer's website or on the product packaging.