

FDW Dining Chairs Set of 4

FDW Dining Chairs Set of 4 Instruction Manual

Model: Dining Chairs Set of 4 (Brown PU Leather with Wood Legs)

1. INTRODUCTION

Thank you for choosing the FDW Dining Chairs Set of 4. These chairs are designed to provide comfort and style to your dining area, kitchen, restaurant, or living room. Featuring abrasion and stain-resistant thickened PU leather on both the seat and backrest, they offer durability and ease of cleaning. The simple and modern design ensures they blend seamlessly with various decor styles. The legs are constructed from robust rubberwood for long-term stability and use.

Please read this manual carefully before assembly and use to ensure proper setup and maintenance.

2. SAFETY INFORMATION

- Ensure all screws and bolts are tightened securely before use. Periodically check and re-tighten as necessary.
- Do not stand on the chairs.
- Avoid placing chairs near open flames or excessive heat sources.
- Keep small parts away from children during assembly.
- Do not exceed the maximum weight capacity (specific weight capacity not provided, use with reasonable care).

3. PACKAGE CONTENTS

Before beginning assembly, please verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 4 x FDW Dining Chair Seats with Backrests
- 4 x Sets of Chair Legs (for 4 chairs)
- 1 x Hardware Pack (screws, washers, Allen wrench)
- 1 x Assembly Instruction Sheet

4. SETUP AND ASSEMBLY

Assembly is straightforward and typically takes 10-15 minutes per chair. All necessary tools are included.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Legs to Seat:** Align the chair legs with the pre-drilled holes on the underside of the chair seat. Ensure the legs are oriented correctly (refer to the included diagram if available).
3. **Secure Legs:** Insert the provided screws and washers into the holes. Hand-tighten all screws initially.
4. **Final Tightening:** Once all legs are in place, use the Allen wrench to fully tighten all screws. Ensure they are snug but do not overtighten to avoid damaging the wood.
5. **Check Stability:** Place the assembled chair on a flat surface and gently test its stability. If it wobbles, loosen the screws slightly, press down on the seat to level it, and then re-tighten the screws.



Figure 4.1: This diagram illustrates the key dimensions of the FDW dining chair, including seat height, seat depth, backrest height, and overall width and depth, measured in inches.

Strong Woden Leg Chair

- The legs of the chair are made of rubber wood, which is very strong stable and stable.



Strong woden leg



Solid Wood

Figure 4.2: A visual representation of the chair's solid rubberwood legs, emphasizing their durability and stability.

5. OPERATING INSTRUCTIONS

These dining chairs are designed for seating purposes in various indoor environments. To ensure optimal use and longevity:

- Use the chairs on a flat, stable surface.
- Sit centrally on the seat to distribute weight evenly.
- Avoid sudden movements or excessive force when sitting down.
- The ergonomic backrest is designed to provide comfort and support, promoting good posture during meals.

Ergonomic Backrest

- An ergonomic dining chair is designed to provide comfort and support while promoting good posture during meals.



Figure 5.1: A detailed view of the chair's backrest, emphasizing its ergonomic curve designed for comfort and support.

Learther Dining Chair

- The chair is made of PU leather and soft sponge, durable, easy to clean.



Precise Suture



PU Leather Surface

Figure 5.2: This image highlights the texture of the PU leather upholstery, the soft sponge padding, and the quality of the stitching on the chair's seat and backrest.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your FDW dining chairs.

- **Cleaning the PU Leather:** The PU leather surface is waterproof and easy to clean. Wipe spills immediately with a soft, damp cloth. For general cleaning, use a mild soap solution and a soft cloth, then wipe dry. Avoid harsh chemicals or abrasive cleaners.
- **Wood Legs Care:** Wipe wood legs with a dry or slightly damp cloth. Avoid excessive moisture.
- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Protection:** The chairs are equipped with anti-slip footpads to protect your floors and enhance stability. Ensure these remain intact.

Product Details



Waterproof



Considerable thickness



Anti-Slip footpads



Figure 6.1: This image showcases specific features such as the waterproof surface of the PU leather, the thickness of the cushioning, and the anti-slip footpads on the chair legs for floor protection and stability.

7. TROUBLESHOOTING

- **Chair is Wobbly:**

Ensure all screws connecting the legs to the seat are fully tightened. If wobbling persists, loosen all leg screws slightly, place the chair on a flat surface, apply even pressure to the seat to level it, then re-tighten all screws firmly.

- **Difficulty Aligning Screw Holes:**

Sometimes, screw holes may not align perfectly. Try rotating the leg or seat component to find a better fit. Do not force screws; if significant misalignment occurs, contact customer support for assistance.

- **Missing or Damaged Parts:**

Before assembly, carefully check the package contents against the list in Section 3. If any parts are missing or damaged, do not proceed with assembly. Contact customer support immediately for replacement parts.

8. SPECIFICATIONS

Feature	Detail
Brand	FDW
Model Name	Dining Chairs Set of 4
Colour	Brown
Material	PU Cushion, Rubberwood
Product Dimensions (D x W x H)	57D x 44W x 88H centimetres (22.56D x 17.3W x 34.6H inches)
Item Weight	22.68 kg (for the set)
Back Style	Solid Back
Frame Material	Rubberwood
Seat Material Type	Polyurethane
Upholstery Fabric Type	PU Leather
Included Components	4 Chairs, Assembly Tools
Assembly Required	Yes (approx. 10-15 minutes per chair)

9. WARRANTY AND SUPPORT

Your FDW Dining Chairs are designed for quality and durability. While specific warranty details are not provided, the product is typically eligible for return, refund, or replacement within 30 days of receipt, in accordance with standard retail policies.

For any questions, concerns, or assistance with assembly or parts, please contact the retailer or manufacturer directly. Please have your purchase information and product model (FDW Dining Chairs Set of 4, Model: B0GHXGC8TS) ready when contacting support.

© 2023 FDW. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question