

[Manuals.plus](#) /

› [Decofy](#) /

› Decofy Fluted Nightstand with Charging Station Instruction Manual

Decofy DC-BG04

Decofy Fluted Nightstand with Charging Station Instruction Manual

Model: DC-BG04

INTRODUCTION

Thank you for choosing the Decofy Fluted Nightstand with Charging Station. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: The Decofy Fluted Nightstand in Natural Oak, featuring its curved profile, fluted drawers, and a charging station on top.

SAFETY INFORMATION

- Always assemble the nightstand on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload the drawers or shelves. The maximum weight recommendation for the nightstand is 110 pounds.
- Keep small parts and packaging materials away from children and pets to avoid choking hazards.
- Do not expose the charging station to liquids. Ensure hands are dry when plugging or unplugging devices.
- Use only with compatible electronic devices. Do not attempt to modify the charging station.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact Decofy customer support.

- Nightstand Panels (Top, Bottom, Sides, Back)
- Drawer Components (Fronts, Sides, Backs, Bottoms)
- Drawer Slides (Metal)
- Drawer Handles

- Charging Station Unit (Pre-installed or separate)
- Assembly Hardware (Screws, dowels, cam locks, hex bolts)
- Tools (Allen Key, Screwdriver)
- Assembly Guide

Product Dimension



Image: Diagram showing the overall dimensions of the nightstand (19.6" W x 15.5" D x 24" H) and individual drawer dimensions (16.2" W x 11.7" D x 6" H).

SETUP AND ASSEMBLY

Assembly is required for this nightstand. Follow the step-by-step instructions provided in the included Assembly Guide. For visual assistance, please refer to the installation video below.

General Assembly Steps:

1. Unpack all components and lay them out on a protected surface.
2. Attach legs with screws. Tighten using the provided tool.
3. Insert tabletop support brackets into pre-drilled holes.

4. Secure legs to brackets using included hex bolts.
5. Assemble the drawer boxes and install the metal drawer slides.
6. Attach the drawer fronts and handles.
7. Carefully flip the table upright once all connections are secure.

Installation Video:

Your browser does not support the video tag.

Video: A step-by-step installation guide for assembling the Decofy Fluted Nightstand with 2 Drawers.

OPERATING INSTRUCTIONS

Using the Charging Station:

The nightstand is equipped with a built-in charging station for your convenience. It features 1 Type-C port, 1 USB port, and 2 standard power outlets.

- Ensure the nightstand's power cord is securely plugged into a functional wall outlet.
- Connect your devices to the appropriate USB, Type-C, or AC outlets.
- The USB-A port provides 18W Quick Charge, and the USB-C port provides 20W Fast Charging.
- Avoid plugging in high-power appliances that exceed the charging station's capacity.

Built-in Charging Station

3X Faster Charging



2 AC Outlets
125V/12A



USB-A
18W Quick Charge



USB-C
20W Fast Charging

Image: Detail of the nightstand's top surface showing the integrated charging station with two AC outlets, one USB-A port, and one USB-C port.

Using the Drawers and Open Shelf:

The nightstand features two spacious drawers and an open storage shelf for organizing your belongings.

- The drawers operate on smooth-gliding metal slides for effortless opening and closing.
- Use the open shelf for items you need to access frequently, such as books or decorative items.
- The drawers are ideal for storing personal items, keeping your tabletop tidy.

Ample Storage Space

One open shelf & 2 drawers for spacious options



Image: The nightstand with its open shelf and two drawers, demonstrating its storage capacity for various items.

Product Features Overview:

Your browser does not support the video tag.

Video: An overview of the Decofy Fluted Nightstand, highlighting its design, storage, and charging capabilities.

MAINTENANCE

Proper care will ensure the longevity and appearance of your Decofy nightstand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** The engineered wood is stain-resistant. Wipe up spills immediately with a dry cloth to prevent moisture damage.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Stability:** Periodically check all fasteners and re-tighten if necessary to maintain stability.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Nightstand is wobbly	Loose fasteners; uneven floor	Check and tighten all screws and bolts. Place shims under legs if the floor is uneven.
Drawers stick or do not slide smoothly	Drawer slides misaligned; obstruction; loose screws on slides	Ensure drawer slides are correctly installed and aligned. Check for any objects obstructing the slides. Tighten screws on drawer slides.
Charging station not working	Power cord unplugged; wall outlet not functional; device incompatibility; overload	Verify the nightstand's power cord is fully plugged into a live wall outlet. Test the wall outlet with another device. Ensure your device is compatible. Avoid plugging in too many high-power devices simultaneously.
Missing parts during assembly	Packaging error	Contact Decofy customer support with your purchase details and the list of missing parts.

SPECIFICATIONS

- Brand:** Decofy
- Model Name:** DC-BG04
- Product Dimensions:** 15.5"D x 19.61"W x 24"H
- Item Weight:** 73.7 Pounds
- Maximum Weight Recommendation:** 110 Pounds
- Frame Material:** Engineered Wood
- Furniture Finish:** Natural Oak
- Color:** Natural Oak (Light Brown Top Color)
- Number of Drawers:** 2
- Charging Station:** 1 Type-C port (20W Fast Charging), 1 USB-A port (18W Quick Charge), 2 AC Power Outlets (125V/12A)
- Assembly Required:** Yes
- Included Components:** Assembly Guide
- Special Features:** Fluted Panel Design, Smooth Curved Edges, Stable Support Base, Smooth Sliding Drawers, Stain Resistant

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact Decofy customer support directly. This product is eligible for a 30-day return policy through the retailer.

For further assistance, missing parts, or technical support, please visit the official [Decofy Store](#) or contact their customer service.

