TRAUSI T7

TRAUSI T7 Wireless Earbuds Instruction Manual

Model: T7

1. Introduction

This manual provides instructions for the TRAUSI T7 Wireless Earbuds. It covers product features, setup, operation, maintenance, and troubleshooting to ensure optimal performance and user experience. Please read this manual thoroughly before using the product.

2. Package Contents

Verify that all items listed below are included in your package:

- T7 Wireless Earbuds (2 units)
- Wireless Charging Case (1 unit)
- USB-C Charging Cable (1 unit)
- Eartips (S/M/L sizes, 3 pairs)
- User Manual (1 unit)




Image: All-inclusive accessories pack for TRAUSI T7 Wireless Earbuds.

3. Product Overview

3.1 Earbuds and Charging Case

The TRAUSI T7 earbuds feature an ergonomic design for comfortable wear and touch-sensitive controls. The charging case incorporates a unique 180° swivel mechanism and a full-color smart LCD touch screen for enhanced control.



Image: TRAUSI T7 Wireless Earbuds and Charging Case.

3.2 180° Swivel Design

The charging case features a 180° swivel design, allowing for easy single-handed opening and closing. This mechanism also provides a tactile experience.

3.3 Smart LCD Touch Screen

The charging case is equipped with an interactive LCD touch screen. This screen allows direct control over various functions without needing to access your paired device.



Image: Intelligent LED Touchscreen Display on the TRAUSI T7 Charging Case.

4. Getting Started

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case.
2. Connect the USB-C charging cable to the charging port on the case and to a power source.
3. The LCD screen on the case will display the charging status and battery percentages for both earbuds and the case.
4. A full charge provides approximately 4-5 hours of continuous earbud use, with the case extending total playtime to over 48 hours.



Image: Battery life and charging display on the TRAUSI T7.

4.2 Pairing with a Device

The TRAUSI T7 earbuds utilize Bluetooth 5.4 for stable and efficient connections.

1. Ensure the earbuds are charged and inside the charging case.
2. Open the charging case. The earbuds will automatically enter pairing mode.

3. On your device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for available Bluetooth devices and select "TRAUSI T7" from the list.
5. Once connected, the earbuds will indicate successful pairing, and the device will show a connected status.



Image: Advanced Bluetooth 5.4 connectivity for TRAUSI T7.

5. Operating Your Earbuds

5.1 Earbud Touch Controls

The earbuds feature touch-sensitive areas for various functions:

Action	Function
Single Tap	Play/Pause music, Answer/End call
Double Tap (Left Earbud)	Volume Down
Double Tap (Right Earbud)	Volume Up
Triple Tap (Left Earbud)	Previous Track
Triple Tap (Right Earbud)	Next Track
Long Press (2 seconds)	Reject Call, Activate Voice Assistant (Siri, Google Assistant)



Image: Earbud Touch Controls.

5.2 Charging Case Touch Screen Functions

The LCD touch screen on the charging case provides direct access to several features:

- **Music Control:** Play/pause, skip tracks, and adjust volume.
- **EQ Presets:** Select from multiple equalizer settings (e.g., Jazz, Bass, Pop).
- **Find My Earbuds:** Activate a sound on misplaced earbuds to locate them.
- **Screen Brightness:** Adjust the display brightness.
- **Custom Wallpapers:** Personalize the screen background.
- **Timer Settings:** Set a timer directly from the case.




Image: 'Find My Earbuds' function on the charging case screen.

5.3 Call Management

The T7 earbuds feature Environmental Noise Cancellation (ENC) technology for clear calls.

- **Answering Calls:** Single tap either earbud.
- **Ending Calls:** Single tap either earbud.
- **Rejecting Calls:** Long press either earbud for 2 seconds.
- ENC technology filters out background noise, ensuring your voice is clear to the person on the other end.




Image: Noise-Canceling Calls for Crystal Clear Communication.

6. Maintenance and Care

6.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Clean the charging contacts on both the earbuds and the case to ensure proper charging.

6.2 Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Avoid storing the device in extreme temperatures or high humidity.

6.3 Water Resistance (IPX7)

The TRAUSI T7 earbuds are IPX7 waterproof, meaning they can withstand immersion in water up to 1 meter for 30 minutes. This makes them suitable for workouts and light rain exposure. However, they are not designed for swimming or prolonged water immersion.

- Ensure the earbuds are dry before placing them back into the charging case to prevent damage.
- The charging case is not waterproof.




Image: IPX7 Waterproof rating for TRAUSI T7.

7. Troubleshooting

7.1 Earbuds Not Pairing

- Ensure both earbuds are charged.
- Place earbuds back into the case, close it, then open it again to re-enter pairing mode.
- Turn off and on your device's Bluetooth.
- Forget/delete "TRAUSI T7" from your device's Bluetooth list and try pairing again.

7.2 No Sound from One Earbud

- Check the battery level of both earbuds on the charging case screen.
- Ensure both earbuds are properly seated in the charging case to make contact with charging pins.
- Try resetting the earbuds (refer to specific reset instructions if available in a full manual, otherwise, re-pair).

7.3 Charging Case Not Charging

- Verify the USB-C cable is securely connected to both the case and the power source.
- Try using a different USB-C cable and power adapter.
- Ensure the charging port on the case is free of debris.

8. Specifications

Feature	Detail
Model Name	T7
Bluetooth Version	5.4
Bluetooth Range	Up to 15 meters
Audio Driver Size	13 mm
Noise Control	Environmental Noise Cancellation (ENC)

Feature	Detail
Earbud Battery Life	4-5 hours (single charge)
Total Playtime (with case)	Over 48 hours
Charging Case Capacity	400 mAh
Charging Port	USB-C
Water Resistance Rating	IPX7 (earbuds only)
Control Type	Touch Control (earbuds), Touch Screen (case)
Compatible Devices	iPhone, Android, Cellphones, Desktops, Laptops, Tablets
Material	Plastic
Item Weight	1 Grams (per earbud)

9. Warranty Information

The TRAUSI T7 Wireless Earbuds come with a 90-day manufacturer's warranty from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims.

10. Customer Support

For further assistance, technical support, or warranty inquiries, please contact TRAUSI customer service through the retailer's platform or visit the official TRAUSI website for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question