

[Manuals.plus](#) /

> [AEEZO](#) /

> AEEZO 10.1-Inch Digital Picture Frame User Manual

AEEZO 10.1 Inch Digital Picture Frame

AEEZO 10.1-Inch Digital Picture Frame User Manual

Model: 10.1 Inch Digital Picture Frame

INTRODUCTION


This manual provides instructions for setting up, operating, and maintaining your AEEZO 10.1-inch Digital Picture Frame. This device allows you to display photos and videos, share memories with loved ones, and enjoy a personalized visual experience.



The AEEZO 10.1-inch Digital Picture Frame, designed for displaying cherished memories.

PRODUCT FEATURES

- **10.1-inch HD IPS Touch Screen:** Provides clear, vibrant images with a 1280x800 resolution and 178° wide viewing angle.
- **32GB Internal Memory:** Stores over 50,000 photos.
- **Expandable Storage:** Supports Micro SD cards up to 64GB (not included) for file management. Note: Photos/videos must be imported to internal memory for playback.
- **Wi-Fi Connectivity:** Enables instant sharing via the AiMOR app.
- **Auto-Rotate Function:** Automatically adjusts photo orientation based on frame placement.
- **Smart Features:** Built-in light sensor for automatic brightness adjustment, customizable slideshows, adjustable volume, and sleep mode.
- **Multi-User Connection:** Allows multiple users to share photos and videos to the frame remotely.



Key features of the AEEZO 10.1-inch WiFi Digital Photo Frame.

SETUP

1. Unboxing and Initial Placement

Carefully remove the digital picture frame and its accessories from the packaging. Place the frame on a stable surface using the integrated stand. The frame can be positioned in either landscape or portrait orientation.

10.1 Inch High-Quality Immersive Display



1280*800 HD



Vibrant Color Fidelity



16:10 Aspect Ratio



178° Wide View



The digital frame with its adjustable stand for versatile placement.

2. Powering On

Connect the power adapter to the frame's power port and then plug it into a wall outlet. The frame will automatically power on and display the initial setup screen.

3. Wi-Fi Connection

Follow the on-screen prompts to connect your frame to a 2.4GHz Wi-Fi network. A stable Wi-Fi connection is essential for sharing photos and videos via the AiMOR app.

4. AiMOR App Setup and Pairing

1. Download the AiMOR app from the Google Play Store or Apple App Store on your smartphone.
2. Open the app and create an account or log in.
3. On your digital frame, navigate to the 'Add Friend' or 'Pair Device' section to generate a unique pairing code.

4. In the AiMOR app, enter this pairing code to link your smartphone with the digital frame.



Instructions for downloading and pairing the AiMOR app with your AEEZO frame.

OPERATING INSTRUCTIONS

1. Sharing Photos and Videos via AiMOR App

Once paired, you can instantly send photos and videos from your smartphone to the digital frame using the AiMOR app. Multiple users can connect to the same frame to share memories.

1. Open the AiMOR app on your smartphone.
2. Select the photos or videos you wish to share from your gallery.
3. Choose the connected digital frame as the recipient.
4. Add an optional caption and select the display area if needed.
5. Tap 'Send' to transfer the media to your frame.



The digital frame helps families stay connected by sharing moments.

2. Touchscreen Navigation

The frame features an intuitive touchscreen interface. Swipe left or right to navigate through photos, tap to access

settings, and pinch to zoom.

3. Display Settings

- **Slideshow:** Customize slideshow intervals and transition effects in the settings menu.
- **Brightness:** Adjust screen brightness manually or enable the built-in light sensor for automatic adjustment based on ambient light.
- **Volume:** Control the volume for videos in the settings.
- **Auto-Rotate:** The frame automatically detects its orientation (landscape or portrait) and adjusts the display accordingly.
- **Sleep Mode:** Set a schedule for the frame to automatically enter and exit sleep mode, conserving energy.
- **Time and Weather:** Enable the display of current time and weather information on the screen.

Share Your Feelings, Deepen Your Bond



Adjusting brightness and volume settings on the AEEZO digital frame.

Share Your Feelings, Deepen Your Bond



The frame features a sleep mode and an automatic rotation function.

4. Memory Management

The frame has 32GB of built-in memory. You can also insert an SD card or USB drive (up to 64GB) to import additional photos and videos. Note that media cannot be played directly from external storage; it must first be imported to the frame's internal memory.

Sleep Mode

The photo frame automatically enters sleep mode during the preset time period everyday. Please note that the frame in sleep mode can still receive photos.



Auto Rotate Function

Better showcasing the photos according to its placement



The frame offers 32GB of internal memory, expandable with an SD card.

MAINTENANCE

1. Cleaning the Screen

To clean the touchscreen, gently wipe it with a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaning solution. Avoid using harsh chemicals or abrasive materials.

2. Software Updates

The frame supports software updates to improve performance and add new features. Ensure your frame is connected to Wi-Fi and check for available updates in the settings menu periodically.

3. General Care

Keep the frame away from direct sunlight, extreme temperatures, and high humidity. Avoid dropping the device or exposing it to liquids.

TROUBLESHOOTING

- **Frame not powering on:** Ensure the power adapter is securely connected to both the frame and a working power outlet.
- **Cannot connect to Wi-Fi:** Verify your Wi-Fi password and ensure you are connecting to a 2.4GHz network. Try restarting your router and the frame.
- **Photos not appearing on frame:** Confirm that the frame is paired correctly with the AiMOR app and that photos/videos have been successfully sent. Check the frame's internal memory storage.
- **Screen unresponsive:** Try restarting the frame by unplugging and re-plugging the power adapter. If the issue persists, contact customer support.
- **SD card/USB not recognized:** Ensure the external storage device is formatted correctly and inserted properly. Remember to import files to internal memory for display.

SPECIFICATIONS

Feature	Detail
Brand	AEEZO
Color	Black
Screen Size	10.1 Inches
Resolution	1280 x 800 (WXGA)
Display Type	IPS Touchscreen
Aspect Ratio	16:10
Memory Storage Capacity	32 GB
Expandable Memory	Max 64GB SD card or USB driver
Connectivity Technology	Wi-Fi (2.4GHz)
Power Source	Corded Electric
Control Method	App, Touch
Item Dimensions (L x W)	10.39"L x 7.09"W
UPC	768857725117

WARRANTY AND SUPPORT

AEEZO provides a **1-year limited manufacturer's warranty** for this digital picture frame. Our factory adheres to strict quality standards, and each unit undergoes 200 hours of machine aging tests before shipment to ensure proper functionality.

For any questions, technical assistance, or warranty claims, please contact AEEZO customer support. We offer lifetime support and aim to provide a prompt response within 24 hours.

Contact Information: Please refer to the contact details provided in your product packaging or visit the official AEEZO website for support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GJ5D2XP6>

More documents and user manuals: <https://manuals.plus/>