

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Geekee](#) /
- › [Geekee CG6 Wireless Outdoor Security Camera System User Manual](#)

Geekee CG6

Geekee CG6 Wireless Outdoor Security Camera System User Manual

Model: CG6

INTRODUCTION

This manual provides essential information for the installation, operation, and maintenance of your Geekee CG6 Wireless Outdoor Security Camera System. Please read these instructions carefully before use to ensure optimal performance and longevity of your device.

The Geekee CG6 camera system offers advanced security features including 2K resolution video, dual light source night vision, AI-powered motion detection, and two-way audio communication. Designed for both indoor and outdoor use, these battery-powered cameras provide flexible placement and reliable monitoring.

WHAT'S IN THE BOX

Verify that all components are present in your package:

- Geekee CG6 Security Camera (2 units)
- USB Charging Cable
- Instruction Manual (this document)
- Screws Set for Mounting
- Mounting Brackets (2 units)



Image: The Geekee CG6 Security Camera System, showing the camera units and included accessories.

PRODUCT FEATURES

- **2K HD Video & Night Vision:** Capture clear, detailed footage with 2K (3MP) resolution. Features dual light source night vision, offering both full-color and infrared options for visibility in low-light conditions. The 110° wide-angle lens provides broad coverage.

2K HD Day and Night

Full color, even at night




Image: A comparison demonstrating the clarity of 2K HD day vision and full-color night vision provided by the camera.

- **100% Wireless & Battery Powered:** Each camera is equipped with a built-in 5200mAh rechargeable battery, allowing for true wireless installation without the need for constant power cords.

100% True Wireless

Low power consumption, built-in 5200mAh rechargeable battery.

A single charge can trigger up to 3,300 times.



Built-in 5200mAh
rechargeable battery

Image: An internal diagram showing the integrated 5200mAh rechargeable battery within the camera unit.

- **Intelligent PIR Motion Detection:** An integrated infrared motion detection sensor accurately detects movement within a customizable range, sending instant notifications to your smartphone via the VicoHome app.
- **Two-Way Talk & Siren Alarm:** Communicate with visitors or deter intruders using the built-in microphone and speaker. The camera can also activate flashing white lights and a siren alarm upon detecting suspicious activity.



Two-way Voice Intercom

Talk to anyone anytime, anywhere




Image: Illustration of the two-way voice intercom feature, allowing communication through the camera.

- **IP65 Weatherproof:** Designed to withstand various weather conditions, ensuring reliable operation outdoors in rain, snow, or shine.

IP65 Waterproof

Work under any condition



Image: The camera shown operating effectively in both rainy and snowy outdoor environments, highlighting its IP65 weatherproof rating.

- **Flexible Dual Storage Options:** Offers a 7-day free trial for cloud storage with easy playback. Supports local storage via a microSD card up to 128GB (not included).
- **AI Intelligent Recognition & Custom Activity Zones:** Advanced features (available with a 30-day free trial) include AI recognition for people, vehicles, and pets, and the ability to define custom monitoring areas.




Image: Visual representation of the camera's AI capabilities, distinguishing between humans, pets, and vehicles within a defined activity zone.

SETUP GUIDE

1. **Download the VicoHome App:** Scan the QR code provided in the packaging or search for "VicoHome" in the App Store (iOS) or Google Play Store (Android) to download and install the application.
2. **Create an Account:** Open the VicoHome app and follow the on-screen instructions to register a new user account.
3. **Charge the Camera:** Before initial use, fully charge your camera using the provided USB cable. The charging port is protected by a silicone cover on the bottom of the camera.
4. **Connect to Wi-Fi:** Ensure your camera is within range of a 2.4GHz Wi-Fi network. The camera does not support 5GHz Wi-Fi. Follow the in-app instructions to connect your camera to your home Wi-Fi network.
5. **Add Camera to App:** Once connected to Wi-Fi, use the VicoHome app to add your new camera. The app will guide you through the pairing process.
6. **Mount the Camera:** Use the included mounting brackets and screws to install the camera in your desired indoor or outdoor location. Ensure the camera has a clear view of the area you wish to monitor.



Image: Visual guide illustrating the simple steps for setting up and installing the camera.

OPERATING INSTRUCTIONS

- **Live View:** Open the VicoHome app and select your camera to view live video feed from anywhere.
- **Motion Detection Alerts:** When motion is detected, the camera will send an instant notification to your phone. Tap the notification to view the recorded event.
- **Two-Way Audio:** During live view, use the microphone icon in the app to speak through the camera's speaker. Use the speaker icon to listen to audio from the camera's microphone.
- **Activating Alarms:** In the app, you can manually trigger the flashlight and siren alarm to deter unwanted visitors. These can also be set to activate automatically upon motion detection.
- **Accessing Recordings:** Recorded events are stored in the cloud (with subscription) or on a local microSD card. Access and playback recordings directly through the VicoHome app.
- **Customizing Settings:** Adjust motion detection sensitivity, define activity zones, and configure notification preferences within the VicoHome app settings for each camera.



Easy to Set Up & Use



1. Scan QR code to download Vicohome APP
Register a Vico Account



2. Fully charge and follow the steps to connect



3. Add camera to your phone

Image: A smartphone displaying the Vicohome app interface, showing live camera feeds and control options.

MAINTENANCE

- **Battery Charging:** The camera's 5200mAh battery requires periodic recharging. The frequency depends on usage and motion detection events. When the battery level is low, you will receive a notification via the Vicohome app. Remove the camera from its mount and charge it using the USB cable.
- **Cleaning the Lens:** Regularly clean the camera lens with a soft, dry cloth to ensure clear image quality. Avoid using abrasive cleaners.
- **Weather Protection:** After charging, ensure the silicone cover for the charging port is securely closed to maintain the IP65 weatherproof rating.
- **Firmware Updates:** Check the Vicohome app periodically for available firmware updates to ensure your camera has the latest features and security enhancements.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Camera not connecting to Wi-Fi	Incorrect Wi-Fi password; Camera too far from router; Using 5GHz Wi-Fi.	Verify password; Move camera closer to router; Ensure you are connecting to a 2.4GHz Wi-Fi network.

Problem	Possible Cause	Solution
Poor image quality	Dirty lens; Low light conditions; Weak Wi-Fi signal.	Clean the camera lens; Ensure adequate lighting or enable night vision; Improve Wi-Fi signal strength.
Short battery life	Frequent motion detection events; Extreme temperatures; Continuous live view.	Adjust motion detection sensitivity or activity zones; Avoid extreme temperatures; Minimize continuous live viewing.
No motion detection alerts	Motion detection disabled; Incorrect sensitivity settings; App notifications blocked.	Enable motion detection in app; Adjust sensitivity; Check phone's notification settings for VicoHome app.

SPECIFICATIONS

- **Model:** CG6
- **Brand:** Geekee
- **Resolution:** 2K (3MP)
- **Viewing Angle:** 110 Degrees
- **Night Vision:** Full-Color and Infrared
- **Connectivity:** 2.4GHz Wi-Fi (IEEE 802.11b/g/n)
- **Power Source:** Battery Powered (5200mAh rechargeable battery)
- **Waterproof Rating:** IP65
- **Audio:** Two-Way Talk
- **Storage:** Cloud Storage (subscription required after trial), MicroSD Card (up to 128GB, not included)
- **Motion Detection:** PIR Motion Sensor with AI Recognition
- **Alerts:** App Notifications, Siren Alarm, Flashing White Lights
- **Dimensions:** 5.9 x 3.9 x 4.72 inches (approximate per camera)
- **Included Items:** 2 Security Cameras, USB Cable, Mounting Hardware

WARRANTY AND SUPPORT

Geekee is committed to providing high-quality products and customer satisfaction. Your Geekee CG6 Wireless Outdoor Security Camera System comes with:

- **Lifetime Technical Support:** We offer lifetime technical assistance for your product.
- **Responsive Customer Service:** For any inquiries or support needs, please contact us via email. We aim to reply within 24 hours.

Contact Support: support@getgeekee.com



Geekee

Image: The official Geekee company logo.

© 2026 Geekee. All rights reserved.