

VINGLI VL-G61000738+G61000739

VINGLI Garden Arbor Instruction Manual

Model: VL-G61000738+G61000739

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, safe operation, and maintenance of your VINGLI Garden Arbor. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of the product. Keep this manual for future reference.

The VINGLI Garden Arbor is a heavy-duty PVC garden arch designed for supporting climbing plants and serving as a decorative backdrop for various outdoor events. Its dimensions are 94 inches high and 59.8 inches wide.

2. SAFETY INFORMATION

- Always prioritize safety during assembly and use. Failure to follow these instructions may result in injury or damage to the product.
- Ensure all components are present and undamaged before beginning assembly. Do not use if any parts are missing or broken.
 - Assemble the arbor on a flat, stable surface.
 - Use appropriate tools as specified in the assembly instructions.
 - Securely install the provided ground anchors to ensure the arch remains stable and does not easily bend or sway, especially in windy conditions.
 - Do not allow children to climb on the arbor.
 - Avoid hanging excessively heavy objects on the arch, as this may compromise its stability and structural integrity.
 - Periodically check all connections and anchors to ensure they remain tight and secure.

3. PACKAGE CONTENTS

Verify that all parts listed below are included in your package. If any parts are missing, contact VINGLI customer support.

Part	Description	Quantity
------	-------------	----------

Part	Description	Quantity
Arch Sections	Curved and straight PVC sections forming the arch structure.	Varies by design (refer to diagram)
Lattice Panels	Side panels for plant climbing.	Varies by design (refer to diagram)
Connectors/Joints	Pieces to connect the PVC sections.	Varies by design (refer to diagram)
Ground Anchors/Stakes	For securing the arbor to the ground.	4 PCS (as per image)
Hardware Kit	Screws, bolts, or other fasteners.	1 Set
Instruction Manual	This document.	1

Note: The exact number and type of components may vary slightly. Refer to the included diagram for precise identification.

4. SETUP AND ASSEMBLY

Assembly is designed to be straightforward and can typically be completed by one person in approximately 30 minutes. Follow these step-by-step instructions carefully.

- Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all parts against the package contents list.
- Assemble Side Panels:** Connect the vertical PVC sections and horizontal lattice bars to form the two side panels of the arbor. Ensure all connections are secure.
- Attach Arch Sections:** Connect the curved arch sections to the top of the assembled side panels. Ensure the arch is properly aligned and secured.
- Secure Connections:** Use the provided hardware (screws, bolts, etc.) to firmly secure all joints and connections. Do not overtighten.
- Position the Arbor:** Carefully move the assembled arbor to its desired location. Ensure the ground is level and firm.
- Install Ground Anchors:** Insert the four ground anchors into the base of each leg of the arbor and drive them into the ground until secure. This provides stability.



Image: Product dimensions (94" H x 59.8" W) and the inclusion of 4 ground stakes for stability.

5. OPERATING AND USAGE

The VINGLI Garden Arbor is designed for versatile use in various outdoor settings.

- **Plant Support:** Utilize the lattice panels and arch structure to support climbing plants such as roses, vines, morning glories, and other flowering or foliage plants. Guide the plant stems gently through the lattice as they grow.
- **Decorative Element:** Enhance your garden, entryway, or event space by decorating the arbor. It can serve as a backdrop for weddings, festivals, or holiday displays.
- **Event Backdrop:** Ideal for creating an elegant entrance or photo opportunity at outdoor events.

VERSATILE USE

Entryway | Garden | Wedding



Image: Examples of the arbor's versatile use, including a wedding arch with drapes, a Christmas-decorated entryway, and a garden trellis with climbing roses.

ELEVATE YOUR LIFE WITH BEAUTY



Climbing Trellies



Rambler



Vines



Morning Glory

Decorations



Colorful Balloons



Decorative Lights



Wind Chimes

Image: The arbor functioning as a climbing trellis for plants like rambler roses, vines, and morning glory, and as a decorative element with balloons, lights, and wind chimes.

6. MAINTENANCE

The VINGLI Garden Arbor is constructed from high-quality PVC resin material, offering durability and low maintenance.

- **Cleaning:** Periodically wipe down the PVC surfaces with a damp cloth and mild soap to remove dirt, dust, or mildew. Rinse thoroughly with water. Avoid abrasive cleaners or harsh chemicals.
- **Inspection:** Regularly inspect all connections, joints, and ground anchors to ensure they remain secure. Tighten any loose fasteners as needed.
- **Winter Care:** The PVC material is designed to withstand various weather conditions. However, in areas with heavy snow or extreme ice, it is advisable to remove any heavy decorations or snow accumulation to prevent undue stress on the structure.

BUILD TO LAST

Made with PVC material,
durable and long-lasting



Maintenance
Free



Rust Free



Image: The garden arbor shown in a winter setting, emphasizing its durable, maintenance-free, and rust-free PVC construction.

7. TROUBLESHOOTING

If you encounter any issues with your VINGLI Garden Arbor, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Arbor feels unstable or wobbly.	Ground anchors not fully secured; loose connections; uneven ground.	Ensure ground anchors are driven deep into firm soil. Check and tighten all screws and connections. Relocate to a more level surface if necessary.
Difficulty assembling parts.	Parts misaligned; incorrect part usage.	Refer to the assembly diagram and instructions. Ensure parts are oriented correctly before attempting to connect them. Do not force parts together.

Problem	Possible Cause	Solution
PVC surface appears dirty or discolored.	Accumulation of dirt, dust, or mildew.	Clean with a damp cloth and mild soap. For stubborn stains, a soft brush may be used. Rinse thoroughly.

8. SPECIFICATIONS

Brand: VINGLI
Model Number: VL-G61000738+G61000739
Material: Heavy Duty PVC Resin
Color: White
Product Dimensions (W x H): 59.8 inches x 94 inches (approximately 152 cm x 239 cm)
Assembly Required: Yes
Included Accessories: Ground Anchors (4 PCS), Hardware Kit

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact VINGLI customer service. Details regarding specific warranty periods and terms are typically provided with your purchase documentation or can be found on the official VINGLI website.

If you have questions or require assistance with assembly, parts, or troubleshooting not covered in this manual, please reach out to our support team.

Contact Information: Refer to your purchase receipt or the VINGLI official website for the most current customer service contact details.

© 2026 VINGLI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0GJ9L7CNB>

More documents and user manuals: <https://manuals.plus/>